
**OPTICAL
SYSTEMS
DESIGN**

OPERATOR MANUAL

OSD2380 SERIES
MANAGED 8-PORT 10/100BASE-T AND
2-PORT GIGABIT ETHERNET SWITCH

OPTICAL SYSTEMS DESIGN

INDEX 1

1	QUICK START GUIDE	5
1.1	FUNCTIONAL DESCRIPTION	5
1.2	PHYSICAL DESCRIPTION	6
1.3	POWER REQUIREMENTS	7
1.4	CONSOLE CONFIGURATION	8
1.4.1	CONNECT TO THE SWITCH CONSOLE:.....	8
1.4.2	CONFIGURATION SETTINGS OF THE TERMINAL-EMULATION PROGRAM:.....	8
1.5	WEB CONFIGURATION.....	10
2	TECHNICAL SUMMARY.....	12
2.1	BRIEF DESCRIPTION	12
2.1.1	PREFACE.....	12
2.1.2	OVERVIEW	12
2.1.3	APPLICATIONS.....	12
2.1.4	FEATURES AND BENEFITS.....	12
2.2	TYPICAL CONFIGURATION.....	13
2.3	TECHNICAL SPECIFICATIONS	14
2.4	OSD2380 FRONT AND TOP PANELS.....	15
2.4.1	OSD2380 DIMENSIONS.....	16
3	INSTALLATION AND OPERATION.....	17
3.1	INTRODUCTION	17
3.2	INSTALLATION	17
3.2.1	WARNING AND PRECAUTIONS	17
3.2.2	LOCATION.....	18
3.2.3	POWER SUPPLY CONNECTIONS	18
3.2.4	DB9 CONFIGURATION CONNECTIONS	19
3.2.5	LED INDICATORS	20
3.2.6	FITTING SFP CONNECTORS.....	20
3.3	OSD2380 OPERATION	21
3.3.1	CABLE CONNECTIONS	21
4	SWITCH MANAGEMENT.....	22
4.1	MANAGEMENT ACCESS OVERVIEW.....	22
4.2	ADMINISTRATION CONSOLE (CLI)	22
4.2.1	DIRECT ACCESS.....	22
4.2.2	MODEM ACCESS	23
4.3	WEB MANAGEMENT	23
4.4	SNMP-BASED NETWORK MANAGEMENT	23
4.5	PROTOCOLS	24
4.6	MANAGEMENT ARCHITECTURE	24
5	SNMP & RMON MANAGEMENT	25
5.1	OVERVIEW	25
5.2	SNMP AGENT AND MIB-2 (RFC 1213)	25
5.3	RMON MIB (RFC 2819) AND BRIDGE MIB (RFC 1493)	26
5.3.1	RMON GROUPS SUPPORTED	26
5.3.2	BRIDGE GROUPS SUPPORTED	26
6	WEB-BASED BROWSER MANAGEMENT	27
6.1	LOGGING ON TO THE SWITCH.....	27
6.2	UNDERSTANDING THE BROWSER INTERFACE	28
6.3	SYSTEM	29
6.4	PORT	40
6.5	SWITCHING.....	45
6.6	TRUNKING	48
6.7	STP / RING	49

OPTICAL SYSTEMS DESIGN

6.8	VLAN	58
6.9	QoS.....	64
6.10	SNMP	67
6.11	802.1X.....	73
6.12	OTHER PROTOCOLS	77
7	COMMAND LINE CONSOLE MANAGEMENT.....	83
7.1	ADMINISTRATION CONSOLE	83
7.1.1	EXEC MODE (VIEW MODE)	84
7.1.2	PRIVILEGED EXEC MODE (ENABLE MODE).....	89
7.1.3	CONFIGURE MODE (CONFIGURE TERMINAL MODE)	94
7.2	SYSTEM	99
7.3	PORT	107
7.4	SWITCHING.....	111
7.5	TRUNKING.....	115
7.6	STP / RING	116
7.7	VLAN	128
7.8	QoS.....	133
7.9	SNMP	136
7.10	802.1X.....	144
7.11	OTHER PROTOCOLS	148
8	APPENDIX A.....	157
9	APPENDIX B.....	161
10	MAINTENANCE.....	162
10.1	INTRODUCTION	162
10.2	EXTERNAL INSPECTION	162
10.3	ROUTINE MAINTENANCE.....	162
11	WARRANTY	163
11.1	WARRANTY PERIOD	163
11.2	REPAIRS.....	163
11.2.1	WARRANTY REPAIRS.....	163
11.2.2	OUT-OF-WARRANTY REPAIRS.....	163
11.2.3	SITE REPAIRS	163
11.2.4	EXCLUSIONS	163
FIGURE 1:	OSD2380 FRONT AND TOP PANELS.....	6
FIGURE 2:	CONFIGURATION SETTINGS	8
FIGURE 3:	CONFIGURATION SETTINGS	9
FIGURE 4:	WEB CONGIURATION	10
FIGURE 5:	WEB CONFIGURATION	11
FIGURE 6:	OSD2380 TYPICAL CONFIGURATION	13
FIGURE 7:	OSD2380 FRONT AND REAR PANELS	15
FIGURE 8:	OSD2380 DIMENSIONS	16
FIGURE 9:	POWER SUPPLY CONNECTIONS	18
FIGURE 10:	FITTING/REMOVING SFP CONNECTORS	20
TABLE 1:	OSD2380 LED FUNCTIONS	6
TABLE 2:	OSD2380 POWER REQUIREMENTS	7
TABLE 3:	TECHNICAL SPECIFICATIONS	14
TABLE 4:	POWER REQUIREMENTS	19
TABLE 5:	DB9 CONFIGURATION CONNECTOR.....	19
TABLE 6:	OSD2380 LED INDICATORS	20
TABLE 7:	CABLE SPECIFICATIONS	21

OPTICAL SYSTEMS DESIGN

1 QUICK START GUIDE

This quick start guide describes how to install and use the Managed Ethernet Switch.

1.1 FUNCTIONAL DESCRIPTION

- Complies with EN50121-4 environmental requirements for railway applications.
- Meets NEMA TS1/TS2 Environmental requirements such as temperature, shock, and vibration for traffic control equipment.
- Meets EN61000-6-2 & EN61000-6-3 EMC Generic Standard Immunity for industrial environment.
- Manageable via SNMP, Web-based, Telnet, and RS-232 console port.
- Supports IEEE802.3/802.3u/802.3z/802.3x. Auto-negotiation: 10/100Mbps-full/half-duplex; Auto MDI/MDIX.
- 100Base-FX: Multi mode SC or ST type, Single mode SC or ST type. 100Base-BX: WDM Single mode SC type.
- 1000Base-SX/LX: Multi mode SC type, Single mode SC type. 1000Base-BX: WDM Single mode SC type.
- Supports 8192 MAC addresses. Provides 2M bits memory buffer.
- Store-and-forward mechanism.
- Full wire-speed forwarding rate.
- Alarms for power and port link failure by relay output.
- Power Supply: Redundant DC Terminal Block power inputs and 12VDC DC JACK with 100-240VAC external power supply.
- Operating voltage and Max. current consumption: 0.92A @ 12VDC, 0.46A @ 24VDC, 0.23A @ 48VDC. Power consumption: 11W Max.
- -40°C to 75°C (-40°F to 167°F) operating temperature range. Tested for functional operation @ -40°C to 85°C (-40°F to 185°F).
- Supports DIN-Rail and Panel Mounting installation.

OPTICAL SYSTEMS DESIGN

1.2 PHYSICAL DESCRIPTION




FIGURE 1: OSD2380 FRONT AND TOP PANELS

TABLE 1: OSD2380 LED FUNCTIONS

LED	State	Indication
Power 1	On	Power on
Power 2	Off	Power off
Power 3		
10/100Base-TX, 100Base-FX/BX		
Link/ACT	On	A valid network connection established
	Flashing	Transmitting or receiving data ACT stands for ACTIVITY
10/100/1000Base-TX, SFP, 1000Base-SX/LX/BX		
Link/ACT	On	A valid network connection established
	Flashing	Transmitting or receiving data ACT stands for ACTIVITY
1000	On	Connection at 1000Mbps speed

OPTICAL SYSTEMS DESIGN

1.3 POWER REQUIREMENTS

Power connection is located on the top panel of the OSD2380. Table 2 outlines the power connections required.

TABLE 2: OSD2380 POWER REQUIREMENTS

Power Input Assignment			
Power3		12VDC	DC Jack
Power2	+	12-48VDC	Terminal Block
	-	Power Ground	
	+	12-48VDC	
	-	Power Ground	
		Earth Ground	
Relay Output Rating			1A @ 24VDC
Relay Alarm Assignment			
	FAULT	*Warning signal disable for following: The relay contact closes if Power1 and Power2 are both failed but Power3 on. The relay contact closes if Power3 is failed but Power1 and Power2 are both on.	

OPTICAL SYSTEMS DESIGN

1.4 CONSOLE CONFIGURATION

1.4.1 CONNECT TO THE SWITCH CONSOLE:

Connect the DB9 straight cable to the RS-232 serial port of the device and the RS-232 serial port of the terminal or computer running the terminal emulation application. Direct access to the administration console is achieved by directly connecting a terminal or a PC equipped with a terminal-emulation program (such as HyperTerminal) to the switch console port.

1.4.2 CONFIGURATION SETTINGS OF THE TERMINAL-EMULATION PROGRAM:

Baud rate: 115,200bps

Data bits: 8

Parity: none

Stop bit: 1

Flow control: none

Press the “Enter” key. The Command Line Interface (CLI) screen should appear as below:

Logon to Exec Mode (View Mode):

At the “switch_a login:” prompt just type in “root” and press <Enter> to logon to Exec Mode (or View Mode). And the “switch_a>” prompt will show on the screen.





FIGURE 2: CONFIGURATION SETTINGS

- Logon to Privileged Exec Mode (Enable Mode): At the “switch_a>” prompt just type in “enable” and press <Enter> to logon to Privileged Exec Mode (or Enable Mode). And the “switch_a#” prompt will show on the screen.

OPTICAL SYSTEMS DESIGN

- Logon to Configure Mode (Configure Terminal Mode): At the “switch_a#” prompt just type in “configure terminal” and press <Enter> to logon to Configure Mode (or Configure Terminal Mode). And the “switch_a(config)#” prompt will show on the screen.



The screenshot shows a Windows HyperTerminal window titled "115200 - HyperTerminal". The window has a menu bar with File, Edit, View, Call, Transfer, Help. Below the menu is a toolbar with icons for copy, paste, cut, etc. The main window displays the following configuration session:

```
switch_a login: root
Switch version 1.43.1 01/22/12 15:40:59
switch_a>enable
switch_a#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
switch_a(config)#interface vlan1.1
switch_a(config-if)#ip address 192.168.1.10/24
switch_a(config-if)#

```

At the bottom of the window, there is a status bar with the text: Connected 0:01:52 VT100 115200 8-N-1 SCROLL CAPS NUM CAPTURE Print echo

FIGURE 3: CONFIGURATION SETTINGS

OPTICAL SYSTEMS DESIGN

1.5 WEB CONFIGURATION

- Login the switch:
Specify the default IP address (192.168.1.10) of the switch in the web browser. A login window will be shown as below:




FIGURE 4: WEB CONGIURATION

- Enter the factory default login ID: root.
- Enter the factory default password (no password).
- Then click on the “Login” button to log on to the switch.

OPTICAL SYSTEMS DESIGN




FIGURE 5: WEB CONFIGURATION

OPTICAL SYSTEMS DESIGN

2 TECHNICAL SUMMARY

2.1 BRIEF DESCRIPTION

2.1.1 PREFACE

This manual describes how to install and use the OSD2380 Managed Ethernet Switch. The OSD2380 switch is designed to deliver full scalability with SNMP/RMON web-based management functions. To get the most out of this manual, you should have an understanding of Ethernet networking concepts.

2.1.2 OVERVIEW

The OSD2380 is a managed 8-port 10/100BASE-T and 2-port Gigabit Ethernet switch designed to operate in tough industrial applications providing real-time redundant performance. It has 8 10/100Base RJ45 copper ports, two SFP ports which are sold separately.

The unit will operate on either 1310nm and/or 1550nm singlemode. Operation over at least 40km of singlemode fiber is possible by use of the appropriate SFP optical devices. It normally requires two fibers per SFP port but is optionally available for one fiber operation.

A major benefit of the OSD2380 is its reliable and consistent performance over the -40°C to +75°C temperature range that allows it to be used in uncontrolled environments such as roadside cabinets, mine sites and factories.

2.1.3 APPLICATIONS

- ▲ Any network utilising a mix of copper and fiber
- ▲ Industrial IP communications
- ▲ Self-healing Gigabit Ethernet backbone networks

2.1.4 FEATURES AND BENEFITS

- ▲ Complies with IEEE802.3i/802.3u/10/100Base-T, IEEE802.3z 1000Base-LX standards.
- ▲ Supports RSTP/MSTP/STP for Ethernet redundancy IP Multicast Filtering through IGMP Snooping V1, V2 & V3
- ▲ Supports port-based VLAN and IEEE802.1Q VLAN Tagging and GVRP
- ▲ IEEE802.1p QoS with four priority queues
- ▲ MAC-based trunking with automatic link fail-over
- ▲ RS232 console, Telnet, SNMP V1, V2c & V3, RMON, Web Browser, and TFTP Management
- ▲ Full wire-speed forwarding rate
- ▲ Supports IEEE802.1x Security
- ▲ Bandwidth Rate Control
- ▲ Per-port programmable MAC address locking
- ▲ Up to 24 Static Secure MAC addresses per port
- ▲ Port mirroring
- ▲ Supports NTP
- ▲ SFP module sold separately
- ▲ 1000Mbps-Full-duplex, 10/100Mbps-Full/Half-duplex, Auto-Negotiation, Auto-MDI/MDIX
- ▲ Operates over the temperature range of -40°C to +75°C

OPTICAL SYSTEMS DESIGN

2.2 TYPICAL CONFIGURATION

Figure 6 below indicates a possible set-up for an OSD2380 system.




FIGURE 6: OSD2380 TYPICAL CONFIGURATION

OPTICAL SYSTEMS DESIGN

2.3 TECHNICAL SPECIFICATIONS

TABLE 3: TECHNICAL SPECIFICATIONS

SPECIFICATION	PERFORMANCE
Electrical Data Interface	IEEE802.3i, IEEE802.3u, Base-T Ethernet at 10 or 100Mbps
Electrical Data Connector	RJ45 on the fixed copper ports
Configuration Connector	DB9
Optical Data Interface	IEEE802.3z, 1000Base-Lx, 1000Base-Sx
Optical connector	LC or SC for SFP modules
SFP Port Options	1000Base-Lx, 1000Base-Sx or 1000Base-T
Operating Mode	Half or full duplex for 10/100 Full duplex for 1000 Store-and-Forward Half-duplex back-pressure and IEEE802.3x full-duplex flow control
Transmitter Wavelength	1310nm ±30nm
Transmit Optical Power	>-10dBm to -4dBm (-5dBm and +2dBm @ 1310nm and 1550nm are optional)
Receiver Sensitivity	<-21dBm
Standard Optical Link Budget	>11dB: >800m on multimode fiber @ 1310nm (Fiber bandwidth limited) >20km on singlemode fiber @ 1310nm >40km on singlemode fiber @ 1550nm
Optional Optical Link Budget	>23dB: >100km on singlemode fiber with optional 1550nm devices
Indicators	1 x Power 8 x 10/100Base-T, Link/Activity 2 x 1000Base-Sx, 1000Base-Lx: Link/Activity
Dimensions (mm)	60W x 125D x 145H
Weight	6.2kg
Power Requirements	12 - 48V _{DC} (nominal) @ 11VA Max
Operating Temperature	-40°C to +75°C
Relative Humidity	5 to 95% non-condensing
Mounting	DIN-Rail (35mm top hat), Wall Mount

102238002

Note: 1000Base is only available via the optionally fitted SFP ports. 8 x 10/100Base RJ45 fixed copper ports.

OPTICAL SYSTEMS DESIGN

2.4 OSD2380 FRONT AND TOP PANELS

There are 8 fixed copper ports for 10/100Base-T and two optional SFP ports on the front panel. The top panel consists of a DB9 configuration connector, an 8-way terminal block, a DC power connector and a reset switch. Each section will be described further throughout this manual.




FIGURE 7: OSD2380 FRONT AND REAR PANELS

OPTICAL SYSTEMS DESIGN

2.4.1 OSD2380 DIMENSIONS

The OSD2380 is designed to be wall mounted onto a DIN-Rail (35mm top hat) fixture. The unit dimensions (excluding connectors, SFPs, etc) is shown in Figure 8 below.




FIGURE 8: OSD2380 DIMENSIONS

OPTICAL SYSTEMS DESIGN

3 INSTALLATION AND OPERATION

3.1 INTRODUCTION

This section outlines the methods required to install and operate the OSD2380 successfully. It should be studied carefully if damage to the equipment or poor results are to be avoided.

This equipment has been fully tested prior to dispatch and is ready for immediate operation. However it is advisable to check for external transportation damage before operation. If damage is evident, return the unit with the packaging to your supplier immediately.

3.2 INSTALLATION


3.2.1 WARNING AND PRECAUTIONS

▲ ELECTROMAGNETIC COMPATIBILITY

WARNING: This is a Class A product. In a domestic environment this product may cause radio interference in which case the user may be required to take adequate measures.

▲ OPTICAL OUTPUT OPERATION

WARNING: Laser Safety: Class 1 Laser Product per IEC/EN 60825-1:20011 standard.



PRECAUTIONS

- ▲ All service personnel should be provided training as to the hazards of direct viewing of laser radiation and of the precautionary measures during servicing of equipment
- ▲ Areas where laser products are installed should be restricted in access to trained service personnel only and appropriate warning signs posted in the work area.
- ▲ All laser apertures should be covered by protective covers when not connected to optical fibers. Never leave outputs uncovered.
- ▲ Laser equipment should be positioned above or below eye level where possible. Apertures should be positioned away from personnel.
- ▲ Protective eyewear should be worn in the vicinity of laser equipment.

OPTICAL SYSTEMS DESIGN

3.2.2 LOCATION

As with any electric device, you should place the switch where it will not be subjected to extreme temperatures, humidity, or electromagnetic interference. Specifically, the site you select should meet the following requirements:

- The ambient temperature should be between -40°C to 75°C (-40°F to 167°F).
- The relative humidity should be less than 95 percent, non-condensing.
- Surrounding electrical devices should not exceed the electromagnetic field (RFC) standards.
- Make sure that the switch receives adequate ventilation. Do not block the ventilation holes on each side of the switch.

3.2.3 POWER SUPPLY CONNECTIONS

The OSD2380 requires external power to either the Redundant DC Terminal Block Power Connector or the supplied 12VDC DC Jack both located at the top of the unit. Always ensure that the power is off before any installation.

12VDC DC Jack

Step 1: Connect the supplied AC to DC power adapter to the receptacle on the topside of the OSD2380.
Step 2: Connect the power cord to the AC to DC power adapter and attach the plug into a standard AC outlet with the appropriate AC voltage.

Redundant DC Terminal Block Power Inputs

There are two pairs of power inputs for use with redundant power sources. Only one power input is required to be connected to run the switch.

Step 1: Connect the DC power cord to the plug-able terminal block on the switch, and then plug it into a standard DC outlet.

Step 2: Disconnect the power cord if you want to shut down the switch.




FIGURE 9: POWER SUPPLY CONNECTIONS

OPTICAL SYSTEMS DESIGN

Alarms for Power Failure

Step 1: There are two pins on the terminal block used for power failure detection. It provides a normally closed (NC) output when the power source is active. Use this as a dry contact application to send a signal for power failure detection.

TABLE 4: POWER REQUIREMENTS

Power Input Assignment			
Power3		12VDC	DC Jack
Power2	+	12-48VDC	Terminal Block
	-	Power Ground	
	+	12-48VDC	
	-	Power Ground	
		Earth Ground	
Relay Output Rating			1A @ 24VDC
Relay Alarm Assignment			
	*Warning signal disable for following: The relay contact closes if Power1 and Power2 are both failed but Power3 on. The relay contact closes if Power3 is failed but Power1 and Power2 are both on.		
FAULT			

Note:

The relay output is normal open position when there is no power to the switch. Please do not connect any power source to this terminal to prevent shorting your power supply.

3.2.4 DB9 CONFIGURATION CONNECTIONS

The OSD2380 has a DB9 DCE connector located on the top of the unit. Table 5 outlines the pin assignments.

TABLE 5: DB9 CONFIGURATION CONNECTOR

Pin no.	Name	RS232 Signal name
1	DCD	Data Carrier detect
2	RxD	Received data
3	TxD	Transmit data
4	---	N/C
5	GND	Signal ground
6	DSR	Data set Ready
7	---	N/C
8	CTS	Clear to send
9	---	N/C

OPTICAL SYSTEMS DESIGN

3.2.5 LED INDICATORS

TABLE 6: OSD2380 LED INDICATORS

LED	State	Indication
Power 1	On	Power on
Power 2		
Power 3	Off	Power off
10/100Base-TX, 100Base-FX/BX		
Link/ACT	On	A valid network connection established
	Flashing	Transmitting or receiving data ACT stands for ACTIVITY
10/100/1000Base-TX, SFP, 1000Base-SX/LX/BX		
Link/ACT	On	A valid network connection established
	Flashing	Transmitting or receiving data ACT stands for ACTIVITY
1000	On	Connection at 1000Mbps speed

3.2.6 FITTING SFP CONNECTORS

Care should be taken when inserting/removing the SFP connectors from SFP ports as SFP modules are Electrostatic (ES) sensitive and Electrostatic Discharge (ESD) precautions should be taken when installing. Ensure that the SFP is fully engaged and latched into position.

Inserting SFP – Ensure that the SFP lever is in the locked position and insert into appropriate SFP port. Gently push the SFP until it locks into place. Remove plastic/rubber dust cap and fit fiber cable.

Removing SFP – Remove fiber connector and pull the SFP lever down to unlock SFP from housing. Using the lever, gently pull the SFP out.




FIGURE 10: FITTING/REMOVING SFP CONNECTORS

OPTICAL SYSTEMS DESIGN

3.3 OSD2380 OPERATION

When using the OSD2380 for the first time, check that the unit is in good condition with no visible damage.

Connect the unit to an appropriate power source and check that the indicators illuminate accordingly on power up (see Table 6) after all other connections have been made.

3.3.1 CABLE CONNECTIONS

It is necessary to follow the cable specifications below when connecting the switch to your network. Use appropriate cables that meet your speed and cabling requirements. Note: 1000Base is only available via the optionally fitted SFP ports. 8 x 10/100Base RJ45 fixed copper ports.

TABLE 7: CABLE SPECIFICATIONS

Speed	Connector	Port Speed Half/Full Duplex	Cable	Max. Distance
10Base-T	RJ-45	10/20 Mbps	2-pair UTP/STP Cat. 3, 4, 5	100m
100Base-TX	RJ-45	100/200 Mbps	2-pair UTP/STP Cat. 5	100m
100Base-FX	ST, SC	200 Mbps	MMF (62.5µm)	2km
100Base-FX	ST, SC	200 Mbps	SMF (10µm)	20, 40, 75, 100km
100Base-BX	SC	200 Mbps	MMF (62.5µm)	2, 5km
100Base-BX	SC	200 Mbps	SMF (10µm)	20, 40km
1000Base-SX	SC	2000 Mbps	MMF (62.5µm)	220m
1000Base-SX	SC	2000 Mbps	MMF (50µm)	550m
1000Base-LX	SC	2000 Mbps	SMF (10µm)	10, 20, 50km
1000Base-BX	SC	2000 Mbps	SMF (10µm)	20, 40km
SFP				
1000Base-SX	Duplex LC	2000 Mbps	MMF (62.5µm)	550m
1000Base-LX	Duplex LC	2000 Mbps	SMF (9µm)	10, 40, 60km
1000Base-BX	Duplex LC	2000 Mbps	SMF (9µm)	70km

Step 1: First, ensure the power of the switch and end devices are turned off.

Step 2: Prepare cable with corresponding connectors for each type of port in use.

Step 3: Consult Cable Specifications Table on previous page for cabling requirements based on connectors and speed.

Step 4: Connect one end of the cable to the switch and the other end to a desired device.

Step 5: Once the connections between two end devices are made successfully, turn on the power and the switch is operational.

OPTICAL SYSTEMS DESIGN

4 SWITCH MANAGEMENT

This chapter explains the methods that can be used to configure management access to the switch. It describes the types of management applications and the communication and management protocols that deliver data between your management device (workstation or personal computer) and the system. It also contains information about port connection options.

This chapter covers the following topics:

- Management Access Overview
- Key Concepts
- Key Guidelines for Implementation
- Web Management Access
- Administration Console Access
- SNMP Access
- Standards, Protocols, and Related Reading

4.1 MANAGEMENT ACCESS OVERVIEW

The switch gives you the flexibility to access and manage the switch using any or all of the following methods.

The web browser interface and administration console (CLI) support are embedded in the switch software and are available for immediate use.

4.2 ADMINISTRATION CONSOLE (CLI)

The administration console is an internal, character-oriented, Command Line Interface (CLI) for performing system administration such as displaying statistics or changing option settings.

Using this method, you can view the administration console from a terminal, personal computer, Apple Macintosh, or workstation connected to the switch's console port.

There are two ways to use this management method: direct access or modem access. The following sections describe these methods.

4.2.1 DIRECT ACCESS

Direct access to the administration console is achieved by directly connecting a terminal or a PC equipped with a terminal-emulation program (such as HyperTerminal) to the switch console port.

When using the management method, configure the terminal-emulation program to use the following parameters (you can change these settings after login):

OPTICAL SYSTEMS DESIGN

[Default parameters]

- 115,200bps
- 8 data bits
- No parity
- 1 stop bit

This management method is often preferred because you can remain connected and monitor the system during system reboots. Also, certain error messages are sent to the serial port, regardless of the interface through which the associated action was initiated. A Macintosh or PC attachment can use any terminal-emulation program for connecting to the terminal serial port. A workstation attachment under UNIX can use an emulator such as TIP.

4.2.2 MODEM ACCESS

You can access the switch's administration console from a PC or Macintosh using an external modem attached to the console port. The switch management program provides **Console Port** screen, accessible from the **Basic Management** screen that lets you configure parameters for modem access.

When you have configured the external modem from the administration console, the switch transmits characters that you have entered as output on the modem port. The switch echoes characters that it receives as input on the modem port to the current administration console session. The console appears to be directly connected to the external modem.

4.3 WEB MANAGEMENT

The switch provides a browser interface that lets you configure and manage the switch remotely.

After you set up your IP address for the switch, you can access the switch's web interface applications directly in your web browser by entering the IP address of the switch. You can then use your web browser to list and manage switch configuration parameters from one central location, just as if you were directly connected to the switch's console port.

4.4 SNMP-BASED NETWORK MANAGEMENT

You can use an external SNMP-based application to configure and manage the switch. This management method requires the SNMP agent on the switch and the SNMP Network Management Station to use the same community string. This management method, in fact, uses two community strings: the get community string and the set community string. If the SNMP Network management station only knows the set community string, it can read and write to the MIBs. However, if it only knows the get community string, it can only read MIBs. **The default get and set community strings for the switch are public.**

OPTICAL SYSTEMS DESIGN

4.5 PROTOCOLS

The switch supports the following protocols:

Virtual terminal protocols, such as Telnet

A virtual terminal protocol is a software program, such as Telnet, that allows you to establish a management session from a Macintosh, a PC, or a UNIX workstation. Because Telnet runs over TCP/IP, you must have at least one IP address configured on the switch before you can establish access to it with a virtual terminal protocol.

<Note> Terminal emulation is different from a virtual terminal protocol in that you must connect a terminal directly to the console port.

Simple Network Management Protocol (SNMP)

SNMP is the standard management protocol for multivendor IP networks. SNMP supports transaction-based queries that allow the protocol to format messages and to transmit information between reporting devices and data-collection programs. SNMP runs on top of the User Datagram Protocol (UDP), offering a connectionless-mode service.

4.6 MANAGEMENT ARCHITECTURE

All of the management application modules use the same Messaging Application Programming Interface (MAPI). By unifying management methods with a single MAPI, configuration parameters set using one method (e.g. console port) are immediately displayed by the other management methods (e.g. SNMP agent of web browser).

The management architecture of the switch adheres to the IEEE open standard. This compliance assures customers that the switch is compatible with, and will interoperate with other solutions that adhere to the same open standard.

OPTICAL SYSTEMS DESIGN

5 SNMP & RMON MANAGEMENT

This chapter describes the switch's Simple Network Management Protocol (SNMP) and Remote Monitoring (RMON) capabilities.

5.1 OVERVIEW

RMON is an abbreviation for the Remote Monitoring MIB (Management Information Base). RMON is a system defined by the Internet Engineering Task Force (IETF) document RFC 2819, which defines how networks can be monitored remotely.

RMONs typically consist of two components: an RMON probe and a management workstation:

- *The RMON probe is an intelligent device or software agent that continually collects statistics about a LAN segment or VLAN. The RMON probe transfers the collected data to a management workstation on request or when a pre-defined threshold is reached.*
- *The management workstation collects the statistics that the RMON probe gathers. The workstation can reside on the same network as the probe, or it can have an in-band or out-of-band connection to the probe.*

The switch provides RMON capabilities that allow network administrators to set parameters and view statistical counters defined in MIB-II, Bridge MIB, and RMON MIB. RMON activities are performed at a Network Management Station running an SNMP network management application with graphical user interface.

5.2 SNMP AGENT AND MIB-2 (RFC 1213)

The SNMP Agent running on the switch manager CPU is responsible for:

- *Retrieving MIB counters from various layers of software modules according to the SNMP GET/GET NEXT frame messages.*
- *Setting MIB variables according to the SNMP SET frame message.*
- *Generating an SNMP TRAP frame message to the Network Management Station if the threshold of a certain MIB counter is reached or if other trap conditions (such as the following) are met:*
 - Warm start
 - Cold start
 - Link up
 - Link down
 - Authentication failure
 - Rising alarm
 - Falling alarm
 - Topology Alarm

MIB-II defines a set of manageable objects in various layers of the TCP/IP protocol suites. MIB-II covers all manageable objects from layer 1 to layer 4, and, as a result, is the major SNMP MIB supported by all vendors in the networking industry. The switch supports a complete implementation of SNMP Agent and MIB-II.

OPTICAL SYSTEMS DESIGN

5.3 RMON MIB (RFC 2819) AND BRIDGE MIB (RFC 1493)

The switch provides hardware-based RMON counters in the switch chipset. The switch manager CPU polls these counters periodically to collect the statistics in a format that complies with the RMON MIB definition.

5.3.1 RMON GROUPS SUPPORTED

The switch supports the following RMON MIB groups defined in RFC 2819:

- *RMON Statistics Group – maintains utilization and error statistics for the switch port being monitored.*
- *RMON History Group – gathers and stores periodic statistical samples from the previous Statistics Group.*
- *RMON Alarm Group – allows a network administrator to define alarm thresholds for any MIB variable. An alarm can be associated with Low Threshold, High Threshold, or both. A trigger can trigger an alarm when the value of a specific MIB variable exceeds a threshold, falls below a threshold, or exceeds or falls below a threshold.*
- *RMON Event Group – allows a network administrator to define actions based on alarms. SNMP Traps are generated when RMON Alarms are triggered. The action taken in the Network Management Station depends on the specific network management application*

5.3.2 BRIDGE GROUPS SUPPORTED

The switch supports the following four groups of Bridge MIB (RFC 1493):

- *The dot1dBase Group – a mandatory group that contains the objects applicable to all types of bridges.*
- *The dot1dStp Group – contains objects that denote the bridge's state with respect to the Spanning Tree Protocol. If a node does not implement the Spanning Tree Protocol, this group will not be implemented. This group is applicable to any transparent only, source route, or SRT bridge that implements the Spanning Tree Protocol.*
- *The dot1dTp Group – contains objects that describe the entity's transparent bridging status. This group is applicable to transparent operation only and SRT bridges.*
- *The dot1dStatic Group – contains objects that describe the entity's destination-address filtering status. This group is applicable to any type of bridge which performs destination-address filtering.*


OPTICAL SYSTEMS DESIGN

6 WEB-BASED BROWSER MANAGEMENT

The switch provides a web-based browser interface for configuring and managing the switch. This interface allows you to access the switch using a preferred web browser.

This chapter describes how to configure the switch using its web-based browser interface.

6.1 LOGGING ON TO THE SWITCH



SWITCH IP ADDRESS

In your web browser, specify the IP address of the switch. Default IP address is 192.168.1.10.

LOGIN

Enter the factory default login ID: root.

PASSWORD

Enter the factory default password (no password).


Or enter a user-defined password if you followed the instructions later and changed the factory default password.

Then click on the "Login" button to log on to the switch.

OPTICAL SYSTEMS DESIGN

6.2 UNDERSTANDING THE BROWSER INTERFACE

The web browser interface provides groups of point-and-click buttons at the left field of the screen for configuring and managing the switch.



SYSTEM

System Information, System Name/Password, IP Address, Save Configuration, Firmware Upgrade, Reboot, Logout

PORt

Configuration, Port Status, Rate Control, RMON Statistics, Per Port VLAN Activities

SWITCHING

Bridging, Static MAC Entry, Port Mirroring

TRUNKING

Port Trunking

STP / RING

Global Configuration, RSTP Port Setting, MSTP Properties, MSTP Instance Setting, MSTP Port Setting, Ring Setting

VLAN

VLAN Mode Setting, 802.1Q VLAN Setting, 802.1Q Port Setting, Port Based VLAN

QOS

Global Configuration, 802.1p Priority, DSCP

SNMP

SNMP General Setting, SNMP v1/v2c, SNMP v3

802.1X


Radius Configuration, Port Authentication

OTHER PROTOCOLS

GVRP, IGMP Snooping, NTP

OPTICAL SYSTEMS DESIGN


6.3 SYSTEM



SYSTEM INFORMATION

The System name, Firmware version, MAC address, Default gateway, VLAN ID, IP Address, and IP Subnet Mask of Switch.


OPTICAL SYSTEMS DESIGN



SYSTEM NAME/PASSWORD

1. System Name: Click in “System Name” text box. Type a system name if it is blank, or replace the current system name with a new one.
2. Updating setting: Click “Updating setting” button to update your settings.
3. Password: Click in “Password” text box. Type a password.
4. Retype Password: Click in “Retype Password” text box. Type the same password in “Password” text box again to verify it.
5. Updating setting: Click “Updating setting” button to update your settings


OPTICAL SYSTEMS DESIGN



IP ADDRESS

1. IP Address: Click in “IP Address” text box and type a new address to change the IP Address.
2. IP Subnet Mask: Click in “IP Subnet Mask” text box and type a new address to change the IP Subnet Mask.
3. Submit: Click “Submit” button when you finished these selections.
4. You need to enter the new IP address on the browser and reconnect to the switch after IP or subnet mask are changed.
5. Default Gateway: Click “Default Gateway” drop-down menu to choose “Disable” or “Enable” from the “Default Gateway” drop-down list to disable or enable Default Gateway Setting for the switch.
6. Click the text box and type a new address to change the Default Gateway. (Need to choose “Enable” from the “Default Gateway” drop-down menu.)
7. Submit: Click “Submit” button when you finished Default Gateway.
8. DNS Server: Click “DNS Server” drop-down menu to choose “Disable” or “Enable” from the “DNS Server” drop-down list to disable or enable DNS Server Setting for the switch. Click the text box and type a new address to change the DNS Server.
9. Submit: Click “Submit” button when you finished DNS Server.


OPTICAL SYSTEMS DESIGN



SAVE CONFIGURATION

1. Load config from TFTP server:
2. Click in “TFTP Server” text box and type the TFTP server IP address from where the file will be obtained.
3. Click in “FILE” text box and type the name of the file that will be obtained.
4. Click “Load” button to load the file from the TFTP server.
5. Backup config to TFTP server:
6. Click in “TFTP Server” text box and type the TFTP server IP address to where the file will be backed up.
7. Click in “FILE” text box and type the name of the file that will be backed up.
8. Click “Backup” button to backup the file to the TFTP server.
9. Save Configuration: Click “Save Configuration” button to save your configuration settings.
10. Restore Default: Click “Restore Default” button to restore the default settings of the switch.
11. Auto save: Click “Auto save” drop-down menu to choose “Disable” or “Enable” from the “Auto save” drop-down list to disable or enable Auto save for the switch.
12. Auto save interval (5~65536 sec): Click in “Auto save interval” text box and type a decimal number between 5 and 65536.
13. Submit: Click “Submit” button when you finished Auto save configuration.


OPTICAL SYSTEMS DESIGN



FIRMWARE UPGRADE


1. **Filename:** Click in “Filename” text box and type the name of the file that you intend to upgrade it to the switch.
2. **TFTP server IP:** Click in “TFTP server IP” text box and type the TFTP server IP address from where the file will be obtained.
3. **Upgrade:** Click “upgrade” button to upgrade firmware to the switch. Please follow the message on the screen during the firmware upgrade process. Do not turn off the power or perform other functions during this period of time. Reboot the switch after completing the upgrade process.

OPTICAL SYSTEMS DESIGN




Please follow the message on the screen during the firmware upgrade process. Do not turn off the power or perform other functions during this period of time.

OPTICAL SYSTEMS DESIGN




OPTICAL SYSTEMS DESIGN

Firmware has been upgraded successfully to the switch. Reboot the switch after completing the upgrade process.




OPTICAL SYSTEMS DESIGN



ALARM SETTING

1. Name: Click "Name" drop-down menu to choose "fe1~fe8", "ge1~ge2", or "Power1~Power3" from the "Name" drop-down list.
2. Trigger Enabled: Click "Trigger Enabled" drop-down menu to choose "YES" or "NO" from the "Trigger Enabled" drop-down list to enable or disable Trigger.
3. Update Setting: Click "Update Setting" button to update settings to the switch.


OPTICAL SYSTEMS DESIGN



REBOOT

Reboot: Click "Reboot" button to restart the switch.

OPTICAL SYSTEMS DESIGN




LOGOUT

Logout: Click "Logout" button to logout of the switch.

OPTICAL SYSTEMS DESIGN

6.4 PORT



CONFIGURATION

1. Admin Setting: Click “Admin Setting” drop-down menu to choose “Link down” or “Link up” from the “Admin Setting” drop-down list to disable or enable Admin Setting for the port.
2. Speed: Click “Speed” drop-down menu to change the line speed and duplex settings from the “Speed” drop-down list for the port.
3. Flow control: Click “Flow control” drop-down menu to choose “Disable” or “Enable” from the “Flow control” drop-down list to disable or enable Flow control for the port.
4. Submit: Click “Submit” button when you finished configurations.

OPTICAL SYSTEMS DESIGN


The screenshot shows a Microsoft Internet Explorer window titled "Welcome to Switch Management - Microsoft Internet Explorer". The address bar indicates the URL is <http://192.168.1.10/cgi-bin/switch.cgi>. The left sidebar contains a navigation tree for a "Management Switch" with categories like System, Port, Switching, Trunking, STP / Ring, VLAN, QoS, SNMP, 802.1x, and Other Protocols. Under the Port category, "Port Status" is selected. The main content area features a graphic of ten network ports (labeled 1 through 10) with various connection icons. Below the graphic is a table with columns: Port, Link Status, Speed, Duplex, and Flow control. The table data is as follows:

Port	Link Status	Speed	Duplex	Flow control
1	running	100M	Full	Enable
2	down	100M	Full	Enable
3	down	100M	Full	Enable
4	down	100M	Full	Enable
5	down	100M	Full	Enable
6	down	100M	Full	Enable
7	down	100M	Full	Enable
8	down	100M	Full	Enable
9	down	1000M	Full	Enable
10	down	1000M	Full	Enable

PORT STATUS

View the Link Status, Speed, Duplex, and Flow control status for all ports

OPTICAL SYSTEMS DESIGN



RATE CONTROL

1. Ingress: Click in “Ingress” text box and type a new Rate to change the Ingress Rate Control for the port.
The rate value is a multiple of 62.5kbps. Please round off decimal fraction of rate value and only key the integer of rate value in “Ingress” text box.
Rate Values: 62kbps, 125kbps, 187kbps, 250kbps, 312kbps, 375kbps, 437kbps, 500kbps, 562kbps, 625kbps, 687kbps, 750kbps, 812kbps, 875kbps, 937kbps, 1000kbps, ..., 1000000kbps.
2. Egress: Click in “Egress” text box and type a new Rate to change the Egress Rate Control for the port.
The rate value is a multiple of 62.5kbps. Please round off decimal fraction of rate value and only key the integer of rate value in “Egress” text box.
Rate Values: 64kbps, 128kbps, 192kbps, 1792kbps, 2Mbps, 3Mbps, 4Mbps, ..., 100Mbps, 104Mbps, 112Mbps, 120Mbps, ..., 1000Mbps. <NOTE> M = 1024K
3. Update setting: Click “Update setting” button when you finished these Rate Control settings.

OPTICAL SYSTEMS DESIGN

Welcome to Switch Management - Microsoft Internet Explorer

File Edit View Favorites Tools Help

Back Forward Stop Home Search Favorites Links Go

Address http://192.168.1.10/cgi-bin/switch.cgi

Management Switch

System Port Configuration Port Status Rate Control RMON Statistics Per Port Vlan Activities

Switching Trunking STP / Ring VLAN QoS SNMP 802.1x Other Protocols

Port1 Port2 Port3 Port4 Port5

Port6 Port7 Port8 Port9 Port10

Port 1 Statistics

Drop Events	0
Broadcast Packets Received	79
Multicast Packets Received	8
Undersize Packets Received	0
Oversize Packets Received	0
fragments_pkts	0
64-byte Packets Received	1500
65 to 127-byte Packets Received	529
128 to 255-byte Packets Received	22
256 to 511-byte Packets Received	476
512 to 1023-byte Packets Received	2
1.0 to 1.5-kbyte Packets Received	0
Jabber Packets	0
Bytes Received	327920
Packets Received	2529
Collisions	0
CRC/Alignment Errors Received	0
TX No Errors	2752
RX No Errors	2529

Done Internet

RMON STATISTICS

Click Port 1 ~ Port 10 to view corresponding RMON Statistics

OPTICAL SYSTEMS DESIGN

Management Switch

- System
- Port
- Configuration
- Port Status
- Rate Control
- RMON Statistics
- Per Port VLAN Activities**
- Switching
- Trunking
- STP / Ring
- VLAN
- QoS
- SNMP
- 802.1x
- Other Protocols

Port1	Port2	Port3	Port4	Port5
Port6	Port7	Port8	Port9	Port10

P1 status


Total VLAN Count	1
Total MAC Address Count	1
VLAN Membership	MAC Address
VLAN1	00e0.b310.aaa9

PER PORT VLAN ACTIVITIES

Click Port 1 ~ Port 10 to view corresponding VLAN activities.

OPTICAL SYSTEMS DESIGN

6.5 SWITCHING




BRIDGING

1. Aging Time (seconds): Click the text box and type a decimal number as Bridging Aging Time in seconds.
2. Update setting: Click “update setting” button when you finished Aging Time settings.
3. Threshold level (0.1-100): Click in “Level” text box and type a decimal number for the port. Need to choose “Broadcast” and/or “DFL-Multicast” from “Storm-control enabled type” for the port. DLF (Destination Lookup Failure).
4. Storm-control enabled type: Choose “Broadcast” and/or “DFL-Multicast” from “Storm-control enabled type” for the port.
5. Update Setting: Click “Update Setting” button when you finished

Threshold level and Storm-control enabled type settings.

OPTICAL SYSTEMS DESIGN



STATIC MAC ENTRY


Static-MAC-Entry Forward:

1. Add MAC address: Click in “Add MAC address” text box and type a locked forwarding MAC address for the port.
2. VLAN ID: Click “VLAN ID” drop-down menu and choose a VLAN ID from the “VLAN ID” drop-down list.
3. Delete MAC address: Click “Delete MAC address” drop-down menu and choose a locked forwarding MAC address from the “Delete MAC address” drop-down list to be deleted from the port.
4. Submit: Click “Submit” button when you finished Static-MAC-Entry Forward settings.

Static-MAC-Entry Discard:

1. Add MAC address: Click in “Add MAC address” text box and type a MAC address to be discarded for the VLAN.
2. VLAN ID: Click “VLAN ID” drop-down menu and choose a VLAN ID from the “VLAN ID” drop-down list.
3. Delete MAC address: Click “Delete MAC address” drop-down menu and choose a MAC address from the “Delete MAC address” drop-down list to be discarded from the VLAN.
4. Submit: Click “Submit” button when you finished Static-MAC-Entry Discard settings.

OPTICAL SYSTEMS DESIGN




PORT MIRRORING

1. Mirror From: Choose Mirror From port from Port 1 ~ Port 10.
2. Mirror To: Click “Mirror To” drop-down menu to Choose Mirror To port (Port 1 ~ Port 10) from “Mirror To” drop-down list.
3. Mirror Mode: Click “Mirror Mode” drop-down menu to Choose “Tx/Rx”, “Tx”, or “Rx” from “Mirror Mode” drop-down list.
4. Submit: Click “Submit” button when you finished Port Mirroring settings.

OPTICAL SYSTEMS DESIGN

6.6 TRUNKING



PORT TRUNKING

Static Channel Group:


1. Trunk 1: Click Port 1 ~ Port 8 to assign ports to Trunk 1. (Maximum 4 ports in Trunk 1.)
2. Submit: Click “Submit” button when you finished Static Channel Group settings.

GE Trunking:

1. Trunk 3: Click “Static” or “Disable” for Trink 3.
2. Submit: Click “Submit” button when you finished GE Trunking settings.

OPTICAL SYSTEMS DESIGN

6.7 STP / RING



GLOBAL CONFIGURATION

1. Spanning Tree Protocol: Click “Spanning Tree Protocol” drop-down menu to Choose “Enable” or “Disable” from “Spanning Tree Protocol” drop-down list to enable or disable Spanning Tree Protocol.
2. Bridge Priority (0..61440): Click “Bridge Priority” text box and type a decimal number between 0 and 61440.
3. Hello Time (sec) (1..9): Click “Hello Time” text box and type a decimal number between 1 and 9.
4. Max Age (sec) (6..28): Click in “Max Age” text box and type a decimal number between 6 and 28.
5. Forward Delay (sec) (4..30): Click in “Forward Delay” text box and type a decimal number between 4 and 30.
6. STP Version: Click “STP Version” drop-down menu to choose “MSTP”, “RSTP” or “STP compatible” from “STP Version” drop-down list.
7. Update setting: Click “Update setting” button when you finished Global Configuration.

OPTICAL SYSTEMS DESIGN

The screenshot shows the 'Welcome to Switch Management - Microsoft Internet Explorer' window. The address bar shows 'http://192.168.1.10/cgi-bin/switch.cgi'. The left sidebar menu includes 'Management Switch' (System, Port, Switching, Trunking, STP / Ring, VLAN, QoS, SNMP, 802.1x, Other Protocols), 'Global Configuration', 'RSTP Port Setting', 'MSTP Properties', 'MSTP Instance Setting', 'MSTP Port Setting', and 'Ring Setting'. The main content area displays a network diagram with ten ports and a table titled 'RSTP Port Configuration'.

Port	Port Status	Priority	Path Cost	Point to Point Link	Edge Port
1	Designated(Forwarding)	128	200000	point-to-point	Disabled
2	Disabled(Discardng)	128	200000	shared	Disabled
3	Disabled(Discardng)	128	200000	shared	Disabled
4	Disabled(Discardng)	128	200000	shared	Disabled
5	Disabled(Discardng)	128	200000	shared	Disabled
6	Disabled(Discardng)	128	200000	shared	Disabled
7	Disabled(Discardng)	128	200000	shared	Disabled
8	Disabled(Discardng)	128	200000	shared	Disabled
9	Disabled(Discardng)	128	20000	shared	Disabled
10	Disabled(Discardng)	128	20000	shared	Disabled

RSTP Port Configuration

Port	Priority(Granularity 16)	Admin. Path Cost	Point to Point Link	Edge Port
1	128	200000	Enable	Disable

Update Setting

RSTP PORT SETTING

1. STP Version: Click “STP Version” drop-down menu to choose “RSTP” from “STP Version” drop-down list.
2. Port: Click “Port” drop-down menu to choose Port 1 ~ Port 10 from “Port” drop-down list.
3. Priority(Granularity 16): Click in “Priority” text box and enter a value between 0 and 240 to set the priority for the port. A higher priority will designate the port to forward packets first. A lower number denotes a higher priority. This entry must be divisible by 16. The default priority setting is 128.
4. Admin. Path Cost: Click in “Admin. Path Cost” text box and enter a value between 0 and 2000000 to set the Admin. Path Cost for the port. 0 (auto) - Setting 0 for the Admin. Path Cost will automatically set the speed for forwarding packets to the port for optimal efficiency. Default port cost: 100Mbps port = 200000. Gigabit port = 20000.
5. Point to Point Link: Click “Point to Point Link” drop-down menu to Choose “Enable” or “Disable” from “Point to Point Link” drop-down list to enable or disable Point to Point Link for the port.
6. Edge Port: Click “Edge Port” drop-down menu to Choose “Enable”, “Disable”, or “Auto” from “Edge Port” drop-down list to set Enable, Disable, or Auto Edge Port for the port.
7. Update setting: Click “Update setting” button when you finished RSTP Port Setting.

OPTICAL SYSTEMS DESIGN

Welcome to Switch Management - Microsoft Internet Explorer

File Edit View Favorites Tools Help

Address http://192.168.1.10/cgi-bin/switch.cgi Go Links

Management Switch

- + System
- + Port
- + Switching
- + Trunking
- STP / Ring
 - [Global Configuration](#)
 - [RSTP Port Setting](#)
 - [MSTP Properties](#)
 - [MSTP Instance Setting](#)
 - [MSTP Port Setting](#)
 - [Ring Setting](#)
- + VLAN
- + QoS
- + SNMP
- + 802.1x
- + Other Protocols

Status

Bridge ID	800000e0b32204b1
Designated Root	800000e0b32204b1
Reg Root ID	800000e0b32204b1
Root Port	0
Root Path Cost	0
Current Max Age (sec)	20
Current Hello Time (sec)	2
Current Forward Delay (sec)	15
Hold Time (sec)	
Topology Change Count	
Time Since Last Topology Change	


Setting

Spanning Tree Protocol	Enable
Bridge Priority (0..61440)	32768
Hello Time (1..10 sec)	2
Max Age (6..40 sec)	20
Forward Delay (4..30 sec)	15
STP Version	MSTP

Update setting

Done Internet


OPTICAL SYSTEMS DESIGN




MSTP PROPERTIES

1. STP Version: Click “STP Version” drop-down menu to choose “MSTP” from “STP Version” drop-down list.
2. Region Name: Click in “Region Name” text box to create an MST region and specify a name to it. MST bridges of a region form different spanning trees for different VLANs. By default, each MST bridge starts with the region name as its bridge address. This means each MST bridge is a region by itself, unless specifically added to one.
3. Revision Level: Click in “Revision Level” text box to specify the number for configuration information. The default value of revision number is 0.
4. Max Hops: Click in “Max Hops” text box to specify the maximum allowed hops for BPDU in an MST region. This parameter is used by all the instances of the MST. Specifying the max hops for a BPDU prevents the messages from looping indefinitely in the network. When a bridge receives a MST BPDU that has exceeded the allowed max-hops, it discards the BPDU.
5. Update setting: Click “Update setting” button when you finished MSTP Properties setting.

OPTICAL SYSTEMS DESIGN



OPTICAL SYSTEMS DESIGN



MSTP INSTANCE SETTING

VLAN Instance Configuration

1. VLAN Instance Configuration: Click “VLAN Instance Configuration” button. The “VLAN Instance Configuration” window appears.
2. VLAN ID: Click “VLAN ID” drop-down menu to choose VLAN from “VLAN ID” drop-down list to simultaneously add multiple VLANs for the corresponding instance of a bridge.
3. Instance ID (1..15): Click in “Instance ID” text box to specify the instance ID.
4. Update setting: Click “Update setting” button when you finished VLAN Instance Configuration.

Included VLANs

1. Instance ID: Click “Instance ID” drop-down menu to choose instance ID from “Instance ID” drop-down list.
2. Included VLAN: Click “Included VLAN” drop-down menu to choose VLAN from “Included VLAN” drop-down list.

Instance Setting

1. Bridge Priority (0..61440): Click in “Bridge Priority” text box to set the bridge priority for an MST instance to the value specified. The lower the priority of the bridge, the better the chances are the bridge becoming a root bridge or a designated bridge for the LAN.

Update setting: Click “Update setting” button when you finished VLAN Instance Configuration.

OPTICAL SYSTEMS DESIGN

■ Welcome to Switch Management - Microsoft Internet Explorer

File Edit View Favorites Tools Help

Back · Forward · Stop · Home · Search · Favorites · Links · Go · Links ·

Address http://192.168.1.10/cgi-bin/switch.cgi

Management Switch

- System
- Port
- Switching
- Trunking
- STP / Ring
 - Global Configuration
 - MSTP Port Setting
 - MSTP Properties
 - MSTP Instance Setting
 - MSTP Port Setting
 - Ring Setting
- VLAN
- QoS
- SNMP
- 802.1x
- Other Protocols

Port Instance Configuration


Instance ID	Port	Port State	Role	Priority	Path Cost	Designated Bridge ID	Designated Port ID	Designated Root ID	Designated Path Cost
1									
2									
3									
4									
5									
6									
7									
8									
9									
10									

MSTP Port Configuration

Port	Priority(Granularity 16)	Admin. Path Cost
1	<input type="text"/>	<input type="text"/>
		<input type="button" value="Update Setting"/>

Done Internet

OPTICAL SYSTEMS DESIGN



MSTP PORT SETTING

Port Instance Configuration

1. Instance ID: Click “Instance ID” drop-down menu to choose instance ID from “Instance ID” drop-down list.
2. Click Port 1 ~ Port 10 to assign ports to the corresponding instance ID.
3. Update setting: Click “Update setting” button when you finished Port Instance Configuration.


Instance ID

1. Instance ID: Click “Instance ID” drop-down menu to choose instance ID from “Instance ID” drop-down list.

MSTP Port Configuration

1. Port: Click “Port” drop-down menu to choose port from “Port” drop-down list.
2. Priority(Granularity 16): Click in “Priority” text box to set the port priority for a bridge group. The Multiple Spanning Tree Protocol uses port priority as a tiebreaker to determine which port should forward frames for a particular instance on a LAN, or which port should be the root port for an instance. A lower value implies a better priority. In the case of the same priority, the interface index will serve as the tiebreaker, with the lower-numbered interface being preferred over others. The permitted range is 0-240. The priority values can only be set in increments of 16.
3. Admin. Path Cost: Click in “Admin. Path Cost” text box to set the cost of a path associated with an interface.
4. Update setting: Click “Update setting” button when you finished MSTP Port Setting.

OPTICAL SYSTEMS DESIGN



RING SETTING

Ring state

1. Click “Ring state” drop-down menu from “Ring state” drop-down list to choose “Enable” or “Disable” to enable or disable Ring state.
2. Update setting: Click “Update setting” button when you finished Ring state setting.

Set ring port

1. Ring port 1: Click “Ring port 1” drop-down menu to choose Ring port 1 from “Ring port 1” drop-down list.
2. Ring port 2: Click “Ring port 2” drop-down menu to choose Ring port 2 from “Ring port 2” drop-down list.
3. Update setting: Click “Update setting” button when you finished Set ring port.

OPTICAL SYSTEMS DESIGN


6.8 VLAN




VLAN MODE SETTING

1. VLAN Mode Setting: Click “VLAN Mode Setting” drop-down menu to Choose “Tag-based VLAN” or “Port-based VLAN” from “VLAN Mode Setting” drop-down list.
2. Update Setting: Click “Update Setting” button when you finished VLAN Mode Setting

OPTICAL SYSTEMS DESIGN



OPTICAL SYSTEMS DESIGN



802.1Q VLAN SETTING


Add VLAN:

1. VLAN setting: Click “VLAN setting”. The “VLAN Setting” window appears.
2. Add VLAN: Click “Add VLAN” button to create a new VLAN from “VLAN Setting” window.
3. VLAN ID(2-4094): Click in the “VLAN ID” textbox and specify a new VLAN ID number from 2 ~ 4094.
4. VLAN Name: Click in the “VLAN Name” textbox and type a name for this newly created VLAN.

Add port to or delete port from VLAN:

1. VLAN Member: Choose the port to be added to or deleted from the VLAN.
2. Tag or Untag: Click “Tag or Untag” drop-down menu to Choose “Tag” or “Untag” from “Tag or Untag” drop-down list for a “Hybrid” port.
3. Submit: Click “Submit” button when you finished VLAN setting.

OPTICAL SYSTEMS DESIGN




Delete VLAN:

1. VLAN setting: Click “VLAN setting”. The “VLAN Setting” window appears.
2. Delete VLAN: Click “Delete VLAN” button.
3. Select a VLAN ID: Click “Select a VLAN ID” drop-down menu from “Select a VLAN ID” drop-down list to choose the VLAN to be deleted.

Submit: Click “Submit” button when you finished VLAN setting



OPTICAL SYSTEMS DESIGN



802.1Q PORT SETTING

1. VLAN Port Setting: Click “VLAN Port Setting”. The “VLAN Port Setting” window appears.
2. Mode: Click “Mode” drop-down menu to Choose “Access”, “Trunk”, or “Hybrid” from “Mode” drop-down list for the port. The port will be Tag port if you choose “Trunk” Mode for the port. And the port will be Tag or Untag port if you choose “Hybrid” Mode for the port.
3. PVID: Click in the “PVID” textbox and specify a new PVID number for the port.
4. Update Setting: Click “Update Setting” button when you finished VLAN Port Setting.

OPTICAL SYSTEMS DESIGN




PORT BASED VLAN

1. VLAN: Choose the port to be added to or deleted from the VLAN.
2. Select all: Click “select all” button to choose Port 1 ~ Port 10 all to be added to the VLAN.
3. Delete all: Click “delete all” button to choose Port 1 ~ Port 10 all to be deleted from the VLAN.
4. Submit: Click “Submit” button when you finished Port Based VLAN setting.

OPTICAL SYSTEMS DESIGN


6.9 QOS



GLOBAL CONFIGURATION

1. QoS: Click “QoS” drop-down menu from “QoS” drop-down list to choose “Enable” or “Disable” to enable or disable QoS.
2. Trust: Enable or disable the switch port to trust the CoS (Class of Service) labels of all traffic received on that port. Enable or disable a routed port to trust the DSCP (Differentiated Service Code Point) labels of all traffic received on that port.
3. Policy: Choose “Strict Priority(Queue3) + WRR(Queue0-2)” or “WRR(Queue0-3)”. A strict priority queue is always emptied first. The queues that are used in the WRR (Weighted Round Robin) are emptied in a round-robin fashion, and you can configure the weight for each queue.
4. Weighted Round Robin: Click in the “Weight(1~55)” textbox and specify a new number from 1 ~ 55 for Queue 0 ~ 3.
5. Submit: Click “Submit” button when you finished Global Configuration

OPTICAL SYSTEMS DESIGN



802.1P PRIORITY

1. Priority: Click “Priority” drop-down menu from “Priority” drop-down list to choose 0 ~ 3 for VLAN Priority 0 ~ 7.
2. Submit: Click “Submit” button when you finished 802.1p priority

OPTICAL SYSTEMS DESIGN

The screenshot shows a Microsoft Internet Explorer window titled "Welcome to Switch Management - Microsoft Internet Explorer". The address bar displays "http://192.168.1.10/cgi-bin/switch.cgi". The left sidebar contains a navigation tree under "Management Switch" with categories like System, Port, Switching, Trunking, STP / Ring, VLAN, QoS, SNMP, 802.1x, and Other Protocols. The "QoS" section is expanded, showing "Global Configuration", "802.1p Priority", and "DSCP". The main content area is a table titled "DSCP Priority" with 14 rows. Each row has two columns: "DSCP Priority" (values 0-15) and "Priority" (drop-down menu). A "Submit" button is at the bottom right of the table.


DSCP Priority	Priority						
0	0	1	0	2	0	3	0
4	0	5	0	6	0	7	0
8	0	9	0	10	0	11	0
12	0	13	0	14	0	15	0
16	0	17	0	18	0	19	0
20	0	21	0	22	0	23	0
24	0	25	0	26	0	27	0
28	0	29	0	30	0	31	0
32	0	33	0	34	0	35	0
36	0	37	0	38	0	39	0
40	0	41	0	42	0	43	0
44	0	45	0	46	0	47	0
48	0	49	0	50	0	51	0
52	0	53	0	54	0	55	0
56	0	57	0	58	0	59	0
60	0	61	0	62	0	63	0

DSCP

1. Priority: Click "Priority" drop-down menu from "Priority" drop-down list to choose 0 ~ 3 for DSCP Priority 0 ~ 63.
2. Submit: Click "Submit" button when you finished DSCP

OPTICAL SYSTEMS DESIGN

6.10 SNMP




SNMP GENERAL SETTING

1. SNMP Status: Click “SNMP Status” drop-down menu from “SNMP Status” drop-down list to choose “Enable” or “Disable” to enable or disable SNMP.
2. Description: Click in the “Description” textbox and specify a new description for SNMP.
3. Location: Click in the “Location” textbox and specify a new location for SNMP.
4. Contact: Click in the “Contact” textbox and specify a new contact for SNMP.
5. Trap Community Name: For each “Trap Community Name”, Click in the “Trap Community Name” textbox and specify a trap community name.

OPTICAL SYSTEMS DESIGN

6. Trap Host IP Address: For each “Trap Host IP Address”, Click in the “Trap Host IP Address” textbox and specify a trap host IP address.
7. Cold Start Trap: Click “Cold Start Trap” drop-down menu from “Cold Start Trap” drop-down list to choose “Enable” or “Disable” to enable or disable cold start trap.
8. Warm Start Trap: Click “Warm Start Trap” drop-down menu from “Warm Start Trap” drop-down list to choose “Enable” or “Disable” to enable or disable warm start trap.
9. Link Down Trap: Click “Link Down Trap” drop-down menu from “Link Down Trap” drop-down list to choose “Enable” or “Disable” to enable or disable link down trap.
10. Link Up Trap: Click “Link Up Trap” drop-down menu from “Link Up Trap” drop-down list to choose “Enable” or “Disable” to enable or disable link up trap.
11. Authentication Failure Trap: Click “Authentication Failure Trap” drop-down menu from “Authentication Failure Trap” drop-down list to choose “Enable” or “Disable” to enable or disable authentication failure trap.
12. Topology Change Trap: Click “Topology Change Trap” drop-down menu from “Topology Change Trap” drop-down list to choose “Enable” or “Disable” to enable or disable topology change trap.
13. Update Setting: Click “Update Setting” button when you finished SNMP General Setting.

OPTICAL SYSTEMS DESIGN



SNMP V1/V2C

1. Get Community Name: Click in the “Get Community Name” textbox and specify a get community name.
2. Set Community Name: Click in the “Set Community Name” textbox and specify a set community name.
3. Update Setting: Click “Update Setting” button when you finished SNMP V1/V2c Setting.

OPTICAL SYSTEMS DESIGN

Welcome to Switch Management - Microsoft Internet Explorer

File Edit View Favorites Tools Help

Address http://192.168.1.10/cgi-bin/switch.cgi

Management Switch

- System
- Port
- Switching
- Trunking
- STP / Ring
- VLAN
- QoS
- SNMP
 - SNMP General Setting
 - SNMP v1/v2c
 - SNMP v3
- 802.1x
- Other Protocols

SNMPv3 Setting Add User Delete User

User Name	Access Mode	Security Level	Authentication Type	Privacy Type
-----------	-------------	----------------	---------------------	--------------

Done

Welcome to Switch Management - Microsoft Internet Explorer

File Edit View Favorites Tools Help

Address http://192.168.1.10/cgi-bin/switch.cgi

Management Switch

- System
- Port
- Switching
- Trunking
- STP / Ring
- VLAN
- QoS
- SNMP
 - SNMP General Setting
 - SNMP v1/v2c
 - SNMP v3
- 802.1x
- Other Protocols

SNMP V3 Setting

SNMP Version	SNMPv3 No-Auth
User Name	
Access Mode	Read Only
Auth. Password	
Privacy PassPhrase	

Submit

Done


OPTICAL SYSTEMS DESIGN

SNMP V3

Add User:

1. Add User: Click “Add User” button. The “SNMP V3 Setting” window appears.
2. SNMP Version: Click “SNMP Version” drop-down menu from “SNMP Version” drop-down list to choose “SNMPv3 No-Auth”, “SNMPv3 Auth-MD5”, “SNMPv3 Auth-SHA”, “SNMPv3 Priv Auth-MD5”, or “SNMPv3 Priv Auth-SHA”.
 - SNMPv3 No-Auth: Add a user using SNMP v3 without authentication.
 - SNMPv3 Auth-MD5: Add a user using SNMP v3 with authentication. Click in the “Auth. Password” textbox and specify an authentication password. SNMPv3 Auth-SHA: Add a user using SNMP v3 with authentication. Click in the “Auth. Password” textbox and specify an authentication password.
 - SNMPv3 Priv Auth-MD5: Add a user using SNMP v3 with authentication and privacy. Click in the “Auth. Password” textbox and specify an authentication password. Click in the “Privacy PassPhrase” textbox and specify a privacy pass phrase.
 - SNMPv3 Priv Auth-SHA: Add a user using SNMP v3 with authentication and privacy. Click in the “Auth. Password” textbox and specify an authentication password. Click in the “Privacy PassPhrase” textbox and specify a privacy pass phrase.
3. User Name: Click in the “User Name” textbox and specify a user name for user using SNMP v3.
4. Access Mode: Click “Access Mode” drop-down menu from “Access Mode” drop-down list to choose “Read Only” or “Read/Write”.
 - Read Only: Add a user using SNMP v3 with read-only access mode.
 - Read/Write: Add an user using SNMP v3 with read-write access mode
5. Submit: Click “Submit” button when you finished SNMP V3 Setting.

OPTICAL SYSTEMS DESIGN




Delete User:

1. Delete User: Click “Delete User” button. The “Select User Name” window appears.
2. Select User Name: Click “Select User Name” drop-down menu from “Select User Name” drop-down list to choose the user to be deleted from using SNMP v3.
3. Submit: Click “Sumit” button when you finished user deletion.

OPTICAL SYSTEMS DESIGN


6.11 802.1X



RADIUS CONFIGURATION

1. Radius Status: Click “Radius Status” drop-down menu from “Radius Status” drop-down list to choose “Enable” or “Disable” to globally enable or disable authentication.
2. Update Setting: Click “Update Setting” button when you finished Radius Status Setting.


OPTICAL SYSTEMS DESIGN



Add Radius:

1. Add Radius: Click “Add Radius” button. The “Radius Server Setting” window appears.
2. Radius Server IP: Click in the “Radius Server IP” textbox and specify the IP address of the remote radius server host.
3. Radius Server Port: Click in the “Radius Server Port” textbox and specify the UDP destination port for authentication requests. The host is not used for authentication if set to 0.
4. Secret Key: Click in the “Secret Key” textbox and specify the authentication and encryption key for all radius communications between the Switch and radius server. This key must match the encryption used on the radius daemon. All leading spaces are ignored, but spaces within and at the end of the key are used. If spaces are used in the key, do not enclose the key in quotation marks unless the quotation marks themselves are part of the key.
5. Timeout <1-1000>: Click in the “Timeout” textbox and specify the time interval (in seconds) that the Switch waits for the radius server to reply before retransmitting. Enter a value in the range 1 to 1000.
6. Retransmit <1-100>: Click in the “Retransmit” textbox and specify the number of times a radius request is resent to a server if that server is not responding or responding slowly. Enter a value in the range 1 to 100.
7. Submit: Click “Submit” button when you finished Radius Server Setting.


OPTICAL SYSTEMS DESIGN



Delete Radius:

1. Delete Radius: Click “Delete Radius” button. The “Select Radius Server IP” window appears.
2. Select Radius Server IP: Click “Select Radius Server IP” drop-down menu from “Select Radius Server IP” drop-down list to choose the IP address of the remote radius server host to be deleted.
3. Submit: Click “Submit” button when you finished radius server deletion

OPTICAL SYSTEMS DESIGN



PORT-BASED AUTHENTICATION

1. Interface: Click “Interface” drop-down menu from “Interface” drop-down list to choose the port to be set port-based authentication.
2. Authentication State: Click “Authentication State” drop-down menu from “Authentication State” drop-down list to choose “Enable” or “Disable” to enable or disable authentication state.
3. Port Control: Click “Port Control” drop-down menu from “Port Control” drop-down list to choose “Auto”, “Force Authorized”, or “Force Unauthorized” to force a port state. “Auto” specifies to enable authentication on port. “Force Authorized” specifies to force a port to always be in an authorized state. “Force Unauthorized” specifies to force a port to always be in an unauthorized state.
4. Periodic Reauthentication: Click “Periodic Reauthentication” drop-down menu from “Periodic Reauthentication” drop-down list to choose “Enable” or “Disable” to enable or disable periodic reauthentication.
5. Reauthentication Period <1-4294967295>: Click in the “Reauthentication Period” textbox and specify the seconds between reauthorization attempts. The default time is 3600 seconds.
6. Update Setting: Click “Update Setting” button when you finished port-based authentication setting.

OPTICAL SYSTEMS DESIGN

6.12 OTHER PROTOCOLS

The screenshot shows the 'Welcome to Switch Management - Microsoft Internet Explorer' interface. The address bar displays `http://192.168.1.10/cgi-bin/switch.cgi`. The left sidebar menu includes: Management Switch, System, Port, Switching, Trunking, STP / Ring, VLAN, QoS, SNMP, 802.1x, Other Protocols (with GVRP, IGMP Snooping, and NTP listed), and a 'Done' button at the bottom.

GVRP Global Setting

GVRP	Disable <input type="button" value="▼"/>
Dynamic VLAN creation	Disable <input type="button" value="▼"/>

Update Setting

Per port setting (include LAG)

Port	GVRP	GVRP applicant	GVRP registration
1	Disable <input type="button" value="▼"/>	Normal <input type="button" value="▼"/>	Disable <input type="button" value="▼"/>
2	Disable <input type="button" value="▼"/>	Normal <input type="button" value="▼"/>	Disable <input type="button" value="▼"/>
3	Disable <input type="button" value="▼"/>	Normal <input type="button" value="▼"/>	Disable <input type="button" value="▼"/>
4	Disable <input type="button" value="▼"/>	Normal <input type="button" value="▼"/>	Disable <input type="button" value="▼"/>
5	Disable <input type="button" value="▼"/>	Normal <input type="button" value="▼"/>	Disable <input type="button" value="▼"/>
6	Disable <input type="button" value="▼"/>	Normal <input type="button" value="▼"/>	Disable <input type="button" value="▼"/>
7	Disable <input type="button" value="▼"/>	Normal <input type="button" value="▼"/>	Disable <input type="button" value="▼"/>
8	Disable <input type="button" value="▼"/>	Normal <input type="button" value="▼"/>	Disable <input type="button" value="▼"/>
9	Disable <input type="button" value="▼"/>	Normal <input type="button" value="▼"/>	Disable <input type="button" value="▼"/>
10	Disable <input type="button" value="▼"/>	Normal <input type="button" value="▼"/>	Disable <input type="button" value="▼"/>

Update setting

OPTICAL SYSTEMS DESIGN

GVRP


GVRP Global Setting:

1. GVRP: Click “GVRP” drop-down menu from “GVRP” drop-down list to choose “Enable” or “Disable” to enable or disable GVRP (GARP VLAN Registration Protocol).
2. Dynamic VLAN creation: Click “Dynamic VLAN creation” drop-down menu from “Dynamic VLAN creation” drop-down list to choose “Enable” or “Disable” to enable or disable Dynamic VLAN creation. GARP (Generic Attribute Registration Protocol) provides IEEE802.1Q compliant VLAN pruning and dynamic VLAN creation on IEEE802.1Q trunk ports.
3. Update Setting: Click “Update Setting” button when you finished GVRP Global Setting.

Per Port Setting (include LAG):

1. GVRP: Click “GVRP” drop-down menu from “GVRP” drop-down list to choose “Enable” or “Disable” to enable or disable GVRP for the port.
2. GVRP applicant: Click “GVRP applicant” drop-down menu from “GVRP applicant” drop-down list to choose “Active” or “Normal” to the port. Ports in the GVRP active applicant state send GVRP VLAN declarations when they are in the STP (Spanning Tree Protocol) blocking state, which prevents the STP bridge protocol data units (BPDUs) from being pruned from the other port. Ports in the GVRP normal applicant state do not declare GVRP VLANs when in the STP blocking state.
3. GVRP registration: Click “GVRP registration” drop-down menu from “GVRP registration” drop-down list to choose “Enable” or “Disable” to enable or disable GVRP registration to the port. Configuring an IEEE802.1Q trunk port in registration mode allows dynamic creation (if dynamic VLAN creation is enabled), registration, and deregistration of VLANs on the trunk port.
4. Update Setting: Click “Update Setting” button when you finished Per port setting.

OPTICAL SYSTEMS DESIGN



IGMP SNOOPING

1. **IGMP mode:** Click “IGMP mode” drop-down menu from “IGMP mode” drop-down list to choose “Disable”, “Passive”, or “querier” for the switch. Disable: Disable IGMP on the switch. Passive: The switch with only multicast-data-forwarding capability. Querier: The switch acts as the querier for the network. There is only one querier on a network at any time.
2. **Update Setting:** Click “Update Setting” button when you finished IGMP mode settings. **VLAN ID:** Click “VLAN ID” drop-down menu from “VLAN ID” drop-down list to choose the VLAN under configuration for the switch.
3. **IGMP version:** Click “IGMP version” drop-down menu from “IGMP version” drop-down list to choose “1”, “2”, or “3” for the switch.
4. **Fast-leave:** Click “fast-leave” drop-down menu from “fast-leave” drop-down list to choose “Enable” or “Disable” for the switch. Enable this function will allow members of a multicast group to leave the group immediately when an IGMP Leave Report Packet is received by the Switch.

OPTICAL SYSTEMS DESIGN


IGMP querier:

1. Query-interval: Click in the “query-interval” textbox and specify a new number from 1 ~ 18000. The query-interval field is used to set the time (in seconds) between transmitting IGMP queries. Entries between 1 and 18000 seconds are allowed. Default = 125.
2. Max-response-time: Click in the “max-response-time” textbox and specify a new number from 1 ~ 124. This determines the maximum amount of time in seconds allowed before sending an IGMP response report. The max-response-time field allows an entry between 1 and 124 (seconds). Default = 10.

IGMP passive snooping:

1. Report suppression: Click “report suppression” drop-down menu from “report suppression” drop-down list to choose “Enable” or “Disable” for the switch. Use this command to enable report suppression for IGMP version 1 and version 2. Report suppression does not apply to IGMP version 3, and is turned off by default for IGMP version 1 and IGMP version 2 reports. The switch uses IGMP report suppression to forward only one IGMP report per multicast router query to multicast devices. When IGMP router suppression is enabled, the switch sends the first IGMP report from all hosts for a group to all the multicast routers. The switch does not send the remaining IGMP reports for the group to the multicast routers. This feature prevents duplicate reports from being sent to the multicast devices.
2. Update Setting: Click “Update Setting” button when you finished IGMP Snooping.

OPTICAL SYSTEMS DESIGN



NTP

NTP Setting:

1. NTP Status: Click “NTP Status” drop-down menu from “NTP Status” drop-down list to choose “Enable” or “Disable” to enable or disable NTP for the Switch.
2. NTP Server (IP Address or Domain name): Click in the “NTP Server” textbox and specify the IP address or Domain name of NTP server.
3. Sync Time: Click “Sync Time” button to synchronize time with NTP server.
4. Time Zone: Click “Tmie Zone” drop-down menu from “Tmie Zone” drop-down list to set time zone.
5. Polling Interval (1-10080 min): Click in the “Polling Interval” textbox and specify the polling interval.
6. Update Setting: Click “Update Setting” button when you finished NTP Setting.

OPTICAL SYSTEMS DESIGN

Daylight Saving Setting:

1. Daylight Saving Mode: Click "Daylight Saving Mode" drop-down menu from "Daylight Saving Mode" drop-down list to choose "Disable", "Weekday", or "Date" to choose disable, weekday, or date daylight saving for the Switch.
2. Time Set Offset (1-1440 min): Click in the "Time Set Offset" textbox and specify the offset time of daylight saving. For example enter 60 for one hour offset.
3. Daylight Saving Tmiezzone: Click in the "Daylight Saving Tmiezzone" textbox and specify the daylight saving timezone. This can be any given name in 14-character alpha-numericals. Enter the Daylight-Saving time zone using the following example:
 - EDT - East Daylight Saving Time Zone.
 - CDT - Central Daylight-Saving Time Zone.
 - MDT - Mountain Daylight-Saving Time Zone.
 - PDT - Pacific Daylight-Saving Time Zone.
 - ADT - Alaska Daylight-Saving Time Zone.
4. Weekday: Click in the textboxes and specify the daylight saving period.
 - Month: Click "Month" drop-down menu from "Month" drop-down list to choose from January to December.
 - Week: <1-5> Specifies weekdays from Monday to Friday.
 - Day: Click "Day" drop-down menu from "Day" drop-down list to choose from Sunday to Saturday.
 - Hour: <0-23> Specifies from 0 to 23.
 - Minute: <0-59> Specifies from 0 to 59.
5. Date: Click in the textboxes and specify the daylight saving period.
 - Month: Click "Month" drop-down menu from "Month" drop-down list to choose from January to December.
 - Day: <1-31> Specifies from 1 to 31.
 - Hour: <0-23> Specifies from 0 to 23.
 - Minute: <0-59> Specifies from 0 to 59.
6. Update Setting: Click "Update Setting" button when you finished Daylight Saving Setting.

<Note> The “Week”, “Hour”, “Minute”, and “Day” fields would not accept the alphabetic characters (Like Jan, Feb, Sun, Mon). They only accept the two digit numbers (0 through 9).

OPTICAL SYSTEMS DESIGN

7 COMMAND LINE CONSOLE MANAGEMENT

The switch provides a command line console interface for configuration purposes. The switch can be configured either locally through its RS-232 port or remotely via a Telnet session. For the later, you must specify an IP address for the switch first.

This chapter describes how to configure the switch using its console by Command Line.

7.1 ADMINISTRATION CONSOLE

Connect the DB9 straight cable to the RS-232 serial port of the device to the RS-232 serial port of the terminal or computer running the terminal emulation application.

Direct access to the administration console is achieved by directly connecting a terminal or a PC equipped with a terminal-emulation program (such as HyperTerminal) to the switch console port.

When using the management method, configure the terminal-emulation program to use the following parameters (you can change these settings after login):

[Default parameters]

115,200bps


8 data bits

No parity

1 stop bit

OPTICAL SYSTEMS DESIGN


7.1.1 EXEC MODE (VIEW MODE)



LOGON TO EXEC MODE (VIEW MODE)

At the **switch_a login:** prompt just type in “root” and press <Enter> to logon to Exec Mode (or View Mode).

```
switch_a login: root
```



OPTICAL SYSTEMS DESIGN


BASIC COMMANDS

Exec Mode (or View Mode) is the base mode from where users can perform basic commands like: clear, debug, disable, enable, exit, help, logout, no, quit, show, terminal

The CLI contains a text-based help facility. Access this help by typing in the full or partial command string then typing a question mark “?”. The CLI displays the command keywords or parameters along with a short description.

At the **switch_a>** prompt just press <?> to list the above basic commands.

```
switch_a?
```



The screenshot shows a HyperTerminal window titled "115200 - HyperTerminal". The window has a blue header bar with standard menu options: File, Edit, View, Call, Transfer, Help. Below the menu is a toolbar with icons for copy, paste, cut, etc. The main terminal area displays the following text:

```
switch_a login: root
Switch version 1.30.r142-sdkr32. 12/05/12 13:59:04
switch_a>?
Exec commands:
  clear      Clear the Forwarding database
  debug      Debugging functions (see also 'undebbug')
  disable    Turn off privileged mode command
  enable     Turn on privileged mode command
  exit       End current mode and down to previous mode
  help       Description of the interactive help system
  logout    Exit from the EXEC
  no        Negate a command or set its defaults
  quit      Exit current mode and down to previous mode
  restore   To restore the default setting
  show      Show running system information
  terminal  Set terminal line parameters

switch_a>
```

At the bottom of the terminal window, there is a status bar with the following information: Connected 0:03:49 | VT100J | 115200 8-N-1 | SCROLL | CAPS | NUM | Capture | Print echo |

OPTICAL SYSTEMS DESIGN

At the **switch_a>** prompt just type in the full or partial command string then typing a question mark "?" to display the command keywords or parameters along with a short description.

```
switch_a>show ?
```

The screenshot shows a HyperTerminal window titled "115200 - HyperTerminal". The menu bar includes File, Edit, View, Call, Transfer, Help, and a toolbar with icons for copy, paste, cut, etc. The main window displays a command help list for "switch_a>show ?". The list includes:

```
switch_a>show ?
all-if          all-if
brand           Brand ID
bridge          bridge protocol
cli              Show CLI tree of current mode
debugging       Debugging functions (see also 'undebug')
etherchannel   LACP channel commands
flowcontrol    IEEE 802.3x Flow Control
gmrp            Generic Attribute Registration Protocol
gvrp            GARP Vlan Registration Protocol
hardware        Hardware configuration
history         Display the session command history
interface       The layer2 interfaces
ip               Internet Protocol (IP)
lacp             LACP commands
lacp-counter   LACP commands
list             Show command lists
mac              Mac address
mirror          Port Mirroring
mls              Switch(L2).
port             port commands
privilege       Show current privilege level
--More-- _
```

At the bottom of the terminal window, there is a status bar with the text: Connected 0:05:08 | VT100J | 115200 8-N-1 | SCROLL | CAPS | NUM | Capture | Print echo |

The screenshot shows a second HyperTerminal window titled "115200 - HyperTerminal". The menu bar, toolbar, and status bar are identical to the first window. The main window displays a command help list for "switch_a>show". The list includes:

```
gvrp            GARP Vlan Registration Protocol
hardware        Hardware configuration
history         Display the session command history
interface       The layer2 interfaces
ip               Internet Protocol (IP)
lacp             LACP commands
lacp-counter   LACP commands
list             Show command lists
mac              Mac address
mirror          Port Mirroring
mls              Switch(L2).
port             port commands
privilege       Show current privilege level
ratecontrol     The layer2 interface
spanning-tree   Display spanning-tree information
static-channel-group Static channel commands
storm-control   The layer2 interface
user-priority   Display the default user priority associated with the
                layer2 interface
users           Display information about terminal lines
version         Display version
vlan            Display VLAN information

switch_a>show
```

At the bottom of the terminal window, there is a status bar with the text: Connected 0:05:59 | VT100J | 115200 8-N-1 | SCROLL | CAPS | NUM | Capture | Print echo |

OPTICAL SYSTEMS DESIGN


LOGIN TIMED OUT

The login session to Exec Mode (or View Mode) has timed out due to an extended period of inactivity (60 seconds) to indicate authentication attempt timed out. And the **switch_a login:** prompt will show on the screen.

LOGON BACK TO EXEC MODE (VIEW MODE)

At the **switch_a login:** prompt just type in “root” and press <Enter> to logon back to Exec Mode (or View Mode).

```
switch_a login: root
```



A screenshot of the HyperTerminal application window titled "115200 - HyperTerminal". The window shows a terminal session with the following text output:

```
switch_a login: root
Switch version 1.30.r142-sdkr32. 12/05/12 13:59:04
switch_a>
Vty connection is timed out...

switch_a login:
Login timed out after 60 seconds.

switch_a login:
```


The window includes standard HyperTerminal controls at the bottom: "Connected 0:18:59", "VT100J", "115200 8-N-1", "SCROLL", "CAPS", "NUM", "Capture", and "Print echo".

OPTICAL SYSTEMS DESIGN

EXIT FROM EXEC MODE (VIEW MODE)

At the **switch_a>** prompt just type in “exit” and press <Enter> to exit from Exec Mode (or View Mode).

```
switch_a>exit
```



The screenshot shows a window titled "115200 - HyperTerminal". The menu bar includes File, Edit, View, Call, Transfer, and Help. Below the menu is a toolbar with icons for copy, paste, cut, and others. The main terminal window displays the following text:

```
switch_a login: root
Switch version 1.30.r142-sdkr32. 12/05/12 13:59:04
switch_a>exit
switch_a login:
```

At the bottom of the window, there is a status bar with the following information:

```
Connected 0:19:58 | VT100J | 115200 8-N-1 | SCROLL | CAPS | NUM | Capture | Print echo |
```

OPTICAL SYSTEMS DESIGN

7.1.2 PRIVILEGED EXEC MODE (ENABLE MODE)

LOGON TO PRIVILEGED EXEC MODE (ENABLE MODE)

At the **switch_a>** prompt just type in “enable” and press <Enter> to logon to Privileged Exec Mode (or Enable Mode). And the **switch_a#** prompt will show on the screen.

```
switch_a>enable
```

The screenshot shows a window titled "115200 - HyperTerminal". The menu bar includes File, Edit, View, Call, Transfer, and Help. Below the menu is a toolbar with icons for copy, paste, cut, and others. The main terminal window displays the following text:

```
switch_a login: root
Switch version 1.30.r142-sdkr32. 12/05/12 13:59:04
switch_a>enable
switch_a#
```

At the bottom of the terminal window, there is a status bar with the following information: Connected 0:01:20, VT100J, 115200 8-N-1, SCROLL, CAPS, NUM, Capture, Print echo.

OPTICAL SYSTEMS DESIGN

COMMANDS

Privileged Exec Mode (or Enable Mode) allows users to run commands as following.

At the **switch_a#** prompt just press <?> to list the commands.

```
switch_a#?
```

The image contains two side-by-side screenshots of the HyperTerminal application window. Both windows have a blue title bar with the text "115200 - HyperTerminal". The menu bar includes "File", "Edit", "View", "Call", "Transfer", and "Help". Below the menu bar is a toolbar with icons for file operations like Open, Save, Print, and Capture. The main window displays a list of "Exec commands" with their descriptions. At the bottom of each window, there is a status bar showing "Connected 0:02:20" or "Connected 0:03:01", "VT100J", "115200 8-N-1", and other terminal settings like SCROLL, CAPS, NUM, Capture, and Print echo.

```
switch_a>enable
switch_a#?
Exec commands:
  clear      Clear the Forwarding database
  configure   Enter configuration mode
  copy        Copy from one file to another
  debug       Debugging functions (see also 'undebbug')
  disable     Turn off privileged mode command
  enable      Turn on privileged mode command
  exit        End current mode and down to previous mode
  help        Description of the interactive help system
  install    Install to flash
  logout     Exit from the EXEC
  no         Negate a command or set its defaults
  ping       Send echo messages
  quit       Exit current mode and down to previous mode
  reload     Reboot the system
  restore   To restore the default setting
  show      Show running system information
  telnet    Open a telnet connection
  terminal  Set terminal line parameters
  traceroute Trace route to destination
  undebbug  Disable debugging functions (see also 'debug')
--More-- _
```



```
Connected 0:02:20 | VT100J | 115200 8-N-1 | SCROLL | CAPS | NUM | Capture | Print echo |
```



```
switch_a#?
```



```
Connected 0:03:01 | VT100J | 115200 8-N-1 | SCROLL | CAPS | NUM | Capture | Print echo |
```

OPTICAL SYSTEMS DESIGN

At the **switch_a#** prompt just type in the full or partial command string then typing a question mark "?" to display the command keywords or parameters along with a short description.

```
switch_a#show ?
```

The screenshot shows a HyperTerminal window titled "115200 - HyperTerminal". The menu bar includes File, Edit, View, Call, Transfer, and Help. The toolbar contains icons for file operations like Open, Save, Print, and Copy/Paste. The main window displays a command help list for "switch_a#show ?". The list includes various commands with their descriptions:

switch_a#show ?	
all-if	all-if
brand	Brand ID
bridge	bridge protocol
cli	Show CLI tree of current mode
debugging	Debugging functions (see also 'undebug')
etherchannel	LACP channel commands
flowcontrol	IEEE 802.3x Flow Control
gmrp	Generic Attribute Registration Protocol
gvrp	GARP Vlan Registration Protocol
hardware	Hardware configuration
history	Display the session command history
interface	The layer2 interfaces
ip	Internet Protocol (IP)
lacp	LACP commands
lacp-counter	LACP commands
list	Show command lists
mac	Mac address
memory	Memory information
mirror	Port Mirroring
mls	Switch(L2).
nsm	NSM
--More--	_

Connected 0:03:49 | VT100J | 115200 8-N-1 | SCROLL | CAPS | NUM | Capture | Print echo |

The screenshot shows a second HyperTerminal window titled "115200 - HyperTerminal". The menu bar, toolbar, and status bar are identical to the first window. The main window displays a command help list for "switch_a#show _". The list includes various commands with their descriptions:

ip	Internet Protocol (IP)
lacp	LACP commands
lacp-counter	LACP commands
list	Show command lists
mac	Mac address
memory	Memory information
mirror	Port Mirroring
mls	Switch(L2).
nsm	NSM
port	port commands
privilege	Show current privilege level
ratecontrol	The layer2 interface
running-config	Current Operating configuration
spanning-tree	Display spanning-tree information
startup-config	Contents of startup configuration
static-channel-group	Static channel commands
storm-control	The layer2 interface
user-priority	Display the default user priority associated with the layer2 interface
users	Display information about terminal lines
version	Display version
vlan	Display VLAN information

Connected 0:04:44 | VT100J | 115200 8-N-1 | SCROLL | CAPS | NUM | Capture | Print echo |

OPTICAL SYSTEMS DESIGN

LOGIN TIMED OUT

The login session to Privileged Exec Mode (or Enable Mode) has timed out due to an extended period of inactivity (60 seconds) to indicate authentication attempt timed out. And the **switch_a login:** prompt will show on the screen.

LOGON BACK TO EXEC MODE (VIEW MODE)

At the **switch_a login:** prompt just type in “root” and press <Enter> to logon back to Exec Mode (or View Mode).

```
switch_a login: root
```

The screenshot shows a HyperTerminal window titled "115200 - HyperTerminal". The window has a blue header bar with standard menu options: File, Edit, View, Call, Transfer, Help. Below the menu is a toolbar with icons for copy, paste, cut, etc. The main terminal window displays the following text:

```
switch_a login: root
Switch version 1.30.r142-sdkr32. 12/05/12 13:59:04
switch_a>enable
switch_a#
Vty connection is timed out...

switch_a login:
Login timed out after 60 seconds.

switch_a login: root
Switch version 1.30.r142-sdkr32. 12/05/12 13:59:04
switch_a>
```

At the bottom of the terminal window, there is a status bar with the following information: Connected 0:20:00 | VT100J | 115200 8-N-1 | SCROLL | CAPS | NUM | Capture | Print echo |

OPTICAL SYSTEMS DESIGN

EXIT FROM PRIVILEGED EXEC MODE (OR ENABLE MODE)

At the **switch_a#** prompt just type in “exit” and press <Enter> to exit from Privileged Exec Mode (or Enable Mode).

```
switch_a#exit
```

The screenshot shows a window titled "115200 - HyperTerminal". The menu bar includes File, Edit, View, Call, Transfer, and Help. Below the menu is a toolbar with icons for copy, paste, cut, and others. The main terminal window displays the following text:

```
switch_a login: root
Switch version 1.30.r142-sdkr32, 12/05/12 13:59:04
switch_a>enable
switch_a#exit
switch_a login: _
```

At the bottom of the window, there is a status bar with the following information:

Connected 0:20:55 | VT100J | 115200 8-N-1 | SCROLL | CAPS | NUM | Capture | Print echo |

OPTICAL SYSTEMS DESIGN

7.1.3 CONFIGURE MODE (CONFIGURE TERMINAL MODE)

LOGON TO CONFIGURE MODE (CONFIGURE TERMINAL MODE)

At the **switch_a#** prompt just type in “configure terminal” and press <Enter> to logon to Configure Mode (or Configure Terminal Mode). And the **switch_a(config)#** prompt will show on the screen.

```
switch_a#configure terminal
```

The screenshot shows a window titled "115200 - HyperTerminal". The menu bar includes File, Edit, View, Call, Transfer, Help, and a toolbar with icons for copy, paste, cut, etc. The main window displays a terminal session:

```
switch_a login: root
Switch version 1.30.r142-sdkr32. 12/05/12 13:59:04
switch_a>enable
switch_a#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
switch_a(config)#

```

At the bottom of the terminal window, there is a status bar with the following information: Connected 0:22:54 | VT100J | 115200 8-N-1 | SCROLL | CAPS | NUM | Capture | Print echo |


OPTICAL SYSTEMS DESIGN

COMMANDS

Configure Mode (or Configure Terminal Mode) serves as a gateway into the modes as following.

At the **switch_a(config)#** prompt just press <?> to list the commands.

```
switch_a(config)#?
```



115200 - HyperTerminal


File Edit View Call Transfer Help

Enter configuration commands, one per line. End with CNTL/Z.
switch_a(config)#?

Configure commands:

banner	Define a login banner
bridge	Bridge group commands.
debug	Debugging functions (see also 'undebug')
do	To run exec commands in config mode
enable	Modify enable password parameters
exit	End current mode and down to previous mode
help	Description of the interactive help system
hostname	Set system's network name
interface	Select an interface to configure
ip	Internet Protocol (IP)
lacp	LACP commands
line	Configure a terminal line
log	Logging control
mls	Switch(L2).
no	Negate a command or set its defaults
priority-queue	Enable the egress expedite queue
service	Set up miscellaneous service
set	Set GMRP Registration to Fixed Registration
show	Show running system information
snmp-server	Configure snmp setting
--More--	_

Connected 0:23:38 | VT100J | 115200 8-N-1 | SCROLL | CAPS | NUM | Capture | Print echo |



115200 - HyperTerminal

File Edit View Call Transfer Help

bridge Bridge group commands.
debug Debugging functions (see also 'undebug')
do To run exec commands in config mode
enable Modify enable password parameters
exit End current mode and down to previous mode
help Description of the interactive help system
hostname Set system's network name
interface Select an interface to configure
ip Internet Protocol (IP)
lacp LACP commands
line Configure a terminal line
log Logging control
mls Switch(L2).
no Negate a command or set its defaults
priority-queue Enable the egress expedite queue
service Set up miscellaneous service
set Set GMRP Registration to Fixed Registration
show Show running system information
snmp-server Configure snmp setting
username Establish User Name Authentication
vlan Configure VLAN parameters
wrr-queue WRR queue

switch_a(config)#_

Connected 0:24:15 | VT100J | 115200 8-N-1 | SCROLL | CAPS | NUM | Capture | Print echo |

OPTICAL SYSTEMS DESIGN

At the **switch_a(config)#** prompt just type in the full or partial command string then typing a question mark “?” to display the command keywords or parameters along with a short description.

```
switch_a(config)#show ?
```

The screenshot shows a window titled "115200 - HyperTerminal". The menu bar includes File, Edit, View, Call, Transfer, Help, and a toolbar with icons for copy, paste, cut, etc. The main window displays a command-line interface. The user has entered "switch_a(config)#show ?" and the terminal is displaying a list of commands and their descriptions. The list includes:

help	Description of the interactive help system
hostname	Set system's network name
interface	Select an interface to configure
ip	Internet Protocol (IP)
lacp	LACP commands
line	Configure a terminal line
log	Logging control
mls	Switch(L2).
no	Negate a command or set its defaults
priority-queue	Enable the egress expedite queue
service	Set up miscellaneous service
set	Set GMRP Registration to Fixed Registration
show	Show running system information
snmp-server	Configure snmp setting
username	Establish User Name Authentication
vlan	Configure VLAN parameters
wrr-queue	WRR queue

Below this, the user has typed "switch_a(config)#show _" and the terminal is displaying command completion options:

cli	Show CLI tree of current mode
list	Show command lists
running-config	Current Operating configuration

```
switch_a(config)#show _
```

```
Connected 0:25:15 | VT100J | 115200 8-N-1 | SCROLL | CAPS | NUM | Capture | Print echo | .#
```

OPTICAL SYSTEMS DESIGN


LOGIN TIMED OUT

The login session to Configure Mode (or Configure Terminal Mode) has timed out due to an extended period of inactivity (60 seconds) to indicate authentication attempt timed out. And the **switch_a login:** prompt will show on the screen.

LOGON BACK TO EXEC MODE (VIEW MODE)

At the **switch_a login:** prompt just type in “root” and press <Enter> to logon back to Exec Mode (or View Mode).

```
switch_a login: root
```



The screenshot shows a window titled "115200 - HyperTerminal". The menu bar includes File, Edit, View, Call, Transfer, Help, and several icons. The main terminal window displays the following text:

```
switch_a login: root
Switch version 1.30.r142-sdkr32. 12/05/12 13:59:04
switch_a>enable
switch_a#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
switch_a(config)#
Vty connection is timed out...

switch_a login:
Login timed out after 60 seconds.

switch_a login: root
Switch version 1.30.r142-sdkr32. 12/05/12 13:59:04
switch_a>
```

At the bottom of the terminal window, there are scroll bars on the right and a status bar at the bottom with the text: "Connected 0:38:30 | VT100 | 115200 8-N-1 | SCROLL | CAPS | NUM | Capture | Print echo |".

OPTICAL SYSTEMS DESIGN

EXIT FROM CONFIGURE MODE (OR CONFIGURE TERMINAL MODE)

At the **switch_a(config)#** prompt just type in “exit” and press <Enter> to exit from Configure Mode (or Configure Terminal Mode).

```
switch_a(config)#exit
```

The screenshot shows a window titled "115200 - HyperTerminal". The menu bar includes File, Edit, View, Call, Transfer, and Help. Below the menu is a toolbar with icons for copy, paste, cut, etc. The main terminal window displays the following text:

```
switch_a login: root
Switch version 1.30.r142-sdkr32. 12/05/12 13:59:04
switch_a>enable
switch_a#configure terminal
Enter configuration commands, one per line. End with CNTL/Z.
switch_a(config)#exit
switch_a#_
```

At the bottom of the terminal window, there are status indicators: Connected 0:40:23, VT100J, 115200 8-N-1, SCROLL, CAPS, NUM, Capture, Print echo.

OPTICAL SYSTEMS DESIGN

7.2 SYSTEM

System Information, System Name/Password, IP Address, Save Configuration, Firmware Upgrade, Reboot, Logout

SYSTEM NAME/PASSWORD

System Name:

1. Command Mode: Configure mode

Logon to Configure Mode (Configure Terminal Mode).

The **switch_a(config)#** prompt will show on the screen.

```
switch_a(config)#
```

2. Usage:

Use **hostname** command to set or change the network server name.

Use the **no hostname** command to disable this function.

3. Command Syntax:

(no) **hostname** **HOSTNAME**

HOSTNAME specifies the network name of the system.

4. Example:

The following example sets the hostname to **switch**, and shows the change in the prompt:

```
switch_a(config)#hostname switch  
switch(config)#
```

Password:

1. Command Mode: Configure mode

Logon to Configure Mode (Configure Terminal Mode).

The **switch_a(config)#** prompt will show on the screen.

```
switch_a(config)#
```

2. Usage:

Use **enable password** command to modify or create a password to be used when entering the Enable mode.

3. Command Syntax:

enable password **PASSWORD**

PASSWORD specifies the new password of the system.

4. Example:

The following example sets the new password **mypasswd** to switch:

```
switch_a(config)#enable password mypasswd  
switch_a(config)#
```

OPTICAL SYSTEMS DESIGN

IP ADDRESS

IP Address/IP Subnet Mask:

1. Command Mode: Interface mode

Logon to Configure Mode (Configure Terminal Mode).

Then logon to Interface mode.

vlan1.1 means vlan 1.

The **switch_a(config-if)#** prompt will show on the screen.

```
switch_a(config)#interface vlan1.1  
switch_a(config-if)#{}
```

2. Usage:

Use **ip address** command to set the IP address of an interface.

Use the **no ip address** command to remove the IP address from an interface.

3. Command Syntax:

ip address IP-ADDRESS

no ip address IP-ADDRESS

no ip address

IP-ADDRESS A.B.C.D/M specifies the IP address and prefix length of an interface.

M specifies IP subnet mask, 8: 255.0.0.0, 16:255.255.0.0, 24: 255.255.255.0.

4. Example:

The following example sets the new IP address **192.168.1.10** and new IP subnet mask **255.255.255.0** to switch:

```
switch_a(config)#interface vlan1.1  
switch_a(config-if)#ip address 192.168.1.10/24  
switch_a(config-if)#{}
```

Default Gateway:

1. Command Mode: Configure mode

Logon to Configure Mode (Configure Terminal Mode).

The **switch_a(config)#** prompt will show on the screen.

```
switch_a(config)#{}
```

2. Usage:

Use **ip default-gateway** command to set the IP address of the default gateway.

Use the **no ip default-gateway** command to remove the IP address of the default gateway.

3. Command Syntax:

ip default-gateway IP-ADDRESS

no ip default-gateway

IP-ADDRESS A.B.C.D specifies the IP address of the default gateway.

4. Example:

The following example sets the default gateway **192.168.1.254** to switch:

```
switch_a(config)#ip default-gateway 192.168.1.254  
switch_a(config)#{}
```

OPTICAL SYSTEMS DESIGN

DNS Server:

1. Command Mode: Configure mode

Logon to Configure Mode (Configure Terminal Mode).

The **switch_a(config)#** prompt will show on the screen.

Switch_a(config)#

2. Usage:

Use **ip dns** command to set the IP address of the DNS server.

Use the **no ip dns** command to remove the IP address of the DNS server.

3. Command Syntax:

no ip dns

IP-ADDRESS A.B.C.D specifies the IP address of the DNS server.

4. Example:

The following example sets the DNS server **192.168.1.100** to switch:

switch_a(config)#ip dns 192.168.1.100
switch_a(config)#

SAVE CONFIGURATION

Load config from TFTP server:

1. Command Mode: Privileged Exec mode

Logon to Privileged Exec Mode (Enable Mode).

The **switch_a#** prompt will show on the screen.

switch_a#

2. Usage:

Use **install image** command to load configuration file from tftp server to switch.

3. Command Syntax:

install image IP-ADDRESS WORD

IP-ADDRESS specifies the IP address of tftp server.

WORD specifies the file name to be loaded to switch.

4. Example:

The following example specifies upgrading firmware (file name: **flash.tgz**) from tftp server (IP address: **192.168.1.100**) to switch:

switch_a#install image 192.168.1.100 flash.tgz
switch_a#

OPTICAL SYSTEMS DESIGN

Load config to TFTP server:

1. Command Mode: Privileged Exec mode

Logon to Privileged Exec Mode (Enable Mode).

The **switch_a#** prompt will show on the screen.

```
switch_a#
```

2. Usage:

Use **write config-file** command to backup configuration file to tftp server.

3. Command Syntax:

```
write config-file IP-ADDRESS
```

IP-ADDRESS specifies the IP address of tftp server.

4. Example:

The following example backups configuration file to tftp server (IP address: **192.168.1.20**):

```
switch_a#write config-file 192.168.1.20  
switch_a#
```

Save Configuration:

1. Command Mode: Privileged Exec mode

Logon to Privileged Exec Mode (Enable Mode).

The **switch_a#** prompt will show on the screen.

```
switch_a#
```

2. Usage:

Use **copy running-config startup-config** command to write configurations to the file to be used at startup. This is the same as the **write memory** command.

3. Command Syntax:

```
copy running-config startup-config
```

4. Example:

The following example specifies writing configurations to the file to be used at startup to switch:

```
switch_a#copy running-config startup-config  
switch_a#
```

Restore Default:

1. Command Mode: Privileged Exec mode

Logon to Privileged Exec Mode (Enable Mode).

The **switch_a#** prompt will show on the screen.

```
switch_a#
```

2. Usage:

Use **restore default** command to restore default setting of the switch.

3. Command Syntax:

```
restore default
```

4. Example:

The following example restores default setting of the switch:

```
switch_a#restore default  
switch_a#
```

OPTICAL SYSTEMS DESIGN

Auto Save:

1. Command Mode: Configure mode

Logon to Configure Mode (Configure Terminal Mode).

The **switch_a(config)#** prompt will show on the screen.

```
switch_a(config)#
```

2. Usage:

Use this command to enable auto save configuration function. The configuration will be automatically saved at every configured interval while this command is enabled. Use the no form of this command to disable this feature.

3. Command Syntax:

```
service auto-config enable
```

```
no service auto-config enable
```

4. Example:

The following example enables or disables auto save configuration to switch:

```
switch_a(config)#service auto-config enable  
switch_a(config)#no service auto-config enable  
switch_a(config)#
```

Auto Save Interval (5~65536 sec):

1. Command Mode: Configure mode

Logon to Configure Mode (Configure Terminal Mode).

The **switch_a(config)#** prompt will show on the screen.

```
switch_a(config)#
```

2. Usage:

Use this command to set the interval when the configuration would be automatically saved. The range of interval value is from 5 to 65535. And the default value is 30 seconds.

3. Command Syntax:

```
service auto-config interval WORD
```

WORD specifies the interval value.

4. Example:

The following example sets the interval WORD **(10)** when the configuration would be automatically saved to switch:

```
switch_a(config)#service auto-config interval 10  
switch_a(config)#
```

OPTICAL SYSTEMS DESIGN

FIRMWARE UPGRADE

1. Command Mode: Privileged Exec mode

Logon to Privileged Exec Mode (Enable Mode).

The **switch_a#** prompt will show on the screen.

```
switch_a#
```

2. Usage:

Use **install image** command to upgrade firmware from tftp server to switch.

3. Command Syntax:

install image IP-ADDRESS WORD

IP-ADDRESS specifies the IP address of tftp server.

WORD specifies the file name to be upgraded to switch.

4. Example:

The following example specifies upgrading firmware (file name: **flash.tgz**) from tftp server (IP address: **192.168.1.100**) to switch:

```
switch_a#install image 192.168.1.100 flash.tgz  
switch_a#
```

Please follow the message on the screen during the firmware upgrade process. Do not turn off the power or perform other functions during this period of time.


The screenshot shows a window titled "115200 - HyperTerminal". The terminal session output is as follows:

```
Vty connection is timed out...
switch_a login: root
Switch version 1.43.1 01/22/12 15:40:59
switch_a>enable
switch_a#install image 192.168.1.100 flash.tgz
Download now, please wait...
tftp flash.tgz from ip 192.168.1.100 success!!
Install now. This may take several minutes, please wait...
Install success!
switch_a#
```

At the bottom of the terminal window, the status bar displays: "Connected 1:02:26 | VT100J | 115200 8-N-1 | SCROLL | CAPS | NUM | Capture | Print echo |".

At the "switch_a#" prompt just type in "reload" and press <Enter> to reboot the switch after completing the upgrade process.

OPTICAL SYSTEMS DESIGN



The screenshot shows a HyperTerminal window titled "115200 - HyperTerminal". The window displays a series of messages indicating a system reboot:

```
switch_a#reload
Reboot now, please wait...
The system is going down NOW !!
Sending SIGTERM to all processes.

% Connection is closed by administrator!
Sending SIGKILL to all processes.
Requesting system reboot.
Start bootloader ...
Uncompressing image ...
Starting image ...
switch_a login:
```

At the bottom of the terminal window, there is a status bar with the following information:

Connected 1:02:26 | VT100J | 115200 8-N-1 | SCROLL | CAPS | NUM | Capture | Print echo |

ALARM SETTING

Alarm-trigger if:

1. Command Mode: Configure mode

Logon to Configure Mode (Configure Terminal Mode).

The **switch_a(config)#** prompt will show on the screen.

switch_a(config)#

2. Usage:

Use this command to enable or disable alarm on interface.

3. Command Syntax:

(no) alarm-trigger if INTERFACE

INTERFACE specifies te interface.

4. Example:

The Following example enables alarm trigger on interface “**fe1**” to switch:

switch_a(config)#alarm-trigger if fe1
switch_a(config)#

OPTICAL SYSTEMS DESIGN

Alarm-trigger power:

1. Command Mode: Configure mode

Logon to Configure Mode (Configure Terminal Mode).

The **switch_a(config)#** prompt will show on the screen.

```
switch_a(config)#
```

2. Usage:

Use this command to enable or disable alarm trigger of power source.

3. Command Syntax:

(no) alarm-trigger power POWER

POWER specifies the power source.

4. Example:

The following example enables alarm trigger of power “1” to switch:

```
switch_a(config)#alarm-trigger power 1  
switch_a(config)#
```

REBOOT

1. Command Mode: Privileged Exec mode

Logon to Privileged Exec Mode (Enable Mode).

The **switch_a#** prompt will show on the screen.

```
switch_a#
```

2. Usage:

Use **reload** command to restart switch.

3. Command Syntax:

reload

4. Example:

The following example specifies restarting switch:

```
switch_a#reload  
switch_a login:
```

LOGOUT

1. Command Mode: Exec mode or Privileged Exec mode

Logon to Exec Mode (View Mode) or Privileged Exec Mode (Enable Mode).

The **switch_a>** or **switch_a#** prompt will show on the screen.

```
switch_a>
```

```
switch_a#
```

2. Usage:

Use **logout** command to exit from the Exec mode or Privileged Exec mode.

3. Command Syntax:

logout

4. Example:

The following example specifies to exit from the Exec mode or Privileged Exec mode.

```
switch_a>logout  
switch_a login:
```

OPTICAL SYSTEMS DESIGN

7.3 PORT

Configuration, Port Status, Rate Control, RMON Statistics, Per Port VLAN Activities

CONFIGURATION

Admin Setting:

1. Command Mode: Interface mode

Logon to Configure Mode (Configure Terminal Mode).

Then logon to Interface mode.

fe1 means port 1.

The **switch_a(config-if)#** prompt will show on the screen.

```
switch_a(config)#interface fe1  
switch_a(config-if)#
```

2. Usage:

Use the **shutdown** command to shut down the selected interface.

Use the **no shutdown** to disable this function.

3. Command Syntax:

(no) shutdown

4. Example:

The following example shows the use of the **shutdown** command to shut down the interface fe1 (port 1):

```
switch_a(config)#interface fe1  
switch_a(config-if)#shutdown  
switch_a(config-if)#
```

Duplex:

1. Command Mode: Interface mode

Logon to Configure Mode (Configure Terminal Mode).

Then logon to Interface mode.

fe1 means port 1.

The **switch_a(config-if)#** prompt will show on the screen.

```
switch_a(config)#interface fe1  
switch_a(config-if)#
```

2. Usage:

Use **duplex** command to specify the duplex mode to be used for each interface.

Use the **no duplex** to disable this function.

3. Command Syntax:

(no) duplex MODE

MODE specifies the duplex mode: auto, full, half.

4. Example:

The following example shows the use of **duplex MODE (full)** to the interface fe1 (port 1):

```
switch_a(config)#interface fe1  
switch_a(config-if)#duplex full  
switch_a(config-if)#
```

OPTICAL SYSTEMS DESIGN

Flow control:

1. Command Mode: Interface mode

Logon to Configure Mode (Configure Terminal Mode).

Then logon to Interface mode.

fe1 means port 1.

The **switch_a(config-if)#** prompt will show on the screen.

```
switch_a(config)#interface fe1  
switch_a(config-if)#
```

2. Usage:

Use **flowcontrol on** command to enable flow control, and configure the flow control mode for the port.

Use the **no flowcontrol** to disable this function.

3. Command Syntax:

flowcontrol on

no flowcontrol

4. Example:

The following example shows the use of **flowcontrol on** to the interface fe1 (port 1):

```
switch_a(config)#interface fe1  
switch_a(config-if)#flowcontrol on  
switch_a(config-if)#
```

PART STATUS

1. Command Mode: Exec mode or Privileged Exec mode

Logon to Exec Mode (View Mode) or Privileged Exec Mode (Enable Mode).

The **switch_a>** or **switch_a#** prompt will show on the screen.

```
switch_a>
```

```
switch_a#
```

2. Usage:

Use the **show interface** command to display interface configuration and status.

3. Command Syntax:

show interface IFNAME

IFNAME specifies the name of the interface for which status and configuration information is desired.

4. Example:

The following example shows the use of **show interface** to display interface configuration and status of the interface fe1 (port 1):

```
switch_a>show interface fe1
```

OPTICAL SYSTEMS DESIGN

RATE CONTROL

1. Command Mode: Interface mode

Logon to Configure Mode (Configure Terminal Mode).

Then logon to Interface mode.

fe1 means port 1.

The **switch_a(config-if)#** prompt will show on the screen.

```
switch_a(config)#interface fe1  
switch_a(config-if)#{}
```

2. Usage:

Use this command to specify the ingress/egress rate to be used for each interface. The bandwidth value is in bits.

Use the no parameter with this command to remove the ingress/egress rate to be used for each interface.

3. Command Syntax:

(no) rate-control ingress/egress VALUE

 VALUE

 <1-10000000000 bits> (usable units: k, m, g)

 <1-999>klm for 1 to 999 kilo bits or mega bits.

 1g for 1 giga bits.

4. Example:

The following example shows the use of rate-control ingress VALUE (**10 mega bits**) to the interface fe1 (port 1):

```
switch_a(config)#interface fe1  
switch_a(config-if)#rate-control ingress 10m  
switch_a(config-if)#{}
```

RMON STATISTICS

1. Command Mode: Exec mode or Privileged Exec mode

Logon to Exec Mode (View Mode) or Privileged Exec Mode (Enable Mode).

The **switch_a>** or **switch_a#** prompt will show on the screen.

```
switch_a>
```

```
switch_a#
```

2. Usage:

Use the **show interface statistics** command to display RMON statistics of interface.

3. Command Syntax:

show interface statistics IFNAME

IFNAME specifies the name of the interface for which RMON statistics is desired.

4. Example:

The following example shows the use of **show interface statistics** to display RMON statistics of the interface fe1 (port 1):

```
switch_a>show interface statistics fe1
```

OPTICAL SYSTEMS DESIGN

PER PORT VLAN ACTIVITIES

1. Command Mode: Exec mode or Privileged Exec mode

Logon to Exec Mode (View Mode) or Privileged Exec Mode (Enable Mode).

The **switch_a>** or **switch_a#** prompt will show on the screen.

```
switch_a>
```

```
switch_a#
```

2. Usage:

Use **show vlan** command to display information about a particular VLAN by specifying the VLAN ID.

3. Command Syntax:

```
show vlan <2-4094>  
<2-4094> VLAN ID.
```

4. Example:

The following is an output of **show vlan** command displaying information about VLAN 2:

```
switch_a>show vlan 2
```

OPTICAL SYSTEMS DESIGN

7.4 SWITCHING

Bridging, Static MAC Entry, Port Mirroring

BRIDGING

Aging Time (seconds):

1. Command Mode: Configure mode

Logon to Configure Mode (Configure Terminal Mode).

The **switch_a(config)#** prompt will show on the screen.

```
switch_a(config)#
```

2. Usage:

Use this command to specify an ageing-out time for a learned MAC address. The learned MAC address will persist till this specified time.

3. Command Syntax:

Bridge GROUP ageing-time AGEINGTIME

no bridge GROUP ageing-time

Group = <1-1> The ID of the bridge-group that this ageing time is for.

AGEINGTIME = <10-1000000> The number of seconds of persistence.

4. Example:

The following example sets the new AGEINGTIME (**1000**) to bridge GROUP (**1**):

```
switch_a(config)#bridge 1 ageing-time 1000  
switch_a(config)#
```

Threshold level (0-100):

1. Command Mode: Interface mode

Logon to Configure Mode (Configure Terminal Mode).

Then logon to Interface mode.

fe1 means port 1.

The **switch_a(config-if)#** prompt will show on the screen.

```
switch_a(config)#interface fe1  
switch_a(config-if)#
```

2. Usage:

Use **storm-control level** command to specify the rising threshold level for broadcasting, multicast, or destination lookup failure traffic. The storm control action occurs when traffic utilization reaches this level.

3. Command Syntax:

storm-control level LEVEL

LEVEL <0-100> specifies the percentage of the threshold; percentage of the maximum speed (pps) of the interface.

4. Example:

The following example shows setting **storm-control level LEVEL (30)** to the interface fe1 (port 1):

```
switch_a(config)#interface fe1  
switch_a(config-if)#storm-control level 30  
switch_a(config-if)#
```

OPTICAL SYSTEMS DESIGN

Broadcast:

1. Command Mode: Interface mode

Logon to Configure Mode (Configure Terminal Mode).

Then logon to Interface mode.

fe1 means port 1.

The **switch_a(config-if)#** prompt will show on the screen.

```
switch_a(config)#interface fe1  
switch_a(config-if)#
```

2. Usage:

Use **storm-control broadcast enable** command to enable broadcast traffic.

Use **no storm-control broadcast** command to disable broadcast traffic.

3. Command Syntax:

storm-control broadcast enable

no storm-control broadcast

4. Example:

The following example shows setting **storm-control broadcast enable** to the interface fe1 (port 1):

```
switch_a(config)#interface fe1  
switch_a(config-if)#storm-control broadcast enable  
switch_a(config-if)#
```

Multicast:

1. Command Mode: Interface mode

Logon to Configure Mode (Configure Terminal Mode).

Then logon to Interface mode.

fe1 means port 1.

The **switch_a(config-if)#** prompt will show on the screen.

```
switch_a(config)#interface fe1  
switch_a(config-if)#
```

2. Usage:

Use **storm-control multicast enable** command to enable multicast traffic.

Use **no storm-control multicast** command to disable multicast traffic.

3. Command Syntax:

storm-control multicast enable

no storm-control multicast

4. Example:

The following example shows setting **storm-control multicast enable** to the interface fe1 (port 1):

```
switch_a(config)#interface fe1  
switch_a(config-if)#storm-control multicast enable  
switch_a(config-if)#
```

OPTICAL SYSTEMS DESIGN

DLF:

1. Command Mode: Interface mode

Logon to Configure Mode (Configure Terminal Mode).

Then logon to Interface mode.

fe1 means port 1.

The **switch_a(config-if)#** prompt will show on the screen.

```
switch_a(config)#interface fe1  
switch_a(config-if)#
```

2. Usage:

Use **storm-control dlf enable** command to enable destination lookup failure traffic.

Use **no storm-control dlf** command to disable destination lookup failure traffic.

3. Command Syntax:

storm-control dlf enable

no storm-control dlf

dlf destination lookup failure

4. Example:

The following example shows setting **storm-control dlf enable** to the interface fe1 (port 1):

```
switch_a(config)#interface fe1  
switch_a(config-if)#storm-control dlf enable  
switch_a(config-if)#
```

STATIC MAC ENTRY

Static-MAC-Entry Forward:

1. Command Mode: Configure mode

Logon to Configure Mode (Configure Terminal Mode).

The **switch_a(config)#** prompt will show on the screen.

```
switch_a(config)#
```

2. Usage:

Use this command to statically configure a bridge entry to forward matching frames.

3. Command Syntax:

bridge GROUP address MAC forward IFNAME VLANID

no bridge GROUP address MAC forward IFNAME VLANID

GROUP <1-1> Bridge-group ID used for bridging.

MAC the Media Access Control (MAC) address in the HHHH.HHHH.HHHH format.

IFNAME the interface on which the frame comes in.

VLANID The VID of the VLAN that will be enabled or disabled on the bridge <2-4094>.

4. Example:

The following example configures a bridge GROUP (1) to forward matching frames (MAC address **2222.2222.2222**) to the interface fe1 (port 1) in vlan VLANID (2):

```
switch_a(config)#bridge 1 address 2222.2222.2222 forward fe1 vlan 2  
switch_a(config)#
```

OPTICAL SYSTEMS DESIGN

Static-MAC-Entry Discard:

1. Command Mode: Configure mode

Logon to Configure Mode (Configure Terminal Mode).

The **switch_a(config)#** prompt will show on the screen.

```
switch_a(config)#
```

2. Usage:

Use this command to statically configure a bridge entry to discard matching frames.

3. Command Syntax:

bridge GROUP address MAC discard IFNAME

no bridge GROUP address MAC discard INFAME

GROUP <1-1> Bridge-group ID used for bridging.

MAC the Media Access Control (MAC) address in the HHHH.HHHH.HHHH format.

IFNAME the interface on which the frames comes in.

4. Example:

The following example configures a bridge GROUP (1) to discard matching frames (MAC address **2222.2222.2222**) to the interface fe1 (port 1):

```
switch_a(config)#bridge 1 address 2222.2222.2222 discard fe1  
switch_a(config)#
```

PART MIRRORING

1. Command Mode: Interface mode

Logon to Configure Mode (Configure Terminal Mode).

Then logon to Interface mode.

fe1 means port 1.

The **switch_a(config-if)#** prompt will show on the screen.

```
switch_a(config)#interface fe1  
switch_a(config-if)#
```

2. Usage:

Use this command to define a mirror source port and its direction.

Use the no parameter with this command to disable port mirroring by the destination port on the specified source port.

3. Command Syntax:

mirror interface SOURCEPORT direction SNOOPDIRECTION

no mirror interface SOURCEPORT

SOURCEPORT Name of the Source interface to be used.

SNOOPDIRECTION [both|receive|transmit]

both Specifies mirroring of traffic in both directions.

receive Specifies mirroring of received traffic.

transmit Specifies mirroring of transmitted traffic.

4. Example:

The following example enables port mirroring by the destination port fe1 (port 1) on the specified source port fe2 (port 2):

```
switch_a(config)#interface fe1  
switch_a(config-if)#mirror interface fe2 direction both  
switch_a(config-if)#
```

OPTICAL SYSTEMS DESIGN

7.5 TRUNKING

PORT TRUNKING

1. Command Mode: Interface mode

Logon to Configure Mode (Configure Terminal Mode).

Then logon to Interface mode.

fe1 means port 1.

The **switch_a(config-if)#** prompt will show on the screen.

```
switch_a(config)#interface fe1  
switch_a(config-if)#{}
```

2. Usage:

Use **static-channel-group** command to create a static aggregator, or add a member port to an already-existing static aggregator.

Use the **no static-channel-group** command to detach the port from the static aggregator.

3. Command Syntax:

static-channel-group <1-3>

no static-channel-group

<1-3> Channel group number.

Maximum 4 ports in static-channel-group 1 and static-channel-group 2.

Maximum 2 ports in static-channel-group 3.

4. Example:

The following example adding the interface fe1 (port 1) to **static-channel-group 1**:

```
switch_a(config)#interface fe1  
switch_a(config-if)#static-channel-group 1  
switch_a(config-if)#{}
```

OPTICAL SYSTEMS DESIGN

7.6 STP / RING

Global Configuration, RSTP Port Setting, MSTP Properties, MSTP Instance Setting, MSTP Port Setting, Ring Setting

GLOBAL CONFIGURATION

STP Version:

1. Command Mode: Configure mode

Logon to Configure Mode (Configure Terminal Mode).

The **switch_a(config)#** prompt will show on the screen.

```
switch_a(config)#
```

2. Usage:

Use this command to choose the Spanning Tree protocol, Rapid Spanning Tree protocol, or Multiple Spanning Tree protocol on a bridge.

3. Command Syntax:

bridge GROUP protocol PROTOCOL vlan-bridge

GROUP <1-1> Bridge group name used for bridging.

PROTOCOL

ieee IEEE 802.1Q spanning-tree protocol.

mstp IEEE 802.1s multiple spanning-tree protocol.

rstp IEEE 802.1w rapid spanning-tree protocol.

4. Example:

The following example chooses the PROTOCOL (**rstp**) on bridge GROUP (1):

```
switch_a(config)#bridge 1 protocol rstp vlan-bridge  
switch_a(config)#
```

Multiple Spanning Tree Protocol:

1. Command Mode: Configure mode

Logon to Configure Mode (Configure Terminal Mode).

The **switch_a(config)#** prompt will show on the screen.

```
switch_a(config)#
```

2. Usage:

Use this command to enable the Multiple Spanning Tree protocol on a bridge.

Use the no form of the command to disable the Multiple Spanning Tree protocol on a bridge.

3. Command Syntax:

bridge GROUP multiple-spanning-tree enable

no bridge GROUP multiple-spanning-tree enable BRIDGE-FORWARD

GROUP <1-1> Bridge group name used for bridging.

BRIDGE-FORWARD Puts all ports of the specified bridge into the forwarding state.

4. Example:

The following example enables or disables the **multiple-spanning-tree** on bridge GROUP (1):

```
switch_a(config)#bridge 1 multiple-spanning-tree enable  
switch_a(config)#no bridge 1 multiple-spanning-tree enable bridge-forward  
switch_a(config)#
```

OPTICAL SYSTEMS DESIGN

Rapid Spanning Tree Protocol:

1. Command Mode: Configure mode

Logon to Configure Mode (Configure Terminal Mode).

The **switch_a(config)#** prompt will show on the screen.

```
switch_a(config)#
```

2. Usage:

Use this command to enable the Rapid Spanning Tree protocol on a bridge.

Use the no form of the command to disable the Rapid Spanning Tree protocol on a bridge.

3. Command Syntax:

```
bridge GROUP rapid-spanning-tree enable
```

```
no bridge GROUP rapid-spanning-tree enable BRIDGE-FORWARD
```

GROUP <1-1> Bridge group name used for bridging.

BRIDGE-FORWARD Puts all ports of the specified bridge into the forwarding state.

4. Example:

The following example enables or disables the **rapid-spanning-tree** on bridge GROUP (1):

```
switch_a(config)#bridge 1 rapid-spanning-tree enable
switch_a(config)#no bridge 1 rapid-spanning-tree enable bridge-forward
switch_a(config)#
```

Spanning Tree Protocol:

1. Command Mode: Configure mode

Logon to Configure Mode (Configure Terminal Mode).

The **switch_a(config)#** prompt will show on the screen.

```
switch_a(config)#
```

2. Usage:

Use this command to enable the Spanning Tree protocol on a bridge.

Use the no form of the command to disable the Spanning Tree protocol on a bridge.

3. Command Syntax:

```
bridge GROUP spanning-tree enable
```

```
no bridge GROUP spanning-tree enable BRIDGE-FORWARD
```

GROUP <1-1> Bridge group name used for bridging.

BRIDGE-FORWARD Puts all ports of the specified bridge into the forwarding state.

4. Example:

The following example enables or disables the **spanning-tree** on bridge GROUP (1):

```
switch_a(config)#bridge 1 spanning-tree enable
switch_a(config)#no bridge 1 spanning-tree enable bridge-forward
switch_a(config)#
```

OPTICAL SYSTEMS DESIGN

Bridge Priority (0..61440):

1. Command Mode: Configure mode

Logon to Configure Mode (Configure Terminal Mode).

The **switch_a(config)#** prompt will show on the screen.

```
switch_a(config)#
```

2. Usage:

Use this command to set bridge priority for the common instance. Using a lower priority indicates a greater likelihood of the bridge becoming root.

3. Command Syntax:

```
bridge GROUP priority PRIORITY
```

```
no bridge GROUP priority
```

GROUP <1-1> The ID of the bridge group for which the priority is set.

PRIORITY <0-61440> The bridge priority.

4. Example:

The following example sets the **priority PRIORITY (4096)** of bridge GROUP (1):

```
switch_a(config)#bridge 1 priority 4096
```

```
switch_a(config)#
```

Hello Time (sec) (1..9):

1. Command Mode: Configure mode

Logon to Configure Mode (Configure Terminal Mode).

The **switch_a(config)#** prompt will show on the screen.

```
switch_a(config)#
```

2. Usage:

Use this command to set the hello-time, the time in seconds after which (if this bridge is the root bridge) all the bridges in a bridged LAN exchange Bridge Protocol Data Units (BPDUs).

3. Command Syntax:

```
bridge GROUP hello-time HELLOTIME
```

```
no bridge GROUP hello-time
```

GROUP <1-1> The ID of the bridge group to which this hello time is assigned.

HELLOTIME <1-9> The hello BPDU interval in seconds.

4. Example:

The following example sets the **hello-time HELLOTIME (9)** of bridge GROUP (1):

```
switch_a(config)#bridge 1 hello-time 9
```

```
switch_a(config)#
```

OPTICAL SYSTEMS DESIGN

Max Age (sec) (6..28):

1. Command Mode: Configure mode

Logon to Configure Mode (Configure Terminal Mode).

The **switch_a(config)#** prompt will show on the screen.

```
switch_a(config)#
```

2. Usage:

Use this command to set the max-age for a bridge.

Use the no parameter with this command to restore the default value of max-age.

3. Command Syntax:

```
bridge GROUP max-age MAXAGE
```

```
no bridge GROUP max-age
```

GROUP <1-1> The ID of the bridge group to which this maximum age time is assigned.

MAXAGE <6-28> The maximum time, in seconds, to listen for the root bridge.

4. Example:

The following example sets the **max-age MAXAGE (28)** of bridge GROUP (1):

```
switch_a(config)#bridge 1 max-age 28
```

```
switch_a(config)#
```

Forward Delay (sec) (4..30):

1. Command Mode: Configure mode

Logon to Configure Mode (Configure Terminal Mode).

The **switch_a(config)#** prompt will show on the screen.

```
switch_a(config)#
```

2. Usage:

Use this command to set the time (in seconds) after which (if this bridge is the root bridge) each port changes states to learning and forwarding.

Use the no parameter with this command to restore the default value.

3. Command Syntax:

```
bridge GROUP forward-time FORWARD_DELAY
```

```
no bridge GROUP forward-time
```

GROUP <1-1> The ID of the bridge group to which this delay time is assigned.

FORWARD_DELAY <4-30> the forwarding time delay in seconds.

4. Example:

The following example sets the **forward-time FORWARD_DELAY (30)** of bridge GROUP (1):

```
switch_a(config)#bridge 1 forward-time 30
```

```
switch_a(config)#
```

OPTICAL SYSTEMS DESIGN

RSTP PORT SETTING

Priority(Granularity 16):

1. Command Mode: Interface mode

Logon to Configure Mode (Configure Terminal Mode).

Then logon to Interface mode.

fe1 means port 1.

The **switch_a(config-if)#** prompt will show on the screen.

```
switch_a(config)#interface fe1  
switch_a(config-if)#
```

2. Usage:

Use this command to set the port priority for a bridge. The lower priority indicates a greater likelihood of the bridge becoming root.

3. Command Syntax:

bridge GROUP priority PRIORITY

GROUP <1-1> the ID of the bridge group.

PRIORITY <0-240> The priority to be assigned to the group.

4. Example:

The following example sets the priority PRIORITY (**100**) of the interface fe1 (port 1) of bridge GROUP (**1**):

```
switch_a(config)#interface fe1  
switch_a(config-if)#bridge 1 priority 100  
switch_a(config-if)#
```

Admin. Path Cost:

1. Command Mode: Interface mode

Logon to Configure Mode (Configure Terminal Mode).

Then logon to Interface mode.

fe1 means port 1.

The **switch_a(config-if)#** prompt will show on the screen.

```
switch_a(config)#interface fe1  
switch_a(config-if)#
```

2. Usage:

Use this command to set the cost of a path associated with a bridge-group.

Use the no parameter with this command to restore the default cost of a path associated with a bridge-group.

3. Command Syntax:

bridge GROUP path-cost PATHCOST

no bridge GROUP path-cost

GROUP <1-1> the ID of the bridge group.

PATHCOST <1-200000000> The cost to be assigned to the group.

4. Example:

The following example sets the cost (**123**) of the interface fe1 (port 1) of bridge GROUP (**1**):

```
switch_a(config)#interface fe1  
switch_a(config-if)#bridge 1 path-cost 123  
switch_a(config-if)#
```

OPTICAL SYSTEMS DESIGN

Point to Point Link:

1. Command Mode: Interface mode

Logon to Configure Mode (Configure Terminal Mode).

Then logon to Interface mode.

fe1 means port 1.

The **switch_a(config-if)#** prompt will show on the screen.

```
switch_a(config)#interface fe1  
switch_a(config-if)#
```

2. Usage:

Use **spanning-tree link-type** command to set the link type of a port to enable or disable rapid transition.

Use the **no spanning-tree link-type** command to set a port to its default state and to disable rapid transition.

3. Command Syntax:

(no) spanning-tree link-type LINKTYPE

LINKTYPE The link type to be assigned to the port.

point-to-point Enable rapid transition.

shared Disable rapid transition.

4. Example:

The following example sets the link-type LINKTYPE (**point-to-point**) of the interface fe1 (port 1):

```
switch_a(config)#interface fe1  
switch_a(config-if)#spanning-tree link-type point-to-point  
switch_a(config-if)#
```

Autoedge:

1. Command Mode: Interface mode

Logon to Configure Mode (Configure Terminal Mode).

Then logon to Interface mode.

fe1 means port 1.

The **switch_a(config-if)#** prompt will show on the screen.

```
switch_a(config)#interface fe1  
switch_a(config-if)#
```

2. Usage:

Use **spanning-tree autoedge** command to assist in automatic identification of the edge port.

Use the **no spanning-tree autoedge** command to disable this feature.

3. Command Syntax:

(no) spanning-tree autoedge

4. Example:

The following example enables the **spanning-tree autoedge** of the interface fe1 (port 1):

```
switch_a(config)#interface fe1  
switch_a(config-if)#spanning-tree autoedge  
switch_a(config-if)#
```

OPTICAL SYSTEMS DESIGN

Edgeport:

1. Command Mode: Interface mode

Logon to Configure Mode (Configure Terminal Mode).

Then logon to Interface mode.

fe1 means port 1.

The **switch_a(config-if)#** prompt will show on the screen.

```
switch_a(config)#interface fe1  
switch_a(config-if)#
```

2. Usage:

Use **spanning-tree edgeport** command to set a port as an edge-port and to enable rapid transitions.

Use the **no spanning-tree edgeport** command to set a port to its default state (not an edge-port) and to disable rapid transitions.

3. Command Syntax:

(no) spanning-tree edgeport

4. Example:

The following example enables the **spanning-tree edgeport** of the interface fe1 (port 1):

```
switch_a(config)#interface fe1  
switch_a(config-if)#spanning-tree edgeport  
switch_a(config-if)#
```

MSTP PROPERTIES

Region Name:

1. Command Mode: MST Configuration mode

Logon to Configure Mode (Configure Terminal Mode).

Then logon to MST Configuration mode.

The **switch_a(config-mst)#** prompt will show on the screen.

```
switch_a(config)#spanning-tree mst configuration  
switch_a(config-mst)#
```

2. Usage:

Use this command to create an MST region and specify a name to it. MST bridges of a region form different spanning trees for different VLANs. By default, each MST bridge starts with the region name as its bridge address. This means each MST bridge is a region by itself, unless specifically added to one.

3. Command Syntax:

bridge GROUP region REGION_NAME

no bridge GROUP region

GROUP <1-1> Specify the bridge-group ID.

REGION_NAME Specify the name of the region.

4. Example:

The following example creates an MST region and specifies a name (**regionname**) to it in bridge GROUP (1):

```
Switch_a(config)#spanning-tree mst configuration  
switch_a(config-mst)#bridge 1 region regionname  
switch_a(config-mst)#
```

OPTICAL SYSTEMS DESIGN

Revision Level:

1. Command Mode: MST Configuration mode

Logon to Configure Mode (Configure Terminal Mode).

Then logon to MST Configuration mode.

The **switch_a(config-mst)#** prompt will show on the screen.

```
switch_a(config)#spanning-tree mst configuration  
switch_a(config-mst)#[/pre]
```

2. Usage:

Use this command to specify the number for configuration information. The default value of revision number is 0.

3. Command Syntax:

```
bridge GROUP revision REVISION_NUM
```

GROUP <1-1> Specify the bridge-group ID.

REVISION_NUM <0-255> Revision number.

4. Example:

The following example specifies a revision number (25) of MST configuration in bridge GROUP (1):

```
switch_a(config)#spanning-tree mst configuration  
switch_a(config-mst)#bridge 1 revision 25  
switch_a(config-mst)#[/pre]
```

Max Hops:

1. Command Mode: Configure mode

Logon to Configure Mode (Configure Terminal Mode).

The **switch_a(config)#** prompt will show on the screen.

```
switch_a(config)#[/pre]
```

2. Usage:

Use this command to specify the maximum allowed hops for BPDU in an MST region. This parameter is used by all the instances of the MST. Specifying the max hops for a BPDU prevents the messages from looping indefinitely in the network. When a bridge receives a MST BPDU that has exceeded the allowed max-hops, it discards the BPDU.

3. Command Syntax:

```
bridge GROUP max-hops HOP_COUNT
```

no bridge GROUP max-hops

GROUP <1-1> Specify the bridge-group ID.

HOP_COUNT Maximum hops the BPDU will be valid for.

4. Example:

The following example specifies the maximum allowed hops (25) for BPDU in bridge GROUP (1):

```
switch_a(config)#bridge 1 max-hops 25  
switch_a(config)#[/pre]
```

OPTICAL SYSTEMS DESIGN

MSTP INSTANCE SETTING

Bridge Instance VLAN:

1. Command Mode: MST Configuration mode

Logon to Configure Mode (Configure Terminal Mode).

Then logon to MST Configuration mode.

The **switch_a(config-mst) #** prompt will show on the screen.

```
switch_a(config)#spanning-tree mst configuration  
switch_a(config-mst)#{/pre}
```

2. Usage:

Use this command to simultaneously add multiple VLANs for the corresponding instance of a bridge. This command can be used only after the VLANs are defined. Use the no parameter with this command to simultaneously remove multiple VLANs for the corresponding instance of a bridge.

3. Command Syntax:

```
bridge GROUP instance INSTANCE_ID vlan VLAN_ID
```

```
no bridge GROUP instance INSTANCE_ID vlan VLAN_ID
```

GROUP <1-1> Specify the bridge-group ID.

INSTANCE_ID <1-15> Specify the instance ID.

VLAN_ID <1-4094> Specify multiple VLAN IDs corresponding to the bridge instance

4. Example:

The following example associates multiple VLANs (10) and (20) to instance (1) of bridge GROUP (1):

```
switch_a(config)#bridge 1 protocol mstp  
switch_a(config)#spanning-tree mst configuration  
switch_a(config-mst)#bridge 1 instance 1 vlan 10, 20  
switch_a(config-mst)#{/pre}
```

Bridge Instance Priority:

1. Command Mode: Configure mode

Logon to Configure Mode (Configure Terminal Mode).

The **switch_a(config) #** prompt will show on the screen.

```
switch_a(config)#{/pre}
```

2. Usage:

Use this command to set the bridge priority for an MST instance to the value specified. Use the no parameter with this command to restore the default value of the bridge priority. The lower the priority of the bridge, the better the chances are the bridge becoming a root bridge or a designated bridge for the LAN. The priority values can be set only in increments of 4096.

3. Command Syntax:

```
bridge GROUP instance INSTANCE_ID priority BRIDGE_PRIORITY
```

```
no bridge GROUP instance INSTANCE_ID priority
```

GROUP <1-1> Specify the bridge-group ID.

INSTANCE_ID Specify the instance ID.

BRIDGE_PRIORITY <0-61440> Specify the bridge priority.

4. Example:

The following example sets the bridge priority (0) for an MST instance (3) in bridge GROUP (1):

```
switch_a(config)#bridge 1 instance 3 priority 0  
switch_a(config)#{/pre}
```

OPTICAL SYSTEMS DESIGN

MSTP PORT SETTING

Bridge-Group Instance:

1. Command Mode: Interface mode

Logon to Configure Mode (Configure Terminal Mode).

Then logon to Interface mode.

fe1 means port 1.

The **switch_a(config-if)#** prompt will show on the screen.

```
switch_a(config)#interface fe1  
switch_a(config-if)#
```

2. Usage:

Use this command to assign a Multiple Spanning Tree instance to a port. Use the no parameter with this command to remove the instance.

3. Command Syntax:

```
bridge GROUP instance INSTANCE_ID  
no bridge GROUP instance INSTANCE_ID  
GROUP <1-1> Specify the bridge-group ID.  
INSTANCE_ID Specify the instance ID.
```

4. Example:

The following example assigns a Multiple Spanning Tree instance (3) to a port (fe1) in bridge GROUP (1):

```
switch_a(config)#interface fe1  
switch_a(config-if)#bridge-group 1 instance 3  
switch_a(config-if)#
```

Bridge-Group Instance Priority:

1. Command Mode: Interface mode

Logon to Configure Mode (Configure Terminal Mode).

Then logon to Interface mode.

fe1 means port 1.

The **switch_a(config-if)#** prompt will show on the screen.

```
switch_a(config)#interface fe1  
switch_a(config-if)#
```

2. Usage:

Use this command to set the port priority for a bridge group. The Multiple Spanning Tree Protocol uses port priority as a tiebreaker to determine which port should forward frames for a particular instance on a LAN, or which port should be the root port for an instance. A lower value implies a better priority. In the case of the same priority, the interface index will serve as the tiebreaker, with the lower-numbered interface being preferred over others. The permitted range is 0-240. The priority values can only be set in increments of 16.

3. Command Syntax:

```
bridge GROUP instance INSTANCE_ID priority PRIORITY  
GROUP <1-1> Specify the bridge-group ID.  
INSTANCE_ID <1-15> Specify the instance ID.  
PRIORITY <0-240> Specify the port priority in a range of <0-240>.
```

4. Example:

The following example sets the port priority (121) for Multiple Spanning Tree instance (3) to a port (fe1) in bridge GROUP (1):

```
switch_a(config)#interface fe1  
switch_a(config-if)#bridge-group 1 instance 3 priority 121  
switch_a(config-if)#
```

OPTICAL SYSTEMS DESIGN

Bridge-Group Instance Path-Cost:

1. Command Mode: Interface mode

Logon to Configure Mode (Configure Terminal Mode).

Then logon to Interface mode.

fe1 means port 1.

The **switch_a(config-if)#** prompt will show on the screen.

```
switch_a(config)#interface fe1  
switch_a(config-if)#{}
```

2. Usage:

Use this command to set the cost of a path associated with an interface. Use the no parameter with this command to restore the default cost value of the path. A lower path-cost indicates a greater likelihood of the specific interface becoming a root.

3. Command Syntax:

```
bridge GROUP instance INSTANCE_ID path-cost PATH_COST
```

GROUP <1-1> Specify the bridge-group ID.

INSTANCE_ID <1-15> Specify the instance ID.

PATH_COST <1-200000000> Specify the cost of path in the range of <1-200000000>.

4. Example:

The following example sets the path cost (**1000**) for Multiple Spanning Tree instance (**3**) to a port (**fe1**) in bridge GROUP (**1**):

```
switch_a(config)#interface fe1  
switch_a(config-if)#bridge-group 1 instance 3 path-cost 1000  
switch_a(config-if)#{}
```

RING SETTING

Ring state:

1. Command Mode: Configure mode

Logon to Configure Mode (Configure Terminal Mode).

The **switch_a(config)#** prompt will show on the screen.

```
switch_a(config)#{}
```

2. Usage:

Use this command to enable Ring state. Use the no parameter with this command to disable Ring state.

3. Command Syntax:

```
bridge GROUP protocol ring
```

no bridge GROUP ring enable BRIDGE-FORWARD

GROUP <1-1> Specify the bridge-group ID.

4. Example:

The following example enables Ring state in bridge GROUP (**1**):

```
switch_a(config)#bridge 1 protocol ring  
switch_a(config)#{}
```

OPTICAL SYSTEMS DESIGN

Set ring port:

1. Command Mode: Configure mode

Logon to Configure Mode (Configure Terminal Mode).

The **switch_a(config)#** prompt will show on the screen.

```
switch_a(config)#
```

2. Usage:

Use this command to set Ring port 1 and Ring port 2.

3. Command Syntax:

```
ring set-port RING_PORT_1 RING_PORT_2
```

RING_PORT_1 Specify the Ring port 1.

RING_PORT_2 Specify the Ring port 2.

4. Example:

The following example sets the fe1 and fe2 as Ring port 1 and Ring port 2:

```
switch_a(config)#ring set-port fe1 fe2
```

```
switch_a(config)#
```

OPTICAL SYSTEMS DESIGN

7.7 VLAN

VLAN Mode Setting, 802.1Q VLAN Setting, 802.1Q Port Setting, Port Based VLAN

802.1Q VLAN SETTING

VLAN Database:

1. Command Mode: Configure mode

Logon to Configure Mode (Configure Terminal Mode).

The **switch_a(config)#** prompt will show on the screen.

```
switch_a(config)#
```

2. Usage:

Use **vlan database** command to enter the VLAN configuration mode.

3. Command Syntax:

```
vlan database
```

4. Example:

The following example changes to VLAN configuration mode from Configure mode:

```
switch_a(config)#vlan database  
switch_a(config-vlan)#
```

Add VLAN/Delete VLAN:

1. Command Mode: VLAN Configure mode

Logon to Configure Mode (Configure Terminal Mode).

Logon to VLAN Configure Mode.

The **switch_a(config-vlan)#** prompt will show on the screen.

```
switch_a(config)#vlan database  
switch_a(config-vlan)#
```

2. Usage:

This command enables or disables the state of a particular VLAN on a bridge basis. Specifying the disable state causes all forwarding over the specified VLAN ID on the specified bridge to cease. Specifying the enable state allows forwarding of frames on the specified VLAN-aware bridge.

3. Command Syntax:

```
vlan VLANID bridge GROUP name VLAN_NAME state enable/disable
```

```
no vlan VLANID bridge GROUP
```

VLANID The VID of the VLAN that will be enabled or disabled on the bridge <2-4094>.

GROUP <1-1> The ID of the bridge-group on which the VLAN will be affected.

VLAN_NAME The ASCII name of the VLAN. Maximum length: 16 characters.

enable Sets VLAN into an enable state.

disable Sets VLAN into a disable state.

4. Example:

The following example enables the vlan VLANID (2) and name VLAN_NAME (**vlan2**) of bridge GROUP (1):

```
switch_a(config-vlan)#vlan 2 bridge 1 name vlan2 state enable  
switch_a(config-vlan)#
```

OPTICAL SYSTEMS DESIGN

802.1Q PORT SETTING

Switchport mode access:

1. Command Mode: Interface mode

Logon to Configure Mode (Configure Terminal Mode).

Then logon to Interface mode.

fe1 means port 1.

The **switch_a(config-if)#** prompt will show on the screen.

```
switch_a(config)#interface fe1  
switch_a(config-if)#
```

2. Usage:

Use **switchport mode access** command to set the switching characteristics of the Layer-2 interface to access mode, and classify untagged frames only.

Use the **no switchport access** command to reset the mode of the Layer-2 interface to access (default).

3. Command Syntax:

```
switchport mode access  
no switchport access
```

4. Example:

The following example sets the **switchport mode access** of the interface fe1 (port 1):

```
switch_a(config)#interface fe1  
switch_a(config-if)#switchport mode access  
switch_a(config-if)#
```

Switchport mode hybrid:

1. Command Mode: Interface mode

Logon to Configure Mode (Configure Terminal Mode).

Then logon to Interface mode.

fe1 means port 1.

The **switch_a(config-if)#** prompt will show on the screen.

```
switch_a(config)#interface fe1  
switch_a(config-if)#
```

2. Usage:

Use **switchport mode hybrid** command to set the switching characteristics of the Layer-2 interface as hybrid, and classify both tagged and untagged frames.

Use the **no switchport hybrid** command to reset the mode of the Layer-2 interface to access (default).

3. Command Syntax:

```
switchport mode hybrid  
switchport mode hybrid acceptable-frame-type all/vlan-tagged  
no switchport hybrid  
all Set all frames can be received.  
vlan-tagged Set vlan-tagged frames can only be received.
```

4. Example:

The following example sets the **switchport mode hybrid** of the interface fe1 (port 1) and all frames to be received on interface fe1 (port 1):

```
switch_a(config)#interface fe1  
switch_a(config-if)#switchport mode hybrid acceptable-frame-type all  
switch_a(config-if)#
```

OPTICAL SYSTEMS DESIGN

Switchport mode trunk:

1. Command Mode: Interface mode

Logon to Configure Mode (Configure Terminal Mode).

Then logon to Interface mode.

fe1 means port 1.

The **switch_a(config-if)#** prompt will show on the screen.

```
switch_a(config)#interface fe1  
switch_a(config-if)#
```

2. Usage:

Use **switchport mode trunk** command to set the switching characteristics of the Layer-2 interface as trunk, and specify only tagged frames.

Use the **no switchport trunk** command to reset the mode of the Layer-2 interface to access (default).

3. Command Syntax:

switchport mode trunk

no switchport trunk

4. Example:

The following example sets the **switchport mode trunk** of the interface fe1 (port 1):

```
switch_a(config)#interface fe1  
switch_a(config-if)#switchport mode trunk  
switch_a(config-if)#
```

Switchport hybrid allowed vlan:

1. Command Mode: Interface mode

Logon to Configure Mode (Configure Terminal Mode).

Then logon to Interface mode.

fe1 means port 1.

The **switch_a(config-if)#** prompt will show on the screen.

```
switch_a(config)#interface fe1  
switch_a(config-if)#
```

2. Usage:

Use this command to set the switching characteristics of the Layer-2 interface to hybrid. Both tagged and untagged frames will be classified over hybrid interfaces.

Use the no parameter to turn off allowed hybrid switching.

3. Command Syntax:

switchport hybrid allowed vlan all

switchport hybrid allowed vlan none

switchport hybrid allowed vlan add VLANID egress-tagged enable/disable

switchport hybrid allowed vlan remove VLANID

no switchport hybrid vlan

all Allow all VLANs to transmit and receive through the Layer-2 interface.

none Allow no VLANs to transmit and receive through the Layer-2 interface.

add Add a VLAN to the member set.

remove Remove a VLAN from the member set.

VLANID <2-4094> The ID of the VLAN or VLANs that will be added to, or removed from, the Layer-2 interface.

For a VLAN range, specify two VLAN numbers: lowest, then highest number in the range, separated by a hyphen.

OPTICAL SYSTEMS DESIGN

For a VLAN list, specify the VLAN numbers separated by commas.
egress-tagged
enable Enable the egress tagging for the outgoing frames.
disable Disable the egress tagging for the outgoing frames.

4. Example:

The following example specifies to **add** the interface fe1 (port 1) to VLANID (2) and **enable** the **egress-tagged** for the outgoing frames on interface fe1 (port 1):

```
switch_a(config)#interface fe1
switch_a(config-if)#switchport hybrid allowed vlan add 2 egress-tagged enable
switch_a(config-if)#
```

Switchport trunk allowed vlan:

1. Command Mode: Interface mode
Logon to Configure Mode (Configure Terminal Mode).
Then logon to Interface mode.
fe1 means port 1.

The **switch_a(config-if)#** prompt will show on the screen.

```
switch_a(config)#interface fe1
switch_a(config-if)#
```

2. Usage:

Use this command to set the switching characteristics of the Layer-2 interface to trunk. The all parameter indicates that any VLAN ID is part of its port's member set. The none parameter indicates that no VLAN ID is configured on this port. The add and remove parameters will add and remove VLAN IDs to/from the port's member set.

Use the no parameter to remove all VLAN IDs configured on this port.

3. Command Syntax:

```
switchport trunk allowed vlan all
switchport trunk allowed vlan none
switchport trunk allowed vlan add VLANID
switchport trunk allowed vlan remove VLANID
switchport trunk allowed vlan except VLANID
no switchport trunk vlan
all Allow all VLANs to transmit and receive through the Layer-2 interface.
none Allow no VLANs to transmit and receive through the Layer-2 interface.
add Add a VLAN to transmit and receive through the Layer-2 interface.
remove Remove a VLAN from transmit and receive through the Layer-2 interface.
except All VLANs, except the VLAN for which the ID is specified, are part of its ports member set.
VLANID <2-4094> The ID of the VLAN or VLANs that will be added to, or removed from, the Layer-2 interface. A single VLAN, VLAN range, or VLAN list can be set.
For a VLAN range, specify two VLAN numbers: lowest, then highest number in the range, separated by a hyphen.
For a VLAN list, specify the VLAN numbers separated by commas.
```

4. Example:

The following example specifies to **add** the interface fe1 (port 1) to VLANID (2):

```
switch_a(config)#interface fe1
switch_a(config-if)#switchport trunk allowed vlan add 2
switch_a(config-if)#
```

OPTICAL SYSTEMS DESIGN

PORT BASED VLAN

Switchport portbase add/remove vlan:

1. Command Mode: Interface mode

Logon to Configure Mode (Configure Terminal Mode).

Then logon to Interface mode.

fe1 means port 1.

The **switch_a(config-if)#** prompt will show on the screen.

```
switch_a(config)#interface fe1  
switch_a(config-if)#
```

2. Usage:

Use this command to set or remove the default VLAN for the interface.

3. Command Syntax:

switchport portbase add | remove vlan VLANID

VLANID The ID of the VLAN will be added to or removed from the Layer-2 interface.

4. Example:

The following example specifies to **add** the interface fe1 (port 1) to VLANID (2):

```
switch_a(config)#interface fe1  
switch_a(config-if)#switchport portbase add vlan 2  
switch_a(config-if)#
```

OPTICAL SYSTEMS DESIGN

7.8 QOS

Global Configuration, 802.1p Priority, DSCP

GLOBAL CONFIGURATION

QoS:

1. Command Mode: Configure mode

Logon to Configure Mode (Configure Terminal Mode).

The **switch_a(config)#** prompt will show on the screen.

```
switch_a(config)#
```

2. Usage:

Use **mls qos enable** command to globally enable QoS.

Use the **no mls qos** command to globally disable QoS.

3. Command Syntax:

mls qos enable

(no) mls qos

4. Example:

The following example globally enables QoS on the switch:

```
switch_a(config)#mls qos enable
```

```
switch_a(config)#
```

Trust:

1. Command Mode: Configure mode

Logon to Configure Mode (Configure Terminal Mode).

The **switch_a(config)#** prompt will show on the screen.

```
switch_a(config)#
```

2. Usage:

Use **mls qos trust** command to turn on QoS trust CoS or DSCP.

Use the **no mls qos trust** command to turn off QoS trust CoS or DSCP.

3. Command Syntax:

(no) mls qos trust cos/dscp

cos Class of Service.

dscp Differentiated Service Code Point.

4. Example:

The following example turns on QoS trust CoS on the switch:

```
switch_a(config)#mls qos trust cos
```

```
switch_a(config)#
```

OPTICAL SYSTEMS DESIGN

Strict Priority:

1. Command Mode: Configure mode

Logon to Configure Mode (Configure Terminal Mode).

The **switch_a(config)#** prompt will show on the screen.

```
switch_a(config)#
```

2. Usage:

Use **priority-queue out** command to enable the egress expedite queue.

Use the **no priority-queue out** command to disable the egress expedite queue.

3. Command Syntax:

```
(no) priority-queue out
```

4. Example:

The following example enables the egress expedite queue on the switch:

```
switch_a(config)#priority-queue out  
switch_a(config)#
```

Weighted Round Robin:

1. Command Mode: Configure mode

Logon to Configure Mode (Configure Terminal Mode).

The **switch_a(config)#** prompt will show on the screen.

```
switch_a(config)#
```

2. Usage:

Use **wrr-queue bandwidth** command to specify the bandwidth ratios of the transmit queues.

3. Command Syntax:

```
wrr-queue bandwidth WRR_WTS
```

WRR_WTS Weighted Round Robin (WRR) weights for the 4 queues (4 values separated by spaces).

Range is 1-55.

4. Example:

The following example specifies the bandwidth ratios of the transmit queues on the switch:

```
switch_a(config)#wrr-queue bandwidth 1 2 4 8  
switch_a(config)#
```

802.1P PRIORITY

1. Command Mode: Configure mode

Logon to Configure Mode (Configure Terminal Mode).

The **switch_a(config)#** prompt will show on the screen.

```
switch_a(config)#
```

2. Usage:

Use **wrr-queue cos-map** command to specify CoS values for a queue.

3. Command Syntax:

```
wrr-queue cos-map QUEUE_ID COS_VALUE
```

QUEUE_ID Queue ID. Range is 0-3.

COS_VALUE CoS values. Up to 8 values (separated by spaces). Range is 0-7.

4. Example:

The following example shows mapping CoS values 0 and 1 to queue 1 on the switch:

```
switch_a(config)#wrr-queue cos-map 1 0 1  
switch_a(config)#
```

OPTICAL SYSTEMS DESIGN

DSCP

1. Command Mode: Configure mode

Logon to Configure Mode (Configure Terminal Mode).

The **switch_a(config)#** prompt will show on the screen.

```
switch_a(config)#
```

2. Usage:

Use **mls qos map dscp-queue** command to map the DSCP values to a queue.

3. Command Syntax:

```
mls qos map dscp-queue DSCP_VALUE to QUEUE_ID
```

DSCP_VALUE DSCP values. Up to 8 values (separated by spaces). Range is 0-63.

QUEUE_ID Queue ID. Range is 0-3.

4. Example:

The following example shows mapping DSCP values 0 to 3 to queue 1 on the switch:

```
switch_a(config)#mls qos map dscp-queue 0 1 2 3 to 1
```

```
switch_a(config)#
```

OPTICAL SYSTEMS DESIGN

7.9 SNMP

SNMP General Setting, SNMP v1/v2c, SNMP v3

SNMP GENERAL SETTING

SNMP Status:

1. Command Mode: Configure mode

Logon to Configure Mode (Configure Terminal Mode).

The **switch_a(config)#** prompt will show on the screen.

```
switch_a(config)#
```

2. Usage:

Use **snmp-server enable** command to enable and **no snmp-server enable** command to disable SNMP to the switch.

3. Command Syntax:

(no) snmp-server enable

4. Example:

The following example enables SNMP to the switch:

```
switch_a(config)#snmp-server enable  
switch_a(config)#
```

Description:

1. Command Mode: Configure mode

Logon to Configure Mode (Configure Terminal Mode).

The **switch_a(config)#** prompt will show on the screen.

```
switch_a(config)#
```

2. Usage:

Use **snmp-server description** command to specify and **no snmp-server description** command to remove description for SNMP.

3. Command Syntax:

snmp-server description DESCRIPTION

no snmp-server description

DESCRIPTION The description for SNMP.

4. Example:

The following example specifies description (**description**) for SNMP:

```
switch_a(config)#snmp-server description description  
switch_a(config)#
```

OPTICAL SYSTEMS DESIGN

Location:

1. Command Mode: Configure mode

Logon to Configure Mode (Configure Terminal Mode).

The **switch_a(config)#** prompt will show on the screen.

```
switch_a(config)#
```

2. Usage:

Use **snmp-server location** command to specify and **no snmp-server location** command to remove location for SNMP.

3. Command Syntax:

```
snmp-server location LOCATION
```

```
no snmp-server location
```

LOCATION The location for SNMP.

4. Example:

The following example specifies location (**location**) for SNMP:

```
switch_a(config)#snmp-server location location
```

```
switch_a(config)#
```

Contact:

1. Command Mode: Configure mode

Logon to Configure Mode (Configure Terminal Mode).

The **switch_a(config)#** prompt will show on the screen.

```
switch_a(config)#
```

2. Usage:

Use **snmp-server contact** command to specify and **no snmp-server contact** command to remove contact for SNMP.

3. Command Syntax:

```
snmp-server contact CONTACT
```

```
no snmp-server contact
```

CONTACT The contact for SNMP.

4. Example:

The following example specifies contact (**contact**) for SNMP:

```
switch_a(config)#snmp-server contact contact
```

```
switch_a(config)#
```

OPTICAL SYSTEMS DESIGN

Trap Community Name:

1. Command Mode: Configure mode

Logon to Configure Mode (Configure Terminal Mode).

The **switch_a(config)#** prompt will show on the screen.

```
switch_a(config)#
```

2. Usage:

Use this command to specify trap community name for SNMP.

Use the no parameter with this command to remove trap community name for SNMP.

3. Command Syntax:

```
snmp-server trap-community <1-5> NAME
```

```
no snmp-server trap-community <1-5>
```

<1-5> The trap community 1-5.

NAME The trap community name for SNMP.

4. Example:

The following example specifies trap community name 1 (**name**) for SNMP:

```
switch_a(config)#snmp-server trap-community 1 name
```

```
switch_a(config)#
```

Trap Host IP Address:

1. Command Mode: Configure mode

Logon to Configure Mode (Configure Terminal Mode).

The **switch_a(config)#** prompt will show on the screen.

```
switch_a(config)#
```

2. Usage:

Use this command to specify trap host IP address for SNMP.

Use the no parameter with this command to remove trap host IP address for SNMP.

3. Command Syntax:

```
snmp-server trap-ipaddress <1-5> IP-ADDRESS
```

```
no snmp-server trap-ipaddress <1-5>
```

<1-5> The trap host IP address 1-5.

IP-ADDRESS The trap host IP address for SNMP. A.B.C.D specifies the IP address.

4. Example:

The following example specifies trap host 1 IP address (**192.168.1.20**) for SNMP:

```
switch_a(config)#snmp-server trap-ipaddress 1 192.168.1.20
```

```
switch_a(config)#
```

OPTICAL SYSTEMS DESIGN

Cold Start Trap:

1. Command Mode: Configure mode

Logon to Configure Mode (Configure Terminal Mode).

The **switch_a(config)#** prompt will show on the screen.

```
switch_a(config)#
```

2. Usage:

Use **snmp-server trap-type enable coldStart** command to enable cold start trap for SNMP.

Use the **no snmp-server trap-type enable coldStart** command to disable cold start trap for SNMP.

Command Syntax:

```
(no) snmp-server trap-type enable coldStart
```

3. Example:

The following example enables cold start trap for SNMP:

```
switch_a(config)#snmp-server trap-type enable coldStart  
switch_a(config)#
```

Warm Start Trap:

1. Command Mode: Configure mode

Logon to Configure Mode (Configure Terminal Mode).

The **switch_a(config)#** prompt will show on the screen.

```
switch_a(config)#
```

2. Usage:

Use **snmp-server trap-type enable warmStart** command to enable warm start trap for SNMP.

Use the **no snmp-server trap-type enable warmStart** command to disable warm start trap for SNMP.

Command Syntax:

```
(no) snmp-server trap-type enable warmStart
```

3. Example:

The following example enables warm start trap for SNMP:

```
switch_a(config)#snmp-server trap-type enable warmStart  
switch_a(config)#
```

Link Down Trap:

1. Command Mode: Configure mode

Logon to Configure Mode (Configure Terminal Mode).

The **switch_a(config)#** prompt will show on the screen.

```
switch_a(config)#
```

2. Usage:

Use **snmp-server trap-type enable linkDown** command to enable link down trap for SNMP.

Use the **no snmp-server trap-type enable linkDown** command to disable link down trap for SNMP.

Command Syntax:

```
(no) snmp-server trap-type enable linkDown
```

3. Example:

The following example enables link down trap for SNMP:

```
switch_a(config)#snmp-server trap-type enable linkDown  
switch_a(config)#
```

OPTICAL SYSTEMS DESIGN

Link Up Trap:

1. Command Mode: Configure mode

Logon to Configure Mode (Configure Terminal Mode).

The **switch_a(config)#** prompt will show on the screen.

```
switch_a(config)#
```

2. Usage:

Use **snmp-server trap-type enable linkUp** command to enable link up trap for SNMP.

Use the **no snmp-server trap-type enable linkUp** command to disable link up trap for SNMP.

3. Command Syntax:

```
(no) snmp-server trap-type enable linkUp
```

4. Example:

The following example enables link up trap for SNMP:

```
switch_a(config)#snmp-server trap-type enable linkUp  
switch_a(config)#
```

Authentication Failure Trap:

1. Command Mode: Configure mode

Logon to Configure Mode (Configure Terminal Mode).

The **switch_a(config)#** prompt will show on the screen.

```
switch_a(config)#
```

2. Usage:

Use **snmp-server trap-type enable authenticationFailure** command to enable authentication failure trap for SNMP.

Use the **no snmp-server trap-type enable authenticationFailure** command to disable authentication failure trap for SNMP.

3. Command Syntax:

```
(no) snmp-server trap-type enable authenticationFailure
```

4. Example:

The following example enables authentication failure trap for SNMP:

```
switch_a(config)#snmp-server trap-type enable authenticationFailure  
switch_a(config)#
```

OPTICAL SYSTEMS DESIGN

Topology Change Trap:

1. Command Mode: Configure mode

Logon to Configure Mode (Configure Terminal Mode).

The **switch_a(config)#** prompt will show on the screen.

```
switch_a(config)#
```

2. Usage:

Use **snmp-server trap-type enable topologyChange** command to enable topology change trap for SNMP.

Use the **no snmp-server trap-type enable topologyChange** command to disable topology change trap for SNMP.

3. Command Syntax:

```
(no) snmp-server trap-type enable topologyChange
```

4. Example:

The following example enables topology change trap for SNMP:

```
switch_a(config)#snmp-server trap-type enable topologyChange  
switch_a(config)#
```

SNMP V1/V2C

Get Community Name:

1. Command Mode: Configure mode

Logon to Configure Mode (Configure Terminal Mode).

The **switch_a(config)#** prompt will show on the screen.

```
switch_a(config)#
```

2. Usage:

Use **snmp-server community get** command to specify and **no snmp-server community get** command to remove get community name for SNMP.

3. Command Syntax:

```
snmp-server community get NAME
```

```
no snmp-server community get
```

NAME The get community name for SNMP.

4. Example:

The following example specifies get community name (**name**) for SNMP:

```
switch_a(config)#snmp-server community get name  
switch_a(config)#
```

OPTICAL SYSTEMS DESIGN

Set Community Name:

1. Command Mode: Configure mode

Logon to Configure Mode (Configure Terminal Mode).

The **switch_a(config)#** prompt will show on the screen.

```
switch_a(config)#
```

2. Usage:

Use **snmp-server community set** command to specify and **no snmp-server community set** command to remove set community name for SNMP.

3. Command Syntax:

```
snmp-server community set NAME
```

```
no snmp-server community set
```

NAME The set community name for SNMP.

4. Example:

The following example specifies set community name (**name**) for SNMP:

```
switch_a(config)#snmp-server community set name  
switch_a(config)#
```

SNMP V3

SNMPv3 No-Auth:

1. Command Mode: Configure mode

Logon to Configure Mode (Configure Terminal Mode).

The **switch_a(config)#** prompt will show on the screen.

```
switch_a(config)#
```

2. Usage:

Add a user using snmp v3 with read-only or read-write access mode and without authentication. Use the no form of the command to delete this user.

3. Command Syntax:

```
(no) snmp-server v3-user USERNAME (ro | rw) noauth
```

USERNAME Specify a user name.

ro read-only access mode

rw read-write access mode

4. Example:

The following example adds a user (**myuser**) using snmp v3 with read-only access mode and without authentication:

```
switch_a(config)#snmp-server v3-user myuser ro noauth  
switch_a(config)#
```

OPTICAL SYSTEMS DESIGN

SNMPv3 Auth-MD5, SNMPv3 Auth-SHA:

1. Command Mode: Configure mode

Logon to Configure Mode (Configure Terminal Mode).

The **switch_a(config)#** prompt will show on the screen.

```
switch_a(config)#
```

2. Usage:

Add a user using snmp v3 with read-only or read-write access mode and with MD5 or SHA authentication. Use the no form of the command to delete this user.

3. Command Syntax:

```
(no) snmp-server v3-user USERNAME (ro | rw) auth (md5 | sha) AUTH_PASSWORD
```

USERNAME Specify a user name.

ro read-only access mode

rw read-write access mode

md5 authentication method

sha authentication method

AUTH_PASSWORD authentication password

4. Example:

The following example adds a user (**myuser**) using snmp v3 with read-write access mode and MD5 authentication (**mypassword**):

```
switch_a(config)#snmp-server v3-user myuser rw auth md5  
mypassword  
switch_a(config)#
```

SNMPv3 Priv Auth-MD5, SNMPv3 Priv Auth-SHA:

1. Command Mode: Configure mode

Logon to Configure Mode (Configure Terminal Mode).

The **switch_a(config)#** prompt will show on the screen.

```
switch_a(config)#
```

2. Usage:

Add a user using snmp v3 with read-only or read-write access mode, MD5 or SHA authentication, and privacy. Use the no form of the command to delete this user.

3. Command Syntax:

```
(no) snmp-server v3-user USERNAME (ro | rw) priv auth (md5 | sha) AUTH_PASSWORD des  
PRIV_PASS_PHRASE
```

USERNAME Specify a user name.

ro read-only access mode

rw read-write access mode

md5 authentication method

sha authentication method

AUTH_PASSWORD authentication password

PRIV_PASS_PHRASE encryption pass phrase

4. Example:

The following example adds a user (**myuser**) using snmp v3 with read-write access mode, MD5 authentication (**mypassword**), and encryption pass phrase (**mypassphrase**):

```
switch_a(config)#snmp-server v3-user myuser rw priv md5  
mypassword des mypassphrase  
switch_a(config)#
```

OPTICAL SYSTEMS DESIGN

7.10 802.1X

Radius Configuration, Port-Based Authentication

RADIUS CONFIGURATION

Radius Status:

1. Command Mode: Configure mode

Logon to Configure Mode (Configure Terminal Mode).

The **switch_a(config)#** prompt will show on the screen.

```
switch_a(config)#
```

2. Usage:

Use **dot1x system-auth-ctrl** command to globally enable authentication.

Use **no dot1x system-auth-ctrl** command to globally disable authentication.

3. Command Syntax:

(no) dot1x system-auth-ctrl

4. Example:

The following example globally enables authentication:

```
switch_a(config)#dot1x system-auth-ctrl  
switch_a(config)#
```

Radius Server IP:

Radius Server Port:

1. Command Mode: Configure mode

Logon to Configure Mode (Configure Terminal Mode).

The **switch_a(config)#** prompt will show on the screen.

```
switch_a(config)#
```

2. Usage:

Use this command to specify the IP address of the remote radius server host and assign authentication and accounting destination port number.

3. Command Syntax:

(no) radius-server host IP-ADDRESS auth-port PORT

IP-ADDRESS A.B.C.D specifies the IP address of the radius server host.

PORT specifies the UDP destination port for authentication requests. The host is not used for authentication if set to 0.

4. Example:

The following example specifies the IP address (**192.168.1.100**) of the remote radius server host and assigns authentication and accounting destination port number (**1812**):

```
switch_a(config)#radius-server host 192.168.1.100 auth-port 1812  
switch_a(config)#
```

OPTICAL SYSTEMS DESIGN

Secret Key:

1. Command Mode: Configure mode

Logon to Configure Mode (Configure Terminal Mode).

The **switch_a(config)#** prompt will show on the screen.

```
switch_a(config)#
```

2. Usage:

Use this command to set the shared secret key between a Radius server and a client.

3. Command Syntax:

(no) radius-server host IP-ADDRESS key KEY

IP-ADDRESS A.B.C.D specifies the IP address of the radius server host.

KEY specifies the secret key shared among the radius server and the 802.1x client.

4. Example:

The following example specifies the IP address (**192.168.1.100**) of the remote radius server host and set the secret key (**ipi**) shared among the radius server and the 802.1x client:

```
switch_a(config)#radius-server host 192.168.1.100 key ipi  
switch_a(config)#
```

Timeout:

1. Command Mode: Configure mode

Logon to Configure Mode (Configure Terminal Mode).

The **switch_a(config)#** prompt will show on the screen.

```
switch_a(config)#
```

2. Usage:

Use this command to specify the number of seconds a Switch waits for a reply to a radius request before retransmitting the request.

3. Command Syntax:

radius-server timeout SEC

no radius-server timeout

SEC <1-1000> The number of seconds for a Switch to wait for a server host to reply before timing out. Enter a value in the range 1 to 1000.

4. Example:

The following example specifies **20** seconds for the Switch to wait for a server host to reply before timing out:

```
switch_a(config)#radius-server timeout 20  
switch_a(config)#
```

OPTICAL SYSTEMS DESIGN

Retransmit:

1. Command Mode: Configure mode

Logon to Configure Mode (Configure Terminal Mode).

The **switch_a(config)#** prompt will show on the screen.

```
switch_a(config)#
```

2. Usage:

Use this command to specify the number of times the Switch transmits each radius request to the server before giving up.

3. Command Syntax:

```
radius-server retransmit RETRIES
```

```
no radius-server retransmit
```

RETRIES <1-100> Specifies the retransmit value. Enter a value in the range 1 to 100.

4. Example:

The following example specifies the retransmit value **12**:

```
switch_a(config)#radius-server retransmit 12  
switch_a(config)#
```

PORt-BASED AUTHENTICATION

Authentication State:

1. Command Mode: Interface mode

Logon to Configure Mode (Configure Terminal Mode).

Then logon to Interface mode.

fe1 means port 1.

The **switch_a(config-if)#** prompt will show on the screen.

```
switch_a(config)#interface fe1  
switch_a(config-if)#
```

2. Usage:

Use **dot1x reauthentication** command to enable reauthentication on a port.

Use **no dot1x reauthentication** command to disable reauthentication on a port.

3. Command Syntax:

```
(no) dot1x reauthentication
```

4. Example:

The following example specifies to enable reauthentication on the interface fe1 (port 1):

```
switch_a(config)#interface fe1  
switch_a(config-if)#dot1x reauthentication  
switch_a(config-if)#
```

OPTICAL SYSTEMS DESIGN

Port Control:

1. Command Mode: Interface mode

Logon to Configure Mode (Configure Terminal Mode).

Then logon to Interface mode.

fe1 means port 1.

The **switch_a(config-if)#** prompt will show on the screen.

```
switch_a(config)#interface fe1  
switch_a(config-if)#
```

2. Usage:

Use this command to force a port state.

Use **no dot1x port-control** command to remove a port from the 802.1x management.

3. Command Syntax:

dot1x port-control auto | force-authorized | force-unauthorized

no dot1x port-control

auto Specify to enable authentication on port.

force-authorized Specify to force a port to always be in an authorized state.

force-unauthorized Specify to force a port to always be in an unauthorized state.

4. Example:

The following example specifies to enable authentication on the interface fe1 (port 1):

```
switch_a(config)#interface fe1  
switch_a(config-if)#dot1x port-control auto  
switch_a(config-if)#
```

Periodic Reauthentication:

Reauthentication Period:

1. Command Mode: Interface mode

Logon to Configure Mode (Configure Terminal Mode).

Then logon to Interface mode.

fe1 means port 1.

The **switch_a(config-if)#** prompt will show on the screen.

```
switch_a(config)#interface fe1  
switch_a(config-if)#
```

2. Usage:

Use this command to set the interval between reauthorization attempts.

Use **no dot1x timeout re-authperiod** command to delete the interval between reauthorization attempts.

3. Command Syntax:

dot1x timeout re-authperiod SECS

no dot1x timeout re-authperiod

SECS <1-4294967295> Specify the seconds between reauthorization attempts. The default time is 3600 seconds.

4. Example:

The following example specifies to set the interval **25** seconds between reauthorization attempts:

```
switch_a(config)#interface fe1  
switch_a(config-if)#dot1x timeout re-authperiod 25  
switch_a(config-if)#
```

OPTICAL SYSTEMS DESIGN

7.11 OTHER PROTOCOLS

GVRP, IGMP Snooping, NTP

GVRP

GVRP:

1. Command Mode: Configure mode

Logon to Configure Mode (Configure Terminal Mode).

The **switch_a(config)#** prompt will show on the screen.

```
switch_a(config)#
```

2. Usage:

Use **set gvrp enable bridge** command to enable (set) and **set gvrp disable bridge** command to disable (reset) GVRP globally for the bridge instance. This command does not enable/disable GVRP in all ports of the bridge. After enabling GVRP globally, use the **set port gvrp enable** command to enable GVRP on individual ports of the bridge.

3. Command Syntax:

set gvrp enable bridge GROUP

set gvrp disable bridge GROUP

GROUP Bridge-group ID used for bridging.

4. Example:

The following example globally enables GVRP to bridge GROUP (1):

```
switch_a(config)#set gvrp enable bridge 1  
switch_a(config)#
```

Dynamic VLAN creation:

1. Command Mode: Configure mode

Logon to Configure Mode (Configure Terminal Mode).

The **switch_a(config)#** prompt will show on the screen.

```
switch_a(config)#
```

2. Usage:

Use **set gvrp dynamic-vlan-creation enable bridge** command to enable and **set gvrp dynamic-vlan-creation disable bridge** command to disable dynamic VLAN creation for a specific bridge instance.

3. Command Syntax:

set gvrp dynamic-vlan-creation enable bridge GROUP

set gvrp dynamic-vlan-creation disable bridge GROUP

GROUP Bridge-group ID used for bridging.

4. Example:

The following example enables dynamic VLAN creation for bridge GROUP (1):

```
switch_a(config)#set gvrp dynamic-vlan-creation enable bridge 1  
switch_a(config)#
```

OPTICAL SYSTEMS DESIGN

Per port setting:

GVRP:

1. Command Mode: Configure mode

Logon to Configure Mode (Configure Terminal Mode).

The **switch_a(config)#** prompt will show on the screen.

```
switch_a(config)#
```

2. Usage:

Use **set port gvrp enable** command to enable and **set port gvrp disable** command to disable GVRP on a port or all ports in a bridge.

3. Command Syntax:

set port gvrp enable all/IFNAME

set port gvrp disable all/IFNAME

all All ports added to recently configured bridge.

IFNAME The name of the interface.

4. Example:

The following example enables GVRP on the interface fe1 (port 1):

```
switch_a(config)#set port gvrp enable fe1  
switch_a(config)#
```

Per port setting:

GVRP applicant:

1. Command Mode: Configure mode

Logon to Configure Mode (Configure Terminal Mode).

The **switch_a(config)#** prompt will show on the screen.

```
switch_a(config)#
```

2. Usage:

Use this command to set the GVRP applicant state to normal or active.

3. Command Syntax:

set gvrp applicant state active/normal IFNAME

active Active state

normal Normal state

IFNAME Name of the interface.

4. Example:

The following example sets GVRP applicant state to active on the interface fe1 (port 1):

```
switch_a(config)#set gvrp applicant state active fe1  
switch_a(config)#
```

OPTICAL SYSTEMS DESIGN

Per port setting:

GVRP registration:

1. Command Mode: Configure mode

Logon to Configure Mode (Configure Terminal Mode).

The **switch_a(config)#** prompt will show on the screen.

```
switch_a(config)#
```

2. Usage:

Use this command to set GVRP registration to normal, fixed, and forbidden registration mode for a given port.

3. Command Syntax:

```
set gvrp registration normal IF_NAME
```

```
set gvrp registration fixed IF_NAME
```

```
set gvrp registration forbidden IF_NAME
```

normal Specify dynamic GVRP multicast registration and deregistration on the port.

fixed Specify the multicast groups currently registered on the switch are applied to the port, but any subsequent registrations or deregistrations do not affect the port. Any registered multicast groups on the port are not deregistered based on the GARP timers.

forbidden Specify that all GVRP multicasts are deregistered, and prevent any further GVRP multicast registration on the port.

IF_NAME The name of the interface.

4. Example:

The following example sets GVRP registration to fixed registration mode on the interface fe1 (port 1):

```
switch_a(config)#set gvrp registration fixed fe1
```

```
switch_a(config)#
```

IGMP SNOOPING

IGMP mode:

Querier:

1. Command Mode: Configure mode

Logon to Configure Mode (Configure Terminal Mode).

Then logon to Interface mode.

Vlan1.1 means vlan 1

The **switch_a(config-if)#** prompt will show on the screen.

```
switch_a(config)#interface vlan1.1
```

2. Usage:

Use **ip igmp snooping querier** command to enable IGMP querier operation on a subnet (VLAN) when no multicast routing protocol is configured in the subnet (VLAN). When enabled, the IGMP Snooping querier sends out periodic IGMP queries for all interfaces on that VLAN.

Use the **no ip igmp snooping querier** command to disable IGMP querier configuration.

3. Command Syntax:

```
(no) ip igmp snooping querier
```

4. Example:

The following example enables IGMP snooping querier:

```
switch_a(config)#interface vlan1.1
```

```
switch_a(config-if)#ip igmp snooping querier
```

OPTICAL SYSTEMS DESIGN

IGMP mode:

Passive:

1. Command Mode: Configure mode

Logon to Configure Mode (Configure Terminal Mode).

The **switch_a(config)#** prompt will show on the screen.

Then logon on Interface mode.

vlan1.1 means vlan 1.

The **switch_a(config-if)#** prompt will show on the screen.

```
switch_aconfigure terminal  
switch_a(config-if)#[/pre]
```

```
switch_a(config)#interface vlan1.1  
switch_a(config-if)#[/pre]
```

2. Usage:

Use **ip igmp snooping** command to enable IGMP Snooping. When this command is given in the Global Config mode, IGMP Snooping is enabled at the switch level. When this command is given at the VLAN interface level, IGMP Snooping is enabled for that VLAN.

Use the **no ip igmp snooping** command to globally disable IGMP Snooping, or for the specified interface.

3. Command Syntax:

(no) ip igmp snooping enable

4. Example:

The following example enables IGMP snooping on the switch or **vlan1.1**:

```
switch_a#configure terminal  
switch_a(config)#ip igmp snooping[/pre]
```

```
switch_a(config)#interface vlan1.1  
switch_a(config)#ip igmp snooping[/pre]
```

IGMP version:

1. Command Mode: Interface mode

Logon to Configure Mode (Configure Terminal Mode).

Then logon to Interface mode.

fe1 means port 1.

The **switch_a(config-if)#** prompt will show on the screen.

```
switch_a(config)#interface fe1  
switch_a(config-if)#[/pre]
```

2. Usage:

Use **ip igmp version** command to set the current IGMP protocol version on an interface.

To return to the default version, use the **no ip igmp version** command.

3. Command Syntax:

ip igmp version VERSION

no ip igmp version

VERSION IGMP protocol version number.

4. Example:

The following example sets the IGMP protocol version 3 on **fe1** (port1):

```
switch_a(config)#interface fe1  
switch_a(config-if)#ip igmp version 3[/pre]
```

OPTICAL SYSTEMS DESIGN

Fast-leave:

1. Command Mode: Interface mode

Logon to Configure Mode (Configure Terminal Mode).

Then logon to Interface mode.

vlan1.1 means vlan 1.

The **switch_a(config-if)#** prompt will show on the screen.

```
switch_a(config)#interface vlan1.1  
switch_a(config-if)#
```

2. Usage:

Use **ip igmp snooping fast-leave** command to enable IGMP Snooping fast-leave processing. Fast-leave processing is analogous to immediate leave processing; the IGMP group-membership is removed, as soon as an IGMP leave group message is received without sending out a group-specific query.

Use the **no ip igmp snooping fast-leave** command to disable fast-leave processing.

3. Command Syntax:

```
(no) ip igmp snooping fast-leave
```

4. Example:

The following example enables IGMP snooping fast-leave on **vlan1.1**:

```
switch_a(config)#interface vlan1.1  
switch_a(config-if)#ip igmp snooping fast-leave
```

IGMP querier:

Query-interval:

1. Command Mode: Interface mode

Logon to Configure Mode (Configure Terminal Mode).

Then logon to Interface mode.

fe1 means port 1.

The **switch_a(config-if)#** prompt will show on the screen.

```
switch_a(config)#interface fe1  
switch_a(config-if)#
```

2. Usage:

Use **ip igmp query-interval** command to configure the frequency of sending IGMP host query messages.

To return to the default frequency, use the **no ip igmp query-interval** command.

3. Command Syntax:

```
ip igmp query-interval INTERVAL
```

```
no ip igmp query-interval
```

INTERVAL <1-18000> Frequency (in seconds) at which IGMP host query messages are sent.

4. Example:

The following example changes the frequency of sending IGMP host-query messages to 2 minutes on interface fe1 (port1):

```
switch_a(config)#interface fe1  
switch_a(config-if)#ip igmp query-interval 120
```

OPTICAL SYSTEMS DESIGN

IGMP querier:

Max-response-time:

1. Command Mode: Interface mode

Logon to Configure Mode (Configure Terminal Mode).

Then logon to Interface mode.

fe1 means port 1.

The **switch_a(config-if)#** prompt will show on the screen.

```
switch_a(config)#interface fe1
```

2. Usage:

Use **ip igmp query-max-response-time** command to configure the frequency of sending IGMP host query messages.

To return to the default frequency, use the **no ip igmp query-max-response-time** command.

3. Command Syntax:

```
ip igmp query-max-response-time RESPONSETIME
```

```
no ip igmp query-max-response-time
```

RESPONSETIME <1-240> Maximum response time (in seconds) advertised in IGMP queries.

Default: 10 seconds.

4. Example:

The following example configures a maximum response time of 8 seconds on interface fe1 (port1):

```
switch_a(config)#interface fe1
```

```
switch_a(config-if)#ip igmp query-max-response-time 8
```

IGMP passive snooping:

Static mc router port:

1. Command Mode: Interface mode

Logon to Configure Mode (Configure Terminal Mode).

Then logon to Interface mode.

vlan1.1 means vlan 1.

The **switch_a(config-if)#** prompt will show on the screen.

```
switch_a(config)#interface vlan1.1
```

```
switch_a(config-if)#
```

2. Usage:

Use **ip igmp snooping mrouter interface** command to statically configure the specified VLAN constituent interface as a multicast router interface for IGMP Snooping in that VLAN.

Use the **no ip igmp snooping mrouter interface** command to remove the static configuration of the interface as a multicast router interface.

3. Command Syntax:

```
(no) ip igmp snooping mrouter interface IFNAME
```

IFNAME Specify the name of the interface

4. Example:

The following example shows interface fe1 (port 1) statically configured to be a multicast router interface on **vlan1.1**:

```
switch_a(config)#interface vlan1.1
```

```
switch_a(config-if)#ip igmp snooping mrouter interface fe1
```

OPTICAL SYSTEMS DESIGN

IGMP passive snooping:

Report suppression:

1. Command Mode: Interface mode

Logon to Configure Mode (Configure Terminal Mode).

Then logon to Interface mode.

vlan1.1 means vlan 1.

The **switch_a(config-if)#** prompt will show on the screen.

```
switch_a(config)#interface vlan1.1  
switch_a(config-if)#{
```

2. Usage:

Use **ip igmp snooping report-suppression** command to enable report suppression for IGMP versions 1 and 2.

Use the **no ip igmp snooping report-suppression** command to disable report suppression.

3. Command Syntax:

(no) ip igmp snooping report-suppression

4. Example:

The following example enables report suppression for IGMPv2 reports on **vlan1.1**:

```
switch_a(config)#interface vlan1.1  
switch_a(config-if)#ip igmp version 2  
switch_a(config-if)#ip igmp snooping report-suppression
```

NTP

NTP Status:

1. Command Mode: Configure mode

Logon to Configure Mode (Configure Terminal Mode).

The **switch_a(config)#** prompt will show on the screen.

```
switch_a(config)#{
```

2. Usage:

Use **ntp enable** command to enable NTP for the Switch.

Use **no ntp enable** command to disable NTP for the Switch.

3. Command Syntax:

(no) ntp enable

4. Example:

The following example enables NTP for the Switch:

```
switch_a(config)#ntp enable  
switch_a(config)#{
```

OPTICAL SYSTEMS DESIGN

NTP Server:

1. Command Mode: Configure mode

Logon to Configure Mode (Configure Terminal Mode).

The **switch_a(config)#** prompt will show on the screen.

```
switch_a(config)#
```

2. Usage:

Use this command to specify the IP address or Domain name of NTP server.

3. Command Syntax:

```
ntp server IP-ADDRESS | DOMAIN-NAME
```

IP-ADDRESS A.B.C.D specifies the IP address of NTP server.

DOMAIN-NAME Specifies the Domain name of NTP server.

4. Example:

The following example specifies the IP address (**192.168.1.100**) of NTP server:

```
switch_a(config)#ntp server 192.168.1.100  
switch_a(config)#
```

Sync Time:

1. Command Mode: Configure mode

Logon to Configure Mode (Configure Terminal Mode).

The **switch_a(config)#** prompt will show on the screen.

```
switch_a(config)#
```

2. Usage:

Use **ntp sync-time** command to synchronize time with NTP server.

3. Command Syntax:

```
ntp sync-time
```

4. Example:

The following example synchronizes time with NTP server:

```
switch_a(config)#ntp sync-time  
switch_a(config)#
```

Time Zone:

1. Command Mode: Configure mode

Logon to Configure Mode (Configure Terminal Mode).

The **switch_a(config)#** prompt will show on the screen.

```
switch_a(config)#
```

2. Usage:

Use this command to set time zone.

3. Command Syntax:

```
clock timezone TIMEZONE
```

TIMEZONE Specifies the time zone. (Please refer the Appendix A)

4. Example:

The following example sets time zone (Canada/Yukon):

```
switch_a(config)#clock timezone YST9YDT  
switch_a(config)#
```

OPTICAL SYSTEMS DESIGN

Polling Interval:

1. Command Mode: Configure mode

Logon to Configure Mode (Configure Terminal Mode).

The **switch_a(config)#** prompt will show on the screen.

```
switch_a(config)#
```

2. Usage:

Use this command to specify the polling interval.

3. Command Syntax:

```
ntp polling-interval MINUTE
```

MINUTE <1-10080> The polling interval. Enter a value in the range 1 to 10080 minutes.

4. Example:

The following example specifies the polling interval **60** minutes:

```
switch_a(config)#ntp polling interval 60  
switch_a(config)#
```

Daylight Saving Mode:

1. Command Mode: Configure mode

Logon to Configure Mode (Configure Terminal Mode).

The **switch_a(config)#** prompt will show on the screen.

```
switch_a(config)#
```

2. Usage:

Use this command to enable daylight saving.

Use **no clock summer-time** command to disable daylight saving.

3. Command Syntax:

```
clock summer-time TIMEZONE weekday WEEK DAY MONTH HOUR MINUTE WEEK DAY  
MONTH HOUR MINUTE OFFSET
```

TIMEZONE Specifies the daylight saving timezone.

WEEK <1-5> Specifies weekdays from Monday to Friday.

DAY <0-6> Specifies from Sunday to Saturday.

MONTH <1-12> Specifies from January to December.

HOUR <0-23> Specifies from 0 to 23.

MINUTE <0-59> Specifies from 0 to 59.

OFFSET <1-1440> Specifies from 1 to 1440 minutes.

```
clock summer-time TIMEZONE date DAY MONTH HOUR MINUTE DAY MONTH HOUR  
MINUTE OFFSET
```

TIMEZONE Specifies the daylight saving timezone.

DAY <1-31> Specifies from 1 to 31.

MONTH <1-12> Specifies from January to December.

HOUR <0-23> Specifies from 0 to 23.

MINUTE <0-59> Specifies from 0 to 59.

OFFSET <1-1440> Specifies from 1 to 1440 minutes.

no clock summer-time

4. Example:

The following example sets clock summer-time TIMEZONE (**onehour**) as daylight saving offset 60 minutes from 4 April AM0:00 to 31 October AM0:00:

```
switch_a(config)#clock summer-time onehour date 4 4 0 0 31 10 0 0 60  
switch_a(config)#
```

OPTICAL SYSTEMS DESIGN

8 APPENDIX A

TIME ZONE	COUNTRY AND CITY LISTS
EUROPE	
MEZ-1MESZ	Europe/Vienna, Europe/Berlin, Europe/Zurich
MET-1METDST	Africa/Tunis, CET, MET, Europe/Tirane, Europe/Andorra, Europe/Brussels, Europe/Prague, Europe/Copenhagen, Europe/Paris, Europe/Gibraltar, Europe/Budapest, Europe/Rome, Europe/Vaduz, Europe/Luxembourg, Europe/Malta, Europe/Monaco, Europe/Amsterdam, Europe/Oslo, Europe/Warsaw, Europe/Belgrade, Europe/Madrid, Africa/Ceuta, Europe/Stockholm, Europe/Vatican, Europe/San_Marino, Arctic/Longyearbyen, Atlantic/Jan_Mayen, Europe/Ljubljana, Europe/Sarajevo, Europe/Skopje, Europe/Zagreb, Europe/Bratislava, Poland
EET-2EETDST	Asia/Nicosia, EET, Europe/Minsk, Europe/Sofia, Europe/Athens, Europe/Vilnius, Europe/Chisinau, Europe/Istanbul, Europe/Kiev, Europe/Uzhgorod, Europe/Zaporozhye, Europe/Nicosia, Asia/Istanbul, Europe/Tiraspol, Turkey
GMT0BST	Europe/London, Europe/Dublin, Eire, Europe/Belfast, GB, GB-Eire
WET0WETDST	WET, Atlantic/Faeroe, Atlantic/Madeira, Atlantic/Canary
PWT0PST	Europe/Lisbon, Portugal
MST-3MDT	Europe/Moscow, W-SU
EUT-1EUTDST	America/Scoresbysund, Atlantic/Azores
EUT-2EUTDST	Asia/Beirut, Europe/Simferopol
EUT-3EUTDST	Asia/Tbilisi
EUT-4EUTDST	Europe/Samara
EUT-6EUTDST	Asia/Almaty, Asia/Qyzylorda
EUT-8EUTDST	Asia/Ulaanbaatar
RUSSIAN FEDERATION	
RFT-2RFTDST	Europe/Kaliningrad
RFT-3RFTDST	Europe/Moscow
RFT-4RFTDST	Asia/Yerevan, Asia/Baku, Asia/Oral, Asia/Ashkhabad
RFT-5RFTDST	Asia/Aqtobe, Asia/Aqtau, Asia/Bishkek, Asia/Yekaterinburg
RFT-6RFTDST	Asia/Omsk, Asia/Novosibirsk
RFT-7RFTDST	Asia/Hovd, Asia/Krasnoyarsk
RFT-8RFTDST	Asia/Irkutsk, Asia/Chungking, Asia/Ulan_Bator
RFT-9RFTDST	Asia/Choibalsan, Asia/Yakutsk
RFT-10RFTDST	Asia/Vladivostok
RFT-11RFTDST	Asia/Sakhalin, Asia/Magadan
RFT-12RFTDST	Asia/Kamchatka, Asia/Anadyr
NORTH AMERICA	
PST8PDT	America/Los_Angeles, US/Pacific-New, PST8PDT, US/Pacific, SystemV/PST8PDT
MST7MDT	America/Denver, America/Boise, America/Cambridge_Bay, America/Shiprock, MST7MDT, Navajo, US/Mountain, SystemV/MST7MDT
MST7	America/Phoenix, MST, US/Arizona, SystemV/MST7
CST6CDT	America/Chicago, America/North_Dakota/Center, America/Menominee, America/Costa_Rica, America/Managua, CST6CDT, US/Central, SystemV/CST6CDT
EST5EDT	America/New_York, America/Kentucky/Louisville, America/Kentucky/Monticello, America/Detroit, America/Pangnirtung, America/Louisville, EST5EDT, US/Eastern, US/Michigan, SystemV/EST5EDT
AST4ADT	America/Thule, Atlantic/Bermuda, SystemV/AST4ADT
EST5	America/Coral_Harbour, America/Cayman, America/Jamaica, America/Panama, EST, Jamaica, SystemV/EST5

OPTICAL SYSTEMS DESIGN

AST10ADT	America/Adak, America/Atka, US/Aleutian
YST9YDT	Canada/Yukon
NST3:30NDT	America/St_Johns, Canada/Newfoundland
NAST3NADT	America/Godthab, America/Miquelon
NAST9NADT	Pacific/Pitcairn, America/Juneau, America/Yakutat, America/Anchorage, America/Nome, US/Alaska, SystemV/YST9YDT, SystemV/PST8
SOUTH AMERICA AND CENTRAL AMERICA	
TTST4	America/Port_of_Spain
SAT3	America/Argentina/Buenos_Aires, America/Argentina/Cordoba, America/Argentina/Tucuman, America/Argentina/La_Rioja, America/Argentina/San_Juan, America/Argentina/Jujuy, America/Argentina/Catamarca, America/Argentina/Mendoza, America/Argentina/Rio_Gallegos, America/Argentina/Ushuaia, America/Argentina/ComodRivadavia, America/Buenos_Aires, America/Cordoba, America/Jujuy, America/Mendoza
EBST3EBDT	America/Fortaleza, America/Recife, America/Araguaina, America/Maceio, America/Bahia, America/Sao_Paulo, America/Cuiaba, America/Montevideo, America/Catamarca, America/Rosario, Brazil/East
WBST4WBDT	America/Campo_Grande, America/Boa_Vista, America/Manaus, Atlantic/Stanley, America/Asuncion, Brazil/West
ACRE5	America/Rio_Branco, America/Porto_Acre, Brazil/Acre
NORO2	America/Noronha, Brazil/DeNoronha
CST4CDT	Antarctica/Palmer, America/Santiago, Chile/Continental
EIST6EIDT	Pacific/Easter, Chile/EasterIsland
ASIA	
MST-8	Asia/Kuala_Lumpur, Asia/Kuching
CST-8	Asia/Harbin, Asia/Shanghai, Asia/Chongqing, Asia/Urumqi, Asia/Kashgar, Asia/Hong_Kong, Asia/Macau, Asia/Macao, Hongkong, PRC, ROC
OCEANIA	
CST-9:30CDT	Australia/Adelaide, Australia/Broken_Hill, Australia/South, Australia/Yancowinna
EST-10EDT	Australia/Brisbane, Australia/Lindeman, Australia/Currie, Australia/Melbourne, Australia/Sydney, Australia/ACT, Australia/Canberra, Australia/NSW, Australia/Queensland, Australia/Tasmania, Australia/Victoria
LHT-10:30LHDT	Australia/Lord_Howe, Australia/LHI
TST-10TDT	Australia/Hobart
NZST-12NZDT	Antarctica/McMurdo, Pacific/Auckland, Antarctica/South_Pole, NZ
CIST-12:45CIDT	Pacific/Chatham, NZ-CHAT
AFRICA	
SAST-2	Africa/Maseru, Africa/Johannesburg, Africa/Mbabane
EST-2EDT	Africa/Cairo, Egypt
UAEST-4	Asia/Dubai
IST-3IDT	Asia/Baghdad
JST-2JDT	Asia/Amman
SST-2SDT	Asia/Damascus

OPTICAL SYSTEMS DESIGN

UNIVERSAL	
UCT	Africa/Ouagadougou, Africa/Abidjan, Africa/Banjul, Africa/Accra, Africa/Conakry, Africa/Bissau, Africa/Monrovia, Africa/Bamako, Africa/Nouakchott, Africa/Casablanca, Africa/El_Aaiun, Atlantic/St_Helena, Africa/Sao_Tome, Africa/Dakar, Africa/Freetown, Africa/Lome, America/Danmarkshavn, Atlantic/Reykjavik, Etc/GMT, Etc/UTC, Etc/UCT, GMT, Etc/Universal, Etc/Zulu, Etc/Greenwich, Etc/GMT-0, Etc/GMT+0, Etc/GMT0, Africa/Timbuktu, GMT+0, GMT-0, GMT0, Greenwich, Iceland, UCT, UTC, Universal, Zulu
UCT1	Atlantic/Cape_Verde, Etc/GMT+1
UCT2	Atlantic/South_Georgia, Etc/GMT+2
UCT3	Antarctica/Rothera, America/Belem, America/Cayenne, America/Paramaribo, Etc/GMT+3
UCT4	America/Anguilla, America/Antigua, America/Barbados, America/Dominica, America/Grenada, America/Guadeloupe, America/Martinique, America/Montserrat, America/Puerto_Rico, America/St_Kitts, America/St_Lucia, America/St_Vincent, America/Tortola, America/St_Thomas, America/Aruba, America/La_Paz, America/Porto_Velho, America/Curacao, America/Caracas, America/Guyana, Etc/GMT+4, America/Virgin, SystemV/AST4
UCT5	America/Guayaquil, America/Eirunepe, America/Lima, Etc/GMT+5
UCT6	America/Belize, America/El_Salvador, America/Tegucigalpa, Pacific/Galapagos, Etc/GMT+6
UCT7	Etc/GMT+7
UCT8	Etc/GMT+8
UCT9	Pacific/Gambier, Etc/GMT+9, SystemV/YST9
UCT10	Pacific/Rarotonga, Pacific/Tahiti, Pacific/Fakaofo, Pacific/Johnston, Pacific/Honolulu, Etc/GMT+10, HST, US/Hawaii, SystemV/HST10
UCT11	Pacific/Niue, Pacific/Pago_Pago, Pacific/Apia, Pacific/Midway, Etc/GMT+11, Pacific/Samoa, US/Samoa
UCT-1	Africa/Algiers, Africa/Luanda, Africa/Porto-Novo, Africa/Douala, Africa/Bangui, Africa/Ndjamena, Africa/Kinshasa, Africa/Brazzaville, Africa/Malabo, Africa/Libreville, Africa/Windhoek, Africa/Niamey, Africa/Lagos, Etc/GMT-1
UCT-2	Africa/Gaborone, Africa/Bujumbura, Africa/Lubumbashi, Africa/Tripoli, Africa/Blantyre, Africa/Maputo, Africa/Kigali, Africa/Lusaka, Africa/Harare, Etc/GMT-2, Libya
UCT-3	Indian/Comoro, Africa/Djibouti, Africa/Asmera, Africa/Addis_Ababa, Africa/Nairobi, Indian/Antananarivo, Indian/Mayotte, Africa/Mogadishu, Africa/Khartoum, Africa/Dar_es_Salaam, Africa/Kampala, Antarctica/Syowa, Asia/Bahrain, Asia/Kuwait, Asia/Qatar, Asia/Riyadh, Asia/Aden, Etc/GMT-3
UCT-4	Indian/Mauritius, Indian/Reunion, Indian/Mahe, Asia/Muscat, Etc/GMT-4
UCT-5	Indian/Kerguelen, Indian/Maldives, Asia/Karachi, Asia/Dushanbe, Asia/Ashgabad, Asia/Samarkand, Asia/Tashkent, Etc/GMT-5
UCT-5:45	Asia/Katmandu
UCT-6	Antarctica/Mawson, Antarctica/Vostok, Asia/Dhaka, Asia/Thimphu, Indian/Chagos, Asia/Colombo, Etc/GMT-6, Asia/Dacca, Asia/Thimbu

OPTICAL SYSTEMS DESIGN

UCT-6:30	Asia/Rangoon, Indian/Cocos
UCT-7	Antarctica/Davis, Asia/Phnom_Penh, Asia/Jakarta, Asia/Pontianak, Asia/Vientiane, Asia/Bangkok, Asia/Saigon, Indian/Christmas, Etc/GMT-7
UCT-8	Antarctica/Casey, Asia/Brunei, Asia/Taipei, Asia/Makassar, Asia/Manila, Asia/Singapore, Etc/GMT-8, Asia/Ujung_Pandang, Singapore
UCT-9	Asia/Dili, Asia/Jayapura, Pacific/Palau, Etc/GMT-9
UCT-9:30	Australia/Darwin, Australia/North
UCT-10	Antarctica/DumontDUrville, Pacific/Guam, Pacific/Saipan, Pacific/Truk, Pacific/Noumea, Pacific/Port_Moresby, Etc/GMT-10, Pacific/Yap
UCT-11	Pacific/Ponape, Pacific/Kosrae, Pacific/Guadalcanal, Etc/GMT-11
UCT-11:30	Pacific/Norfolk
UCT-12	Pacific/Fiji, Pacific/Tarawa, Pacific/Enderbury, Pacific/Majuro, Pacific/Kwajalein, Pacific/Nauru, Pacific/Tongatapu, Pacific/Funafuti, Pacific/Wake, Pacific/Efate, Pacific/Wallis, Etc/GMT-12, Kwajalein
UCT-13	Etc/GMT-13
JST	Asia/Tokyo, Japan
KST	Asia/Seoul, Asia/Pyongyang, ROK
UCT-3:30	Asia/Tehran, Iran
UCT-4:30	Asia/Kabul
IST-2IDT	Asia/Jerusalem, Asia/Gaza, Asia/Tel_Aviv, Israel
CST6MEX	America/Cancun, America/Merida, America/Monterrey, America/Mexico_City, America/Lima, Mexico/General
CST6	America/Regina, America/Swift_Current, Canada/East-Saskatchewan, Canada/Saskatchewan, SystemV/CST6
EET-2EETDST2	Europe/Bucharest
EET-2EETDST3	Europe/Tallinn, Europe/Helsinki, Europe/Riga, Europe/Mariehamn
EET-2EETDST2W2K	Europe/Istanbul
UCT-14	Pacific/Kiritimati, Etc/GMT-14
UCT9:30	Pacific/Marquesas
UCT12	Etc/GMT+12
NORTH AMERICA (CANADA)	
PST8PDT_CA	America/Vancouver, America/Dawson_Creek, America/Whitehorse, America/Dawson, Canada/Pacific
MST7MDT_CA	America/Edmonton, America/Yellowknife, America/Inuvik, Canada/Mountain
CST6CDT_CA	America/Rainy_River, America/Winnipeg, America/Rankin_Inlet, Canada/Central
EST5EDT_CA	America/Montreal, America/Toronto, America/Thunder_Bay, America/Nipigon, America/Iqaluit, Canada/Eastern
AST4ADT_CA	America/Goose_Bay, America/Halifax, America/Glace_Bay, Canada/Atlantic
NORTH AMERICA (CUBA)	
EST5EDT CU	America/Havana, Cuba
NORTH AMERICA (HAITI)	
EST5EDT HT	America/Nassau, America/Santo_Domingo, America/Port-au-Prince, America/Bogota
NORTH AMERICA (MEXICO)	
PST8PDT MX	America/Tijuana, America/Ensenada, Mexico/BajaNorte
MST7MDT MX	America/Chihuahua, America/Hermosillo, America/Mazatlan, Mexico/BajaSur
CST6CDT MX	America/Guatemala

OPTICAL SYSTEMS DESIGN

NORTH AMERICA (TURKS AND CAICOS)	
EST5EDT_TC	America/Grand_Turk
ADDITIONS SINCE 10g RTM	
EST5EDT_INDIANA	America/Indiana/Indianapolis, America/Indiana/Marengo, America/Indiana/Vevay, America/Fort_Wayne, America/Indianapolis, America/Indiana/Knox, America/Knox_IN, US/Indiana-Starke, US/East-Indiana
UCT-8_WA	Australia/Perth, Australia/West

9 APPENDIX B

OSD Systems Managed switches firmware release notes		
Switch Series Affected	Protocols/ Functions Involved	Release notes
		Ver 1.94.1
		Add New protocol or commands
All	Chain protocol	Add Chain-Pass-through protocol
All	LLDP	Add LLDP protocol
All	CLI	Add CLI command - web UI can be disabled
All	CLI	Add CLI command -detach CPU
All	User Account	Add Multi user (Admin / Technician / Operator)
All	System log	Add System log(Local /remote)
All	VLAN	Add Port priority
All	Web interface	Add Clear button for RMON statistics to reset counter information and auto refresh per 10 sec
		Enhancement or changes
All	VLAN	Modify :The Maxium Vlan-Number from 128 to 64.
All	IGMP Snooping	Modify :IGMP snooping force-forward/pассив CLI and GUI for trunking port
All	Ring coupling	Modify :Ring Coupling Port 2 unused options string.
All	Web interface	Modify :SNMPv3 account limit to 20 on webpage
All	Loopback-Detect	Change :The max value of loopback-detect interval to 30
All	NTP	Change :Limit the timezone name not to over 6 characters
All	NTP	Change :NTP server to [time-a.nist.gov]
All	Web interface	Change: web banner of the switch interface to generic interface

OPTICAL SYSTEMS DESIGN

10 MAINTENANCE

10.1 INTRODUCTION

The following section outlines the fault-finding procedure for the OSD2380 modems. Please take note of the following:

- ▲ Personnel without appropriate training should not attempt any maintenance except that outlined below.
- ▲ If further maintenance is attempted you are warned that every care should be taken to ensure that internal measurements made while the equipment is operational are taken carefully as some components within the unit are expensive and may be damaged by failure of any portion of their support circuitry.
- ▲ Some components within the unit are Electrostatic (ES) sensitive and Electrostatic Discharge (ESD) precautions should be taken when performing maintenance upon the unit.

10.2 EXTERNAL INSPECTION

Visually check for the following:

- ▲ Check that the correct power source is connected to the power socket.
- ▲ Check that the Ethernet cables are connected to the modem correctly and that distant modem(s) have been connected correctly to any external equipment.
- ▲ Inspect the optical connectors (for fiber SFP option) for any contamination and clean using isopropyl alcohol and a lint free tissue if any contamination is detected.

10.3 ROUTINE MAINTENANCE

- ▲ There is no routine maintenance required with the OSD2380.

OPTICAL SYSTEMS DESIGN

11 WARRANTY

Thank you for purchasing equipment designed, manufactured and serviced by Optical Systems Design (OSD). OSD warrants that at the time of shipment, its products are free from defects in material and workmanship and conforms to specifications. Our Warranty conditions are outlined below:

11.1 WARRANTY PERIOD

For warranty period, please contact your local OSD distributor.

11.2 REPAIRS

Optical Systems Design reserves the right to repair or replace faulty modules/units. Please obtain a “Return Material Authorisation” (RMA) form and number before returning goods.

Goods must be returned in adequate packing material to Optical Systems Design, Warriewood or its nominated authorised representative, for all repairs.

11.2.1 WARRANTY REPAIRS

Return shipments to OSD shall be at customer's expense and freight back to the customer will be at OSD expense.

11.2.2 OUT-OF-WARRANTY REPAIRS

OSD reserves the right to repair or replace any faulty goods. Freight costs and insurance for both journeys are met by the user. All equipment repaired by OSD will have a 3-Month Warranty from the date of dispatch.

11.2.3 SITE REPAIRS

By agreement site repairs may be undertaken for which out of pocket, hotel and travel expenses will be charged.

11.2.4 EXCLUSIONS

This warranty does not apply to defects caused by unauthorized modifications, misuse, abuse or transport damage to the equipment. All modifications to OSD's standard product will need written authorization and will be charged at normal repair rates. All modifications are to be carried out by OSD Technicians. Warranty is void if unauthorized removal and/or tampering with serial number and/or repair labels is evident.

Optical Systems Design Pty. Ltd.
7/1 Vuko Pl. Warriewood 2102
P.O. Box 891 Mona Vale
N.S.W. Australia 2103
Telephone: +61 2 9913 8540
Facsimile: +61 2 9913 8735
Email: sales@osd.com.au
Web Site: www.osd.com.au

OPTICAL

SYSTEMS

DESIGN

PTY LTD

A.B.N. 83 003 020 504

Printed in Australia